

# 1 Test Results for Mobile Device Acquisition Tool – 2 Lantern v4.5.6

3 The main item of interest for interpreting the test results is determining the conformance  
4 of the tool under test. Conformance with each assertion tested by a given test case is  
5 evaluated by examining the **Log Highlights** box of the test report.  
6

## 7 1.1 Test Results Report Key

8 The following table presents an explanation of each section of the test details in section  
9 1.2. The Tester Name, Test Host, Test Date, Device, Source Setup and Log Highlights  
10 sections for each test case are populated by excerpts taken from the log files produced by  
11 the tool under test.  
12  
13

Heading	Description
First Line:	Test case ID, name, and version of tool tested.
Case Summary:	Test case summary from <i>Mobile Device Tool Test Assertions and Test Plan (Draft 1 Version 1.0, July 8, 2014)</i> .
Assertions:	The test assertions applicable to the test case, selected from <i>Mobile Device Tool Test Assertions and Test Plan (Draft 1 Version 1.0, July 8, 2014)</i> .
Tester Name:	Name or initials of person executing test procedure.
Test Host:	Host computer executing the test.
Test Date:	Time and date that test was started.
Device:	Source mobile device, SIM.
Source Setup:	Acquisition interface.
Log Highlights:	Information extracted from various log files to illustrate conformance or non-conformance to the test assertions.

14 **Table 1: Test Results Report Key**  
15

## 1.2 Test Results

The test results are presented in this section.

### 1.2.1 MDT-01 – iPhone5 GSM

Test Case MDT-01 Lantern v4.5.6		
Case Summary:	MDT-01 Acquire mobile device internal memory over tool-supported interfaces (e.g., cable, Bluetooth, IrDA).	
Assertions:	MDT-CA-01 If a mobile device forensic tool provides support for connectivity of the target device then the tool shall successfully recognize the target device via all vendor supported interfaces (e.g., cable, Bluetooth, IrDA).	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Thu Apr 2 06:12:23 EDT 2015	
Device:	iPhone5_GSM	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 06:12:23 EDT 2015 Acquisition finished: Thu Apr 2 06:21:48 EDT 2015  Device connectivity was established via supported interface	
Results:		
	<b>Assertion &amp; Expected Result</b>	<b>Actual Result</b>
	MDT-CA-01 Device connectivity via supported interfaces.	as expected
Analysis:	Expected results achieved	

### 1.2.2 MDT-02 – iPhone5 GSM

Test Case MDT-02 Lantern v4.5.6		
Case Summary:	MDT-02 Begin mobile device internal memory acquisition and interrupt connectivity by interface disengagement.	
Assertions:	MDT-CA-02 If connectivity between the mobile device and mobile device forensic tool is disrupted then the tool shall notify the user that connectivity has been disrupted.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Thu Apr 2 06:12:59 EDT 2015	
Device:	iPhone5_GSM	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 06:12:59 EDT 2015 Acquisition finished: Thu Apr 2 06:22:04 EDT 2015  Device acquisition disruption notification was successful	
Results:		
	<b>Assertion &amp; Expected Result</b>	<b>Actual Result</b>
	MDT-CA-02 Notification of device acquisition disruption.	as expected
Analysis:	Expected results achieved	

### 24 1.2.3 MDT-03 – iPhone5 GSM

Test Case MDT-03 Lantern v4.5.6						
Case Summary:	MDT-03 Acquire mobile device internal memory and review reported data via the preview-pane or generated reports for readability.					
Assertions:	MDT-CA-03 If a mobile device forensic tool completes acquisition of the target device without error then the tool shall have the ability to present acquired data objects in a useable format via either a preview-pane or generated report.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Thu Apr 2 06:30:15 EDT 2015					
Device:	iPhone5_GSM					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 06:30:15 EDT 2015 Acquisition finished: Thu Apr 2 06:32:14 EDT 2015  Readability and completeness of acquired data was successful					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-03 Readability and completeness of acquired data via supported reports.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-03 Readability and completeness of acquired data via supported reports.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-03 Readability and completeness of acquired data via supported reports.	as expected					
Analysis:	Expected results achieved					

25

### 26 1.2.4 MDT-04 – iPhone5 GSM

Test Case MDT-04 Lantern v4.5.6						
Case Summary:	MDT-04 Acquire mobile device internal memory and review reported subscriber and equipment related information (e.g., IMSI, IMEI, MEID/ESN, MSISDN).					
Assertions:	MDT-CA-04 If a mobile device forensic tool completes acquisition of the target device without error then subscriber and equipment related information shall be presented in a useable format.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Thu Apr 2 06:30:43 EDT 2015					
Device:	iPhone5 GSM					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 06:30:43 EDT 2015 Acquisition finished: Thu Apr 2 06:34:12 EDT 2015  Subscriber and Equipment related data (i.e., MSISDN, IMEI) were acquired					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	as expected					
Analysis:	Expected results achieved					

27

28

## 29 1.2.5 MDT-05 – iPhone5 GSM

Test Case MDT-05 Lantern v4.5.6						
Case Summary:	MDT-05 Acquire mobile device internal memory and review supported data elements (i.e., PIM data, call logs, SMS, MMS, stand-alone files: audio, pictures, video, application related data: documents, spreadsheets, presentations, social-media data and Internet related data: bookmarks, visited sites).					
Assertions:	MDT-CA-05 If a mobile device forensic tool completes acquisition of the target device without error then all supported data elements shall be presented in a useable format.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Thu Apr 2 09:37:38 EDT 2015					
Device:	iPhone5 GSM					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 09:37:38 EDT 2015 Acquisition finished: Thu Apr 2 11:31:18 EDT 2015</p> <p>Regular Length Address Book entries were acquired Maximum Length Address Book entries were not acquired Special Character Address Book entries were acquired Blank Name Address Book entries were acquired Email addresses within Address Book entries were acquired Embedded graphics within Address Book entries were acquired ALL PIM related data was acquired All Call Logs (incoming, outgoing, missed) were acquired All Call Log date/time stamps data were correctly reported ALL text messages (SMS, EMS) were acquired Correct date/time stamps were reported for all text messages Correct status flags were reported for all text messages Sender and Recipient phone numbers associated with text messages were correctly reported ALL MMS messages (Audio, Image, Video) were acquired ALL stand-alone data files (Audio, Image, Video) were acquired All application data was acquired Partial Internet related data was acquired Partial Social media related data was acquired</p> <p><b>Notes:</b> Only first and last names were reported for contacts. Attachments were not included in email data. Media is not reported in the Lantern sidebar. Facebook and Twitter were not reported in the Lantern sidebar. Social media related data was partially reported. Gmail is not reported in the Lantern sidebar.</p>					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.</td><td>Partial</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Partial
Assertion & Expected Result	Actual Result					
MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Partial					
Analysis:	Partial results achieved					

30

31

## 32 1.2.6 MDT-06 – iPhone5 GSM

Test Case MDT-06 Lantern v4.5.6											
Case Summary:	MDT-06 Acquire mobile device internal memory by selecting a combination of supported data elements.										
Assertions:	MDT-CA-06 If a mobile device forensic tool provides the user with an Acquire All device data objects acquisition option then the tool shall complete the acquisition of all data objects without error. MDT-CA-07 If a mobile device forensic tool provides the user with an Select All individual device data objects then the tool shall complete the acquisition of all individually selected data objects without error. MDT-CA-08 If a mobile device forensic tool provides the user with the ability to Select Individual device data objects for acquisition then the tool shall acquire each exclusive data object without error. MDT-CA-09 If a mobile device forensic tool completes two consecutive logical acquisitions of the target device without error then the payload (data objects) on the mobile device shall remain consistent.										
Tester Name:	rpa										
Test Host:	p644381										
Test Date:	Thu Apr 2 06:51:51 EDT 2015										
Device:	iPhone5 GSM										
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable										
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 06:51:51 EDT 2015 Acquisition finished: Thu Apr 2 07:08:49 EDT 2015  Acquire All acquisition was successful										
Results:	<table border="1"> <thead> <tr> <th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-CA-06 Acquire-all mobile device data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-CA-07 Select-all mobile device data objects acquisition.</td><td>NA</td></tr> <tr> <td>MDT-CA-08 Select-individual mobile device data objects acquisition.</td><td>NA</td></tr> <tr> <td>MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected	MDT-CA-07 Select-all mobile device data objects acquisition.	NA	MDT-CA-08 Select-individual mobile device data objects acquisition.	NA	MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected
Assertion & Expected Result	Actual Result										
MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected										
MDT-CA-07 Select-all mobile device data objects acquisition.	NA										
MDT-CA-08 Select-individual mobile device data objects acquisition.	NA										
MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected										
Analysis:	Expected results achieved										

33

## 34 1.2.7 MDT-12 – iPhone5 GSM

Test Case MDT-12 Lantern v4.5.6	
Case Summary:	MDT-12 After a successful mobile device internal memory, alter the case file via third-party means and attempt to re-open the case.
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.
Tester Name:	rpa
Test Host:	p644381
Test Date:	Thu Apr 2 07:13:40 EDT 2015
Device:	iPhone5 GSM
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 07:13:40 EDT 2015 Acquisition finished: Thu Apr 2 07:49:07 EDT 2015  Notification of modified device memory data was not successful  <b>Notes:</b>

Test Case MDT-12 Lantern v4.5.6		
	Lantern.db was modified, the case file was re-opened without informing the user that the case data was altered. The modifications made within Lantern.db were displayed within the modified case file.	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-AO-08 Notification of modified device case data.	Not as expected
Analysis:	Expected results Not achieved	

35

## 36 1.2.8 MDT-19 – iPhone5 GSM

Test Case MDT-19 Lantern v4.5.6						
Case Summary:	MDT-19 Acquire mobile device internal memory and review data containing non-ASCII characters.					
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Thu Apr 2 08:10:24 EDT 2015					
Device:	iPhone5 GSM					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 08:10:24 EDT 2015 Acquisition finished: Thu Apr 2 08:13:20 EDT 2015  Non-ASCII Address book entries were acquired and properly displayed Non-ASCII text messages were acquired and properly displayed					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected					
Analysis:	Expected results achieved					

37

## 38 1.2.9 MDT-22 – iPhone5 GSM

Test Case MDT-22 Lantern v4.5.6		
Case Summary:	MDT-22 Acquire mobile device internal memory and review hash values for vendor supported data objects.	
Assertions:	MDT-AO-15 If the mobile device forensic tool supports hashing for individual data objects then the tool shall present the user with a hash value for each supported data object.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Thu Apr 2 08:16:32 EDT 2015	
Device:	iPhone5 GSM	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 08:16:32 EDT 2015 Acquisition finished: Thu Apr 2 08:24:20 EDT 2015</p> <p>Hash values were properly reported for individually acquired device data elements</p>	

Test Case MDT-22 Lantern v4.5.6		
Results:	<b>Assertion &amp; Expected Result</b>	
	<b>Actual Result</b>	
	MDT-AO-15 Hash values for individual data and case presented in a useable format.	as expected
Analysis:	Expected results achieved	

39

## 40 1.2.10 MDT-24 – iPhone5 GSM

Test Case MDT-24 Lantern v4.5.6		
Case Summary:	MDT-24 Acquire mobile device internal memory and review data containing GPS longitude and latitude coordinates	
Assertions:	MDT-AO-16 If the mobile device forensic tool supports acquisition of GPS data then the tool shall present the user with the longitude and latitude coordinates for all GPS-related data in a useable format.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Thu Apr 2 08:27:44 EDT 2015	
Device:	iPhone5 GSM	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	<p>Created by Lantern v4.5.6  Acquisition started: Thu Apr 2 08:27:44 EDT 2015  Acquisition finished: Thu Apr 2 09:20:42 EDT 2015</p> <p>GPS Coordinate data was not successfully acquired</p> <p><b>Notes:</b>  The KMZ file was not reported. Partial location information can be located in: /private/var/mobile/library/maps/Direction.mapsdata</p>	
Results:	<b>Assertion &amp; Expected Result</b>	
	<b>Actual Result</b>	
	MDT-AO-16 Acquisition of GPS related data presented in a useable format.	Not as expected
Analysis:	Expected results Not achieved	

41

## 42 1.2.11 MDT-01 – iPhone5S CDMA

Test Case MDT-01 Lantern v4.5.6		
Case Summary:	MDT-01 Acquire mobile device internal memory over tool-supported interfaces (e.g., cable, Bluetooth, IrDA).	
Assertions:	MDT-CA-01 If a mobile device forensic tool provides support for connectivity of the target device then the tool shall successfully recognize the target device via all vendor supported interfaces (e.g., cable, Bluetooth, IrDA).	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Thu Apr 2 06:13:42 EDT 2015	
Device:	iPhone5S CDMA	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	<p>Created by Lantern v4.5.6  Acquisition started: Thu Apr 2 06:13:42 EDT 2015  Acquisition finished: Thu Apr 2 06:23:20 EDT 2015</p>	

Test Case MDT-01 Lantern v4.5.6						
	Device connectivity was established via supported interface					
	<b>Notes:</b> Lantern prompted user for iTunes Encryption password. Without the password the following data elements are acquired: System Data, App Data, Photos, Video, and Media.					
Results:						
	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-01 Device connectivity via supported interfaces.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-01 Device connectivity via supported interfaces.	as expected
	Assertion & Expected Result	Actual Result				
MDT-CA-01 Device connectivity via supported interfaces.	as expected					
Analysis:	Expected results achieved					

43

## 44 1.2.12 MDT-02 – iPhone5S CDMA

Test Case MDT-02 Lantern v4.5.6						
Case Summary:	MDT-02 Begin mobile device internal memory acquisition and interrupt connectivity by interface disengagement.					
Assertions:	MDT-CA-02 If connectivity between the mobile device and mobile device forensic tool is disrupted then the tool shall notify the user that connectivity has been disrupted.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Thu Apr 2 06:14:01 EDT 2015					
Device:	iPhone5S CDMA					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 06:14:01 EDT 2015 Acquisition finished: Thu Apr 2 06:23:26 EDT 2015  Device acquisition disruption notification was successful					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-02 Notification of device acquisition disruption.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-02 Notification of device acquisition disruption.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-02 Notification of device acquisition disruption.	as expected					
Analysis:	Expected results achieved					

45

## 46 1.2.13 MDT-03 – iPhone5S CDMA

Test Case MDT-03 Lantern v4.5.6		
Case Summary:	MDT-03 Acquire mobile device internal memory and review reported data via the preview-pane or generated reports for readability.	
Assertions:	MDT-CA-03 If a mobile device forensic tool completes acquisition of the target device without error then the tool shall have the ability to present acquired data objects in a useable format via either a preview-pane or generated report.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Thu Apr 2 06:31:14 EDT 2015	
Device:	iPhone5S CDMA	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 06:31:14 EDT 2015 Acquisition finished: Thu Apr 2 06:43:53 EDT 2015  Readability and completeness of acquired data was successful	

Test Case MDT-03 Lantern v4.5.6		
Results:		
	Assertion & Expected Result	Actual Result
	MDT-CA-03 Readability and completeness of acquired data via supported reports.	as expected
Analysis:	Expected results achieved	

47

## 48 1.2.14 MDT-04 – iPhone5S CDMA

Test Case MDT-04 Lantern v4.5.6		
Case Summary:	MDT-04 Acquire mobile device internal memory and review reported subscriber and equipment related information (e.g., IMSI, IMEI, MEID/ESN, MSISDN).	
Assertions:	MDT-CA-04 If a mobile device forensic tool completes acquisition of the target device without error then subscriber and equipment related information shall be presented in a useable format.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Thu Apr 2 06:31:38 EDT 2015	
Device:	iPhone5S CDMA	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 06:31:38 EDT 2015 Acquisition finished: Thu Apr 2 06:44:00 EDT 2015  IMEI, MEID/ESN were acquired	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	as expected
Analysis:	Expected results achieved	

49

## 50 1.2.15 MDT-05 – iPhone5S CDMA

Test Case MDT-05 Lantern v4.5.6		
Case Summary:	MDT-05 Acquire mobile device internal memory and review supported data elements (i.e., PIM data, call logs, SMS, MMS, stand-alone files: audio, pictures, video, application related data: documents, spreadsheets, presentations, social-media data and Internet related data: bookmarks, visited sites).	
Assertions:	MDT-CA-05 If a mobile device forensic tool completes acquisition of the target device without error then all supported data elements shall be presented in a useable format.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Thu Apr 2 09:38:12 EDT 2015	
Device:	iPhone5S CDMA	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 09:38:12 EDT 2015 Acquisition finished: Thu Apr 2 11:31:26 EDT 2015  All stand-alone data files (Audio, Image, Video) were acquired	

Test Case MDT-05 Lantern v4.5.6		
	<p>Application data was not acquired Internet related data was not acquired Partial Social media related data was acquired</p> <p><b>Notes:</b> Facebook and Twitter were not reported in the Lantern sidebar. Partial social media related data for LinkedIn was reported. No social media data for facebook or twitter was reported.</p>	
Results:		
	<b>Assertion &amp; Expected Result</b>	<b>Actual Result</b>
	MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Partial
Analysis:	Expected results Not achieved	

51

52 **1.2.16 MDT-06 – iPhone5S CDMA**

Test Case MDT-06 Lantern v4.5.6												
Case Summary:	MDT-06 Acquire mobile device internal memory by selecting a combination of supported data elements.											
Assertions:	MDT-CA-06 If a mobile device forensic tool provides the user with an Acquire All device data objects acquisition option then the tool shall complete the acquisition of all data objects without error. MDT-CA-07 If a mobile device forensic tool provides the user with an Select All individual device data objects then the tool shall complete the acquisition of all individually selected data objects without error. MDT-CA-08 If a mobile device forensic tool provides the user with the ability to Select Individual device data objects for acquisition then the tool shall acquire each exclusive data object without error. MDT-CA-09 If a mobile device forensic tool completes two consecutive logical acquisitions of the target device without error then the payload (data objects) on the mobile device shall remain consistent.											
Tester Name:	rpa											
Test Host:	p644381											
Test Date:	Thu Apr 2 06:51:25 EDT 2015											
Device:	iPhone5S CDMA											
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable											
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 06:51:25 EDT 2015 Acquisition finished: Thu Apr 2 07:08:56 EDT 2015  Acquire All acquisition was successful											
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-06 Acquire-all mobile device data objects acquisition.</td><td>as expected</td></tr><tr><td>MDT-CA-07 Select-all mobile device data objects acquisition.</td><td>NA</td></tr><tr><td>MDT-CA-08 Select-individual mobile device data objects acquisition.</td><td>NA</td></tr><tr><td>MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected	MDT-CA-07 Select-all mobile device data objects acquisition.	NA	MDT-CA-08 Select-individual mobile device data objects acquisition.	NA	MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected
Assertion & Expected Result	Actual Result											
MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected											
MDT-CA-07 Select-all mobile device data objects acquisition.	NA											
MDT-CA-08 Select-individual mobile device data objects acquisition.	NA											
MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected											
Analysis:	Expected results achieved											

53

54 **1.2.17 MDT-12 – iPhone5S CDMA**

<b>Test Case MDT-12 Lantern v4.5.6</b>					
Case Summary:	MDT-12 After a successful mobile device internal memory, alter the case file via third-party means and attempt to re-open the case.				
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.				
Tester Name:	rpa				
Test Host:	p644381				
Test Date:	Thu Apr 2 07:14:09 EDT 2015				
Device:	iPhone5S CDMA				
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable				
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 07:14:09 EDT 2015 Acquisition finished: Thu Apr 2 07:52:40 EDT 2015</p> <p>Notification of modified device memory data was not successful</p> <p><b>Notes:</b> Lantern.db was modified, the case file was re-opened without informing the user that the case data was altered. The modifications made within Lantern.db were displayed within the modified case file.</p>				
Results:	<table border="1"> <thead> <tr> <th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-AO-08 Notification of modified device case data.</td><td>Not as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-AO-08 Notification of modified device case data.	Not as expected
Assertion & Expected Result	Actual Result				
MDT-AO-08 Notification of modified device case data.	Not as expected				
Analysis:	Expected results Not achieved				

55

56 **1.2.18 MDT-22 – iPhone5S CDMA**

<b>Test Case MDT-22 Lantern v4.5.6</b>					
Case Summary:	MDT-22 Acquire mobile device internal memory and review hash values for vendor supported data objects.				
Assertions:	MDT-AO-15 If the mobile device forensic tool supports hashing for individual data objects then the tool shall present the user with a hash value for each supported data object.				
Tester Name:	rpa				
Test Host:	p644381				
Test Date:	Thu Apr 2 08:16:57 EDT 2015				
Device:	iPhone5S CDMA				
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable				
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 08:16:57 EDT 2015 Acquisition finished: Thu Apr 2 08:24:53 EDT 2015</p> <p>Hash values were properly reported for individually acquired device data elements</p>				
Results:	<table border="1"> <thead> <tr> <th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-AO-15 Hash values for individual data and case presented in a useable format.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-AO-15 Hash values for individual data and case presented in a useable format.	as expected
Assertion & Expected Result	Actual Result				
MDT-AO-15 Hash values for individual data and case presented in a useable format.	as expected				
Analysis:	Expected results achieved				

57

58 **1.2.19 MDT-01 – iPad GSM**

Test Case MDT-01 Lantern v4.5.6						
Case Summary:	MDT-01 Acquire mobile device internal memory over tool-supported interfaces (e.g., cable, Bluetooth, IrDA).					
Assertions:	MDT-CA-01 If a mobile device forensic tool provides support for connectivity of the target device then the tool shall successfully recognize the target device via all vendor supported interfaces (e.g., cable, Bluetooth, IrDA).					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Thu Apr 2 06:14:25 EDT 2015					
Device:	iPad GSM					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 06:14:25 EDT 2015 Acquisition finished: Thu Apr 2 06:24:16 EDT 2015  Device connectivity was established via supported interface					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-01 Device connectivity via supported interfaces.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-01 Device connectivity via supported interfaces.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-01 Device connectivity via supported interfaces.	as expected					
Analysis:	Expected results achieved					

59

60 **1.2.20 MDT-02 – iPad GSM**

Test Case MDT-02 Lantern v4.5.6						
Case Summary:	MDT-02 Begin mobile device internal memory acquisition and interrupt connectivity by interface disengagement.					
Assertions:	MDT-CA-02 If connectivity between the mobile device and mobile device forensic tool is disrupted then the tool shall notify the user that connectivity has been disrupted.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Thu Apr 2 06:14:47 EDT 2015					
Device:	iPad GSM					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 06:14:47 EDT 2015 Acquisition finished: Thu Apr 2 06:24:26 EDT 2015  Device acquisition disruption notification was successful					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-02 Notification of device acquisition disruption.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-02 Notification of device acquisition disruption.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-02 Notification of device acquisition disruption.	as expected					
Analysis:	Expected results achieved					

61

62

63

64

65

66 **1.2.21 MDT-03 – iPad GSM**

Test Case MDT-03 Lantern v4.5.6						
Case Summary:	MDT-03 Acquire mobile device internal memory and review reported data via the preview-pane or generated reports for readability.					
Assertions:	MDT-CA-03 If a mobile device forensic tool completes acquisition of the target device without error then the tool shall have the ability to present acquired data objects in a useable format via either a preview-pane or generated report.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Thu Apr 2 06:32:14 EDT 2015					
Device:	iPadGSM					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 06:32:14 EDT 2015 Acquisition finished: Thu Apr 2 06:45:20 EDT 2015  Readability and completeness of acquired data was successful					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-03 Readability and completeness of acquired data via supported reports.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-03 Readability and completeness of acquired data via supported reports.	as expected
	Assertion & Expected Result	Actual Result				
MDT-CA-03 Readability and completeness of acquired data via supported reports.	as expected					
Analysis:	Expected results achieved					

67

68 **1.2.22 MDT-04 – iPad GSM**

Test Case MDT-04 Lantern v4.5.6						
Case Summary:	MDT-04 Acquire mobile device internal memory and review reported subscriber and equipment related information (e.g., IMSI, IMEI, MEID/ESN, MSISDN).					
Assertions:	MDT-CA-04 If a mobile device forensic tool completes acquisition of the target device without error then subscriber and equipment related information shall be presented in a useable format.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Thu Apr 2 06:32:33 EDT 2015					
Device:	iPad GSM					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 06:32:33 EDT 2015 Acquisition finished: Thu Apr 2 06:45:27 EDT 2015  Subscriber and Equipment related data (i.e., MSISDN, IMEI) were acquired					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	as expected					
Analysis:	Expected results achieved					

69

70

71

## 1.2.23 MDT-05 – iPad GSM

Test Case MDT-05 Lantern v4.5.6						
Case Summary:	MDT-05 Acquire mobile device internal memory and review supported data elements (i.e., PIM data, call logs, SMS, MMS, stand-alone files: audio, pictures, video, application related data: documents, spreadsheets, presentations, social-media data and Internet related data: bookmarks, visited sites).					
Assertions:	MDT-CA-05 If a mobile device forensic tool completes acquisition of the target device without error then all supported data elements shall be presented in a useable format.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Thu Apr 2 09:38:49 EDT 2015					
Device:	iPad GSM					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 09:38:49 EDT 2015 Acquisition finished: Thu Apr 2 11:31:35 EDT 2015</p> <p>Regular Length Address Book entries were acquired Maximum Length Address Book entries were not acquired Special Character Address Book entries were acquired Blank Name Address Book entries were acquired Email addresses within Address Book entries were acquired Embedded graphics within Address Book entries were acquired ALL PIM related data was acquired All Call Logs (incoming, outgoing, missed) were acquired All Call Log date/time stamps data were correctly reported ALL text messages (SMS, EMS) were acquired Correct date/time stamps were reported for all text messages Correct status flags were reported for all text messages Sender and Recipient phone numbers associated with text messages were correctly reported ALL MMS messages (Audio, Image, Video) were acquired ALL stand-alone data files (Audio, Image, Video) were acquired All application data was acquired All Internet related data was acquired Partial Social media related data was acquired</p> <p><b>Notes:</b> Only first and last names were reported for contacts. Recovered MMS messages did not contain associated attachments. Media is not reported in the Lantern sidebar. Attachments were not included in email data. LinkedIn, facebook and twitter were not reported in the Lantern sidebar. Social media related data was partially reported.</p>					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.</td><td>Partial</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Partial
Assertion & Expected Result	Actual Result					
MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Partial					
Analysis:	Partial results achieved					

72

73

74

75

76

77 **1.2.24 MDT-06 – iPad GSM**

<b>Test Case MDT-06 Lantern v4.5.6</b>											
Case Summary:	MDT-06 Acquire mobile device internal memory by selecting a combination of supported data elements.										
Assertions:	MDT-CA-06 If a mobile device forensic tool provides the user with an Acquire All device data objects acquisition option then the tool shall complete the acquisition of all data objects without error. MDT-CA-07 If a mobile device forensic tool provides the user with an Select All individual device data objects then the tool shall complete the acquisition of all individually selected data objects without error. MDT-CA-08 If a mobile device forensic tool provides the user with the ability to Select Individual device data objects for acquisition then the tool shall acquire each exclusive data object without error. MDT-CA-09 If a mobile device forensic tool completes two consecutive logical acquisitions of the target device without error then the payload (data objects) on the mobile device shall remain consistent.										
Tester Name:	rpa										
Test Host:	p644381										
Test Date:	Thu Apr 2 06:52:12 EDT 2015										
Device:	iPad GSM										
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable										
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 06:52:12 EDT 2015 Acquisition finished: Thu Apr 2 07:09:04 EDT 2015  Acquire All acquisition was successful										
Results:	<table border="1"> <thead> <tr> <th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-CA-06 Acquire-all mobile device data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-CA-07 Select-all mobile device data objects acquisition.</td><td>NA</td></tr> <tr> <td>MDT-CA-08 Select-individual mobile device data objects acquisition.</td><td>NA</td></tr> <tr> <td>MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected	MDT-CA-07 Select-all mobile device data objects acquisition.	NA	MDT-CA-08 Select-individual mobile device data objects acquisition.	NA	MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected
Assertion & Expected Result	Actual Result										
MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected										
MDT-CA-07 Select-all mobile device data objects acquisition.	NA										
MDT-CA-08 Select-individual mobile device data objects acquisition.	NA										
MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected										
Analysis:	Expected results achieved										

78

79 **1.2.25 MDT-12 – iPad GSM**

<b>Test Case MDT-12 Lantern v4.5.6</b>	
Case Summary:	MDT-12 After a successful mobile device internal memory, alter the case file via third-party means and attempt to re-open the case.
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.
Tester Name:	rpa
Test Host:	p644381
Test Date:	Thu Apr 2 07:14:51 EDT 2015
Device:	iPad GSM
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 07:14:51 EDT 2015 Acquisition finished: Thu Apr 2 07:53:25 EDT 2015  Notification of modified device memory data was not successful  <b>Notes:</b>

Test Case MDT-12 Lantern v4.5.6		
	Lantern.db was modified, the case file was re-opened without informing the user that the case data was altered. The modifications made within Lantern.db were displayed within the modified case file.	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-AO-08 Notification of modified device case data.	Not as expected
Analysis:	Expected results Not achieved	

80

## 81 1.2.26 MDT-19 – iPad GSM

Test Case MDT-19 Lantern v4.5.6						
Case Summary:	MDT-19 Acquire mobile device internal memory and review data containing non-ASCII characters.					
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Thu Apr 2 08:10:55 EDT 2015					
Device:	iPad GSM					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 08:10:55 EDT 2015 Acquisition finished: Thu Apr 2 08:13:44 EDT 2015  Non-ASCII Address book entries were acquired and properly displayed Non-ASCII text messages were acquired and properly displayed					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected					
Analysis:	Expected results achieved					

82

## 83 1.2.27 MDT-22 – iPad GSM

Test Case MDT-22 Lantern v4.5.6		
Case Summary:	MDT-22 Acquire mobile device internal memory and review hash values for vendor supported data objects.	
Assertions:	MDT-AO-15 If the mobile device forensic tool supports hashing for individual data objects then the tool shall present the user with a hash value for each supported data object.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Thu Apr 2 08:17:24 EDT 2015	
Device:	iPad GSM	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 08:17:24 EDT 2015 Acquisition finished: Thu Apr 2 08:25:13 EDT 2015</p> <p>Hash values were properly reported for individually acquired device data elements</p>	

Test Case MDT-22 Lantern v4.5.6		
Results:	<b>Assertion &amp; Expected Result</b>	
	<b>Actual Result</b>	
	MDT-AO-15 Hash values for individual data and case presented in a useable format.	as expected
Analysis:	Expected results achieved	

84

## 85 1.2.28 MDT-24 – iPad GSM

Test Case MDT-24 Lantern v4.5.6		
Case Summary:	MDT-24 Acquire mobile device internal memory and review data containing GPS longitude and latitude coordinates	
Assertions:	MDT-AO-16 If the mobile device forensic tool supports acquisition of GPS data then the tool shall present the user with the longitude and latitude coordinates for all GPS-related data in a useable format.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Thu Apr 2 08:28:16 EDT 2015	
Device:	iPad GSM	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 08:28:16 EDT 2015 Acquisition finished: Thu Apr 2 09:29:47 EDT 2015</p> <p>GPS Coordinate data was not successfully acquired</p> <p><b>Notes:</b> The KMZ file was not reported. Partial location information can be located in: /private/var/mobile/library/maps/Direction.mapsdata</p>	
Results:	<b>Assertion &amp; Expected Result</b>	
	<b>Actual Result</b>	
	MDT-AO-16 Acquisition of GPS related data presented in a useable format.	Not as expected
Analysis:	Expected results Not achieved	

86

## 87 1.2.29 MDT-01 – iPad CDMA

Test Case MDT-01 Lantern v4.5.6		
Case Summary:	MDT-01 Acquire mobile device internal memory over tool-supported interfaces (e.g., cable, Bluetooth, IrDA).	
Assertions:	MDT-CA-01 If a mobile device forensic tool provides support for connectivity of the target device then the tool shall successfully recognize the target device via all vendor supported interfaces (e.g., cable, Bluetooth, IrDA).	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Thu Apr 2 06:17:24 EDT 2015	
Device:	iPad CDMA	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 06:17:24 EDT 2015 Acquisition finished: Thu Apr 2 06:27:06 EDT 2015</p>	

Test Case MDT-01 Lantern v4.5.6		
	Device connectivity was established via supported interface	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-CA-01 Device connectivity via supported interfaces.	as expected
Analysis:	Expected results achieved	

88

### 89 1.2.30 MDT-02 – iPad CDMA

Test Case MDT-02 Lantern v4.5.6						
Case Summary:	MDT-02 Begin mobile device internal memory acquisition and interrupt connectivity by interface disengagement.					
Assertions:	MDT-CA-02 If connectivity between the mobile device and mobile device forensic tool is disrupted then the tool shall notify the user that connectivity has been disrupted.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Thu Apr 2 06:17:41 EDT 2015					
Device:	iPad CDMA					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 06:17:41 EDT 2015 Acquisition finished: Thu Apr 2 06:27:14 EDT 2015  Device acquisition disruption notification was successful					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-02 Notification of device acquisition disruption.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-02 Notification of device acquisition disruption.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-02 Notification of device acquisition disruption.	as expected					
Analysis:	Expected results achieved					

90

### 91 1.2.31 MDT-03 – iPad CDMA

Test Case MDT-03 Lantern v4.5.6						
Case Summary:	MDT-03 Acquire mobile device internal memory and review reported data via the preview-pane or generated reports for readability.					
Assertions:	MDT-CA-03 If a mobile device forensic tool completes acquisition of the target device without error then the tool shall have the ability to present acquired data objects in a useable format via either a preview-pane or generated report.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Thu Apr 2 06:32:55 EDT 2015					
Device:	iPad CDMA					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 06:32:55 EDT 2015 Acquisition finished: Thu Apr 2 06:46:12 EDT 2015  Readability and completeness of acquired data was successful					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td></td><td></td></tr></table>		Assertion & Expected Result	Actual Result		
Assertion & Expected Result	Actual Result					

Test Case MDT-03 Lantern v4.5.6		
	MDT-CA-03 Readability and completeness of acquired data via supported reports.	as expected
Analysis:	Expected results achieved	

92

### 93 1.2.32 MDT-04 – iPad CDMA

Test Case MDT-04 Lantern v4.5.6						
Case Summary:	MDT-04 Acquire mobile device internal memory and review reported subscriber and equipment related information (e.g., IMSI, IMEI, MEID/ESN, MSISDN).					
Assertions:	MDT-CA-04 If a mobile device forensic tool completes acquisition of the target device without error then subscriber and equipment related information shall be presented in a useable format.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Thu Apr 2 06:33:20 EDT 2015					
Device:	iPad_CDMA					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 06:33:20 EDT 2015 Acquisition finished: Thu Apr 2 06:46:20 EDT 2015  IMEI, MEID/ESN were acquired					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	as expected
	Assertion & Expected Result	Actual Result				
MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	as expected					
Analysis:	Expected results achieved					

94

### 95 1.2.33 MDT-05 – iPad CDMA

Test Case MDT-05 Lantern v4.5.6	
Case Summary:	MDT-05 Acquire mobile device internal memory and review supported data elements (i.e., PIM data, call logs, SMS, MMS, stand-alone files: audio, pictures, video, application related data: documents, spreadsheets, presentations, social-media data and Internet related data: bookmarks, visited sites).
Assertions:	MDT-CA-05 If a mobile device forensic tool completes acquisition of the target device without error then all supported data elements shall be presented in a useable format.
Tester Name:	rpa
Test Host:	p644381
Test Date:	Thu Apr 2 09:39:25 EDT 2015
Device:	iPad_CDMA
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 09:39:25 EDT 2015 Acquisition finished: Thu Apr 2 11:32:11 EDT 2015  Regular Length Address Book entries were acquired Maximum Length Address Book entries were not acquired Special Character Address Book entries were acquired Blank Name Address Book entries were acquired Email addresses within Address Book entries were acquired

Test Case MDT-05 Lantern v4.5.6						
	<p>Embedded graphics within Address Book entries were acquired ALL PIM related data was acquired All Call Logs (incoming, outgoing, missed) were acquired All Call Log date/time stamps data were correctly reported ALL text messages (SMS, EMS) were acquired Correct date/time stamps were reported for all text messages Correct status flags were reported for all text messages Sender and Recipient phone numbers associated with text messages were correctly reported ALL MMS messages (Audio, Image, Video) were acquired ALL stand-alone data files (Audio, Image, Video) were acquired All application data was acquired All Internet related data was acquired Partial Social media related data was acquired</p> <p><b>Notes:</b> Only first and last name were reported for contacts. Attachments were not included in email data. LinkedIn, Facebook, Twitter not reported in Lantern sidebar. Social media related data was partially reported.</p>					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.</td><td>Partial</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Partial
Assertion & Expected Result	Actual Result					
MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Partial					
Analysis:	Partial results achieved					

96

## 97 1.2.34 MDT-06 – iPad CDMA

Test Case MDT-06 Lantern v4.5.6								
Case Summary:	MDT-06 Acquire mobile device internal memory by selecting a combination of supported data elements.							
Assertions:	MDT-CA-06 If a mobile device forensic tool provides the user with an Acquire All device data objects acquisition option then the tool shall complete the acquisition of all data objects without error. MDT-CA-07 If a mobile device forensic tool provides the user with an Select All individual device data objects then the tool shall complete the acquisition of all individually selected data objects without error. MDT-CA-08 If a mobile device forensic tool provides the user with the ability to Select Individual device data objects for acquisition then the tool shall acquire each exclusive data object without error. MDT-CA-09 If a mobile device forensic tool completes two consecutive logical acquisitions of the target device without error then the payload (data objects) on the mobile device shall remain consistent.							
Tester Name:	rpa							
Test Host:	p644381							
Test Date:	Thu Apr 2 06:52:32 EDT 2015							
Device:	iPad_CDMA							
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable							
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 06:52:32 EDT 2015 Acquisition finished: Thu Apr 2 07:09:14 EDT 2015  Acquire All acquisition was successful							
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-06 Acquire-all mobile device data objects acquisition.</td><td>as expected</td></tr><tr><td>MDT-CA-07 Select-all mobile device data objects acquisition.</td><td>NA</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected	MDT-CA-07 Select-all mobile device data objects acquisition.	NA
Assertion & Expected Result	Actual Result							
MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected							
MDT-CA-07 Select-all mobile device data objects acquisition.	NA							

Test Case MDT-06 Lantern v4.5.6		
	MDT-CA-08 Select-individual mobile device data objects acquisition.	NA
	MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected
Analysis:	Expected results achieved	

98

### 99 1.2.35 MDT-12 – iPad CDMA

Test Case MDT-12 Lantern v4.5.6						
Case Summary:	MDT-12 After a successful mobile device internal memory, alter the case file via third-party means and attempt to re-open the case.					
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Thu Apr 2 07:15:10 EDT 2015					
Device:	iPad CDMA					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 07:15:10 EDT 2015 Acquisition finished: Thu Apr 2 07:54:15 EDT 2015</p> <p>Notification of modified device memory data was not successful</p> <p><b>Notes:</b> Lantern.db was modified, the case file was re-opened without informing the user that the case data was altered. The modifications made within Lantern.db were displayed within the modified case file.</p>					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-08 Notification of modified device case data.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-08 Notification of modified device case data.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-AO-08 Notification of modified device case data.	Not as expected					
Analysis:	Expected results Not achieved					

100

### 101 1.2.36 MDT-19 – iPad CDMA

Test Case MDT-19 Lantern v4.5.6	
Case Summary:	MDT-19 Acquire mobile device internal memory and review data containing non-ASCII characters.
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.
Tester Name:	rpa
Test Host:	p644381
Test Date:	Thu Apr 2 08:11:22 EDT 2015
Device:	iPad CDMA
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 08:11:22 EDT 2015 Acquisition finished: Thu Apr 2 08:14:21 EDT 2015</p> <p>Non-ASCII Address book entries were acquired and properly displayed Non-ASCII text messages were acquired and properly displayed</p>
Results:	

Test Case MDT-19 Lantern v4.5.6		
	Assertion & Expected Result	Actual Result
	MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected
Analysis:	Expected results achieved	

102

### 103 1.2.37 MDT-22 – iPad CDMA

Test Case MDT-22 Lantern v4.5.6		
Case Summary:	MDT-22 Acquire mobile device internal memory and review hash values for vendor supported data objects.	
Assertions:	MDT-AO-15 If the mobile device forensic tool supports hashing for individual data objects then the tool shall present the user with a hash value for each supported data object.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Thu Apr 2 08:17:48 EDT 2015	
Device:	iPad CDMA	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 08:17:48 EDT 2015 Acquisition finished: Thu Apr 2 08:25:46 EDT 2015  Hash values were properly reported for individually acquired device data elements	
Results:	Assertion & Expected Result	
	MDT-AO-15 Hash values for individual data and case presented in a useable format.	as expected
Analysis:	Expected results achieved	

104

### 105 1.2.38 MDT-24 – iPad CDMA

Test Case MDT-24 Lantern v4.5.6		
Case Summary:	MDT-24 Acquire mobile device internal memory and review data containing GPS longitude and latitude coordinates	
Assertions:	MDT-AO-16 If the mobile device forensic tool supports acquisition of GPS data then the tool shall present the user with the longitude and latitude coordinates for all GPS-related data in a useable format.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Thu Apr 2 08:28:44 EDT 2015	
Device:	iPadMini GSM	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 08:28:44 EDT 2015 Acquisition finished: Thu Apr 2 09:30:01 EDT 2015  GPS Coordinate data was not successfully acquired  <b>Notes:</b> The KMZ file was not reported. Partial location information can be located in: /private/var/mobile/library/maps/Direction.mapsdata	

Test Case MDT-24 Lantern v4.5.6		
Results:		
	<b>Assertion &amp; Expected Result</b>	<b>Actual Result</b>
	MDT-AO-16 Acquisition of GPS related data presented in a useable format.	Not as expected
Analysis: Expected results Not achieved		

### 1.2.39 MDT-01 – iPadMini GSM

Test Case MDT-01 Lantern v4.5.6		
Case Summary:	MDT-01 Acquire mobile device internal memory over tool-supported interfaces (e.g., cable, Bluetooth, IrDA).	
Assertions:	MDT-CA-01 If a mobile device forensic tool provides support for connectivity of the target device then the tool shall successfully recognize the target device via all vendor supported interfaces (e.g., cable, Bluetooth, IrDA).	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Thu Apr 2 06:18:03 EDT 2015	
Device:	iPadMini_GSM	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 06:18:03 EDT 2015 Acquisition finished: Thu Apr 2 06:28:02 EDT 2015  Device connectivity was established via supported interface	
Results:	<b>Assertion &amp; Expected Result</b>	<b>Actual Result</b>
	MDT-CA-01 Device connectivity via supported interfaces.	as expected
Analysis: Expected results achieved		

### 1.2.40 MDT-02 – iPadMini GSM

Test Case MDT-02 Lantern v4.5.6		
Case Summary:	MDT-02 Begin mobile device internal memory acquisition and interrupt connectivity by interface disengagement.	
Assertions:	MDT-CA-02 If connectivity between the mobile device and mobile device forensic tool is disrupted then the tool shall notify the user that connectivity has been disrupted.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Thu Apr 2 06:18:35 EDT 2015	
Device:	iPadMini_GSM	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 06:18:35 EDT 2015 Acquisition finished: Thu Apr 2 06:28:25 EDT 2015  Device acquisition disruption notification was successful	
Results:	<b>Assertion &amp; Expected Result</b>	<b>Actual Result</b>
	MDT-CA-02 Notification of device acquisition disruption.	as expected

<b>Test Case MDT-02 Lantern v4.5.6</b>	
Analysis:	Expected results achieved

111

## 112 1.2.41 MDT-03 – iPadMini GSM

<b>Test Case MDT-03 Lantern v4.5.6</b>					
Case Summary:	MDT-03 Acquire mobile device internal memory and review reported data via the preview-pane or generated reports for readability.				
Assertions:	MDT-CA-03 If a mobile device forensic tool completes acquisition of the target device without error then the tool shall have the ability to present acquired data objects in a useable format via either a preview-pane or generated report.				
Tester Name:	rpa				
Test Host:	p644381				
Test Date:	Thu Apr 2 06:33:41 EDT 2015				
Device:	iPadMini GSM				
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable				
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 06:33:41 EDT 2015 Acquisition finished: Thu Apr 2 06:47:57 EDT 2015  Readability and completeness of acquired data was successful				
Results:	<table border="1"> <thead> <tr> <th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-CA-03 Readability and completeness of acquired data via supported reports.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-CA-03 Readability and completeness of acquired data via supported reports.	as expected
Assertion & Expected Result	Actual Result				
MDT-CA-03 Readability and completeness of acquired data via supported reports.	as expected				
Analysis:	Expected results achieved				

113

## 114 1.2.42 MDT-04 – iPadMini GSM

<b>Test Case MDT-04 Lantern v4.5.6</b>					
Case Summary:	MDT-04 Acquire mobile device internal memory and review reported subscriber and equipment related information (e.g., IMSI, IMEI, MEID/ESN, MSISDN).				
Assertions:	MDT-CA-04 If a mobile device forensic tool completes acquisition of the target device without error then subscriber and equipment related information shall be presented in a useable format.				
Tester Name:	rpa				
Test Host:	p644381				
Test Date:	Thu Apr 2 06:33:58 EDT 2015				
Device:	iPadMini GSM				
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable				
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 06:33:58 EDT 2015 Acquisition finished: Thu Apr 2 06:48:08 EDT 2015  Subscriber and Equipment related data (i.e., MSISDN, IMEI) were acquired				
Results:	<table border="1"> <thead> <tr> <th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	as expected
Assertion & Expected Result	Actual Result				
MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	as expected				

<b>Test Case MDT-04 Lantern v4.5.6</b>	
Analysis:	Expected results achieved

115

## 116 1.2.43 MDT-05 – iPadMini GSM

Test Case MDT-05 Lantern v4.5.6						
Case Summary:	MDT-05 Acquire mobile device internal memory and review supported data elements (i.e., PIM data, call logs, SMS, MMS, stand-alone files: audio, pictures, video, application related data: documents, spreadsheets, presentations, social-media data and Internet related data: bookmarks, visited sites).					
Assertions:	MDT-CA-05 If a mobile device forensic tool completes acquisition of the target device without error then all supported data elements shall be presented in a useable format.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Thu Apr 2 09:39:50 EDT 2015					
Device:	iPadMini_GSM					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 09:39:50 EDT 2015 Acquisition finished: Thu Apr 2 11:32:20 EDT 2015</p> <p>Regular Length Address Book entries were acquired Maximum Length Address Book entries were not acquired Special Character Address Book entries were acquired Blank Name Address Book entries were acquired Email addresses within Address Book entries were acquired Embedded graphics within Address Book entries were acquired ALL PIM related data was acquired All Call Logs (incoming, outgoing, missed) were acquired All Call Log date/time stamps data were correctly reported ALL text messages (SMS, EMS) were acquired Correct date/time stamps were reported for all text messages Correct status flags were reported for all text messages Sender and Recipient phone numbers associated with text messages were correctly reported ALL MMS messages (Audio, Image, Video) were acquired ALL stand-alone data files (Audio, Image, Video) were acquired All application data was acquired All Internet related data was acquired Partial Social media related data was acquired</p> <p><b>Notes:</b> Only first and last names were reported for contacts. Attachments were not included in email data. Partial social media related data was recovered for facebook, Linkedin, and Twitter. LinkedIn and Twitter were not reported in Lantern sidebar.</p>					
Results:	<table><tr><td>Assertion &amp; Expected Result</td><td>Actual Result</td></tr><tr><td>MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.</td><td>Partial</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Partial
Assertion & Expected Result	Actual Result					
MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Partial					
Analysis:	Partial results achieved					

117

118

119 **1.2.44 MDT-06 – iPadMini GSM**

<b>Test Case MDT-06 Lantern v4.5.6</b>											
Case Summary:	MDT-06 Acquire mobile device internal memory by selecting a combination of supported data elements.										
Assertions:	MDT-CA-06 If a mobile device forensic tool provides the user with an Acquire All device data objects acquisition option then the tool shall complete the acquisition of all data objects without error. MDT-CA-07 If a mobile device forensic tool provides the user with an Select All individual device data objects then the tool shall complete the acquisition of all individually selected data objects without error. MDT-CA-08 If a mobile device forensic tool provides the user with the ability to Select Individual device data objects for acquisition then the tool shall acquire each exclusive data object without error. MDT-CA-09 If a mobile device forensic tool completes two consecutive logical acquisitions of the target device without error then the payload (data objects) on the mobile device shall remain consistent.										
Tester Name:	rpa										
Test Host:	p644381										
Test Date:	Thu Apr 2 06:52:54 EDT 2015										
Device:	iPadMini GSM										
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable										
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 06:52:54 EDT 2015 Acquisition finished: Thu Apr 2 07:09:23 EDT 2015  Acquire All acquisition was successful										
Results:	<table border="1"> <thead> <tr> <th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-CA-06 Acquire-all mobile device data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-CA-07 Select-all mobile device data objects acquisition.</td><td>NA</td></tr> <tr> <td>MDT-CA-08 Select-individual mobile device data objects acquisition.</td><td>NA</td></tr> <tr> <td>MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected	MDT-CA-07 Select-all mobile device data objects acquisition.	NA	MDT-CA-08 Select-individual mobile device data objects acquisition.	NA	MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected
Assertion & Expected Result	Actual Result										
MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected										
MDT-CA-07 Select-all mobile device data objects acquisition.	NA										
MDT-CA-08 Select-individual mobile device data objects acquisition.	NA										
MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected										
Analysis:	Expected results achieved										

120

121 **1.2.45 MDT-12 – iPadMini GSM**

<b>Test Case MDT-12 Lantern v4.5.6</b>	
Case Summary:	MDT-12 After a successful mobile device internal memory, alter the case file via third-party means and attempt to re-open the case.
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.
Tester Name:	rpa
Test Host:	p644381
Test Date:	Thu Apr 2 07:15:36 EDT 2015
Device:	iPadMini GSM
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 07:15:36 EDT 2015 Acquisition finished: Thu Apr 2 07:54:58 EDT 2015  Notification of modified device memory data was not successful  <b>Notes:</b>

Test Case MDT-12 Lantern v4.5.6		
	Lantern.db was modified, the case file was re-opened without informing the user that the case data was altered. The modifications made within Lantern.db were displayed within the modified case file.	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-AO-08 Notification of modified device case data.	Not as expected
Analysis:	Expected results Not achieved	

122

## 123 1.2.46 MDT-19 – iPadMini GSM

Test Case MDT-19 Lantern v4.5.6						
Case Summary:	MDT-19 Acquire mobile device internal memory and review data containing non-ASCII characters.					
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Thu Apr 2 08:11:47 EDT 2015					
Device:	iPadMini GSM					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 08:11:47 EDT 2015 Acquisition finished: Thu Apr 2 08:14:55 EDT 2015  Non-ASCII Address book entries were acquired and properly displayed Non-ASCII text messages were acquired and properly displayed					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected					
Analysis:	Expected results achieved					

124

## 125 1.2.47 MDT-22 – iPadMini GSM

Test Case MDT-22 Lantern v4.5.6		
Case Summary:	MDT-22 Acquire mobile device internal memory and review hash values for vendor supported data objects.	
Assertions:	MDT-AO-15 If the mobile device forensic tool supports hashing for individual data objects then the tool shall present the user with a hash value for each supported data object.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Thu Apr 2 08:18:12 EDT 2015	
Device:	iPadMini GSM	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 08:18:12 EDT 2015 Acquisition finished: Thu Apr 2 08:26:05 EDT 2015</p> <p>Hash values were properly reported for individually acquired device data elements</p>	

Test Case MDT-22 Lantern v4.5.6		
Results:	<b>Assertion &amp; Expected Result</b>	
	<b>Actual Result</b>	
	MDT-AO-15 Hash values for individual data and case presented in a useable format.	as expected
Analysis:	Expected results achieved	

126

## 127 1.2.48 MDT-24 – iPadMini GSM

Test Case MDT-24 Lantern v4.5.6		
Case Summary:	MDT-24 Acquire mobile device internal memory and review data containing GPS longitude and latitude coordinates	
Assertions:	MDT-AO-16 If the mobile device forensic tool supports acquisition of GPS data then the tool shall present the user with the longitude and latitude coordinates for all GPS-related data in a useable format.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Thu Apr 2 08:29:29 EDT 2015	
Device:	iPadMini GSM	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 08:29:29 EDT 2015 Acquisition finished: Thu Apr 2 09:30:11 EDT 2015</p> <p>GPS Coordinate data was not successfully acquired</p> <p><b>Notes:</b> The KMZ file was not reported. Partial location information can be located in: /private/var/mobile/library/maps/Direction.mapsdata</p>	
Results:	<b>Assertion &amp; Expected Result</b>	
	<b>Actual Result</b>	
	MDT-AO-16 Acquisition of GPS related data presented in a useable format.	Not as expected
Analysis:	Expected results Not achieved	

128

## 129 1.2.49 MDT-01 – iPadMini CDMA

Test Case MDT-01 Lantern v4.5.6		
Case Summary:	MDT-01 Acquire mobile device internal memory over tool-supported interfaces (e.g., cable, Bluetooth, IrDA).	
Assertions:	MDT-CA-01 If a mobile device forensic tool provides support for connectivity of the target device then the tool shall successfully recognize the target device via all vendor supported interfaces (e.g., cable, Bluetooth, IrDA).	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Thu Apr 2 06:19:58 EDT 2015	
Device:	iPadMini CDMA	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 06:19:58 EDT 2015 Acquisition finished: Thu Apr 2 06:29:19 EDT 2015</p>	

Test Case MDT-01 Lantern v4.5.6		
	Device connectivity was established via supported interface	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-CA-01 Device connectivity via supported interfaces.	as expected
Analysis:	Expected results achieved	

130

## 131 1.2.50 MDT-02 – iPadMini CDMA

Test Case MDT-02 Lantern v4.5.6						
Case Summary:	MDT-02 Begin mobile device internal memory acquisition and interrupt connectivity by interface disengagement.					
Assertions:	MDT-CA-02 If connectivity between the mobile device and mobile device forensic tool is disrupted then the tool shall notify the user that connectivity has been disrupted.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Thu Apr 2 06:20:29 EDT 2015					
Device:	iPadMini_CDMA					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 06:20:29 EDT 2015 Acquisition finished: Thu Apr 2 06:29:26 EDT 2015  Device acquisition disruption notification was successful					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-02 Notification of device acquisition disruption.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-02 Notification of device acquisition disruption.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-02 Notification of device acquisition disruption.	as expected					
Analysis:	Expected results achieved					

132

## 133 1.2.51 MDT-03 – iPadMini CDMA

Test Case MDT-03 Lantern v4.5.6				
Case Summary:	MDT-03 Acquire mobile device internal memory and review reported data via the preview-pane or generated reports for readability.			
Assertions:	MDT-CA-03 If a mobile device forensic tool completes acquisition of the target device without error then the tool shall have the ability to present acquired data objects in a useable format via either a preview-pane or generated report.			
Tester Name:	rpa			
Test Host:	p644381			
Test Date:	Thu Apr 2 06:34:23 EDT 2015			
Device:	iPadMini CDMA			
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable			
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 06:34:23 EDT 2015 Acquisition finished: Thu Apr 2 06:48:20 EDT 2015  Readability and completeness of acquired data was successful			
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr></table>		Assertion & Expected Result	Actual Result
Assertion & Expected Result	Actual Result			

Test Case MDT-03 Lantern v4.5.6		
	MDT-CA-03 Readability and completeness of acquired data via supported reports.	as expected
Analysis:	Expected results achieved	

134

## 135 1.2.52 MDT-04 – iPadMini CDMA

Test Case MDT-04 Lantern v4.5.6						
Case Summary:	MDT-04 Acquire mobile device internal memory and review reported subscriber and equipment related information (e.g., IMSI, IMEI, MEID/ESN, MSISDN).					
Assertions:	MDT-CA-04 If a mobile device forensic tool completes acquisition of the target device without error then subscriber and equipment related information shall be presented in a useable format.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Thu Apr 2 06:34:45 EDT 2015					
Device:	iPadMini_CDMA					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 06:34:45 EDT 2015 Acquisition finished: Thu Apr 2 06:48:32 EDT 2015  IMEI, MEID/ESN were acquired					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	as expected					
Analysis:	Expected results achieved					

136

## 137 1.2.53 MDT-05 – iPadMini CDMA

Test Case MDT-05 Lantern v4.5.6		
Case Summary:	MDT-05 Acquire mobile device internal memory and review supported data elements (i.e., PIM data, call logs, SMS, MMS, stand-alone files: audio, pictures, video, application related data: documents, spreadsheets, presentations, social-media data and Internet related data: bookmarks, visited sites).	
Assertions:	MDT-CA-05 If a mobile device forensic tool completes acquisition of the target device without error then all supported data elements shall be presented in a useable format.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Thu Apr 2 09:41:52 EDT 2015	
Device:	iPadMini_CDMA	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 09:41:52 EDT 2015 Acquisition finished: Thu Apr 2 11:32:29 EDT 2015  Regular Length Address Book entries were acquired Maximum Length Address Book entries were not acquired Special Character Address Book entries were acquired Blank Name Address Book entries were acquired Email addresses within Address Book entries were acquired	

Test Case MDT-05 Lantern v4.5.6						
	<p>Embedded graphics within Address Book entries were acquired ALL PIM related data was acquired All Call Logs (incoming, outgoing, missed) were acquired All Call Log date/time stamps data were correctly reported ALL text messages (SMS, EMS) were acquired Correct date/time stamps were reported for all text messages Correct status flags were reported for all text messages Sender and Recipient phone numbers associated with text messages were correctly reported ALL MMS messages (Audio, Image, Video) were acquired ALL stand-alone data files (Audio, Image, Video) were acquired All application data was acquired All Internet related data was acquired Partial Social media related data was acquired</p> <p><b>Notes:</b> Only first and last name were reported for contacts. Attachments were not included in email data. LinkedIn and Twitter were not reported in Lantern sidebar. Partial social media related data was recovered for facebook. No social media related data was recovered for LinkedIn or Twitter. Gmail is not reported in the Lantern sidebar.</p>					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.</td><td>Partial</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Partial
Assertion & Expected Result	Actual Result					
MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Partial					
Analysis:	Partial results achieved					

138

## 139 1.2.54 MDT-06 – iPadMini CDMA

Test Case MDT-06 Lantern v4.5.6						
Case Summary:	MDT-06 Acquire mobile device internal memory by selecting a combination of supported data elements.					
Assertions:	MDT-CA-06 If a mobile device forensic tool provides the user with an Acquire All device data objects acquisition option then the tool shall complete the acquisition of all data objects without error. MDT-CA-07 If a mobile device forensic tool provides the user with an Select All individual device data objects then the tool shall complete the acquisition of all individually selected data objects without error. MDT-CA-08 If a mobile device forensic tool provides the user with the ability to Select Individual device data objects for acquisition then the tool shall acquire each exclusive data object without error. MDT-CA-09 If a mobile device forensic tool completes two consecutive logical acquisitions of the target device without error then the payload (data objects) on the mobile device shall remain consistent.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Thu Apr 2 06:53:21 EDT 2015					
Device:	iPadMini_CDMA					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 06:53:21 EDT 2015 Acquisition finished: Thu Apr 2 07:09:39 EDT 2015  Acquire All acquisition was successful					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-06 Acquire-all mobile device data objects acquisition.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected					

Test Case MDT-06 Lantern v4.5.6		
	MDT-CA-07 Select-all mobile device data objects acquisition.	NA
	MDT-CA-08 Select-individual mobile device data objects acquisition.	NA
	MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected
Analysis:	Expected results achieved	

140

## 141 1.2.55 MDT-12 – iPadMini CDMA

Test Case MDT-12 Lantern v4.5.6						
Case Summary:	MDT-12 After a successful mobile device internal memory, alter the case file via third-party means and attempt to re-open the case.					
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Thu Apr 2 07:16:02 EDT 2015					
Device:	iPadMini CDMA					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 07:16:02 EDT 2015 Acquisition finished: Thu Apr 2 07:55:44 EDT 2015</p> <p>Notification of modified device memory data was not successful</p> <p><b>Notes:</b> Lantern.db was modified, the case file was re-opened without informing the user that the case data was altered. The modifications made within Lantern.db were displayed within the modified case file.</p>					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-08 Notification of modified device case data.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-08 Notification of modified device case data.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-AO-08 Notification of modified device case data.	Not as expected					
Analysis:	Expected results Not achieved					

142

## 143 1.2.56 MDT-19 – iPadMini CDMA

Test Case MDT-19 Lantern v4.5.6		
Case Summary:	MDT-19 Acquire mobile device internal memory and review data containing non-ASCII characters.	
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Thu Apr 2 08:12:30 EDT 2015	
Device:	iPadMini CDMA	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 08:12:30 EDT 2015 Acquisition finished: Thu Apr 2 08:15:30 EDT 2015</p> <p>Non-ASCII Address book entries were acquired and properly displayed Non-ASCII text messages were acquired and properly displayed</p>	

Test Case MDT-19 Lantern v4.5.6		
Results:		
	Assertion & Expected Result	Actual Result
	MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected
Analysis:	Expected results achieved	

144

## 145 1.2.57 MDT-22 – iPadMini CDMA

Test Case MDT-22 Lantern v4.5.6						
Case Summary:	MDT-22 Acquire mobile device internal memory and review hash values for vendor supported data objects.					
Assertions:	MDT-AO-15 If the mobile device forensic tool supports hashing for individual data objects then the tool shall present the user with a hash value for each supported data object.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Thu Apr 2 08:18:37 EDT 2015					
Device:	iPadMini CDMA					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 08:18:37 EDT 2015 Acquisition finished: Thu Apr 2 08:26:35 EDT 2015  Hash values were properly reported for individually acquired device data elements					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-15 Hash values for individual data and case presented in a useable format.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-15 Hash values for individual data and case presented in a useable format.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-15 Hash values for individual data and case presented in a useable format.	as expected					
Analysis:	Expected results achieved					

146

## 147 1.2.58 MDT-24 – iPadMini CDMA

Test Case MDT-24 Lantern v4.5.6		
Case Summary:	MDT-24 Acquire mobile device internal memory and review data containing GPS longitude and latitude coordinates	
Assertions:	MDT-AO-16 If the mobile device forensic tool supports acquisition of GPS data then the tool shall present the user with the longitude and latitude coordinates for all GPS-related data in a useable format.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Thu Apr 2 08:29:56 EDT 2015	
Device:	iPadMini CDMA	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Thu Apr 2 08:29:56 EDT 2015 Acquisition finished: Thu Apr 2 09:30:25 EDT 2015</p> <p>GPS Coordinate data was not successfully acquired</p> <p><b>Notes:</b></p>	

Test Case MDT-24 Lantern v4.5.6		
	The KMZ file was not reported. Partial location information can be located in: /private/var/mobile/library/maps/Direction.mapsdata	
Results:		
	<b>Assertion &amp; Expected Result</b>	<b>Actual Result</b>
	MDT-AO-16 Acquisition of GPS related data presented in a useable format.	Not as expected
Analysis:	Expected results Not achieved	

148

## 149 1.2.59 MDT-01 – Galaxy S3

Test Case MDT-01 Lantern v4.5.6		
Case Summary:	MDT-01 Acquire mobile device internal memory over tool-supported interfaces (e.g., cable, Bluetooth, IrDA).	
Assertions:	MDT-CA-01 If a mobile device forensic tool provides support for connectivity of the target device then the tool shall successfully recognize the target device via all vendor supported interfaces (e.g., cable, Bluetooth, IrDA).	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Tue Apr 7 06:57:38 EDT 2015	
Device:	GalaxyS3	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 06:57:38 EDT 2015 Acquisition finished: Tue Apr 7 13:13:44 EDT 2015</p> <p>Device connectivity was established via supported interface</p> <p><b>Notes:</b> Info and Files were not reported after subsequent acquisitions.</p>	
Results:		
	<b>Assertion &amp; Expected Result</b>	<b>Actual Result</b>
	MDT-CA-01 Device connectivity via supported interfaces.	as expected
Analysis:	Expected results achieved	

150

## 151 1.2.60 MDT-02 – Galaxy S3

Test Case MDT-02 Lantern v4.5.6		
Case Summary:	MDT-02 Begin mobile device internal memory acquisition and interrupt connectivity by interface disengagement.	
Assertions:	MDT-CA-02 If connectivity between the mobile device and mobile device forensic tool is disrupted then the tool shall notify the user that connectivity has been disrupted.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Tue Apr 7 06:58:00 EDT 2015	
Device:	GalaxyS3	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 06:58:00 EDT 2015 Acquisition finished: Tue Apr 7 13:13:51 EDT 2015</p> <p>Device acquisition disruption notification was not successful</p>	

Test Case MDT-02 Lantern v4.5.6		
	<b>Notes:</b> When disrupting the acquisition process by removing the plug from the mobile device, an error message is not produced.	
Results:		
	<b>Assertion &amp; Expected Result</b>	<b>Actual Result</b>
	MDT-CA-02 Notification of device acquisition disruption.	Not as expected
Analysis:	Expected results Not achieved	

152

## 153 1.2.61 MDT-03 – Galaxy S3

Test Case MDT-03 Lantern v4.5.6						
Case Summary:	MDT-03 Acquire mobile device internal memory and review reported data via the preview-pane or generated reports for readability.					
Assertions:	MDT-CA-03 If a mobile device forensic tool completes acquisition of the target device without error then the tool shall have the ability to present acquired data objects in a useable format via either a preview-pane or generated report.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 06:58:22 EDT 2015					
Device:	GalaxyS3					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 06:58:22 EDT 2015 Acquisition finished: Tue Apr 7 13:13:56 EDT 2015  Readability and completeness of acquired data was successful					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-03 Readability and completeness of acquired data via supported reports.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-03 Readability and completeness of acquired data via supported reports.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-03 Readability and completeness of acquired data via supported reports.	as expected					
Analysis:	Expected results achieved					

154

## 155 1.2.62 MDT-04 – Galaxy S3

Test Case MDT-04 Lantern v4.5.6		
Case Summary:	MDT-04 Acquire mobile device internal memory and review reported subscriber and equipment related information (e.g., IMSI, IMEI, MEID/ESN, MSISDN).	
Assertions:	MDT-CA-04 If a mobile device forensic tool completes acquisition of the target device without error then subscriber and equipment related information shall be presented in a useable format.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Tue Apr 7 06:58:45 EDT 2015	
Device:	GalaxyS3	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 06:58:45 EDT 2015 Acquisition finished: Tue Apr 7 13:14:06 EDT 2015	

Test Case MDT-04 Lantern v4.5.6		
	MSISDN and IMEI were not acquired	
	<b>Notes:</b> The MSISDN, IMEI, or ICCID were not reported in "Info".	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected
Analysis:	Expected results Not achieved	

156

## 157 1.2.63 MDT-05 – Galaxy S3

Test Case MDT-05 Lantern v4.5.6						
Case Summary:	MDT-05 Acquire mobile device internal memory and review supported data elements (i.e., PIM data, call logs, SMS, MMS, stand-alone files: audio, pictures, video, application related data: documents, spreadsheets, presentations, social-media data and Internet related data: bookmarks, visited sites).					
Assertions:	MDT-CA-05 If a mobile device forensic tool completes acquisition of the target device without error then all supported data elements shall be presented in a useable format.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 06:59:05 EDT 2015					
Device:	GalaxyS3					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 06:59:05 EDT 2015 Acquisition finished: Tue Apr 7 13:14:13 EDT 2015</p> <p>Regular Length Address Book entries were acquired Maximum Length Address Book entries were acquired Special Character Address Book entries were acquired Blank Name Address Book entries were acquired Email addresses within Address Book entries were acquired Embedded graphics within Address Book entries were not acquired Basic PIM related data was not acquired Maximum length PIM related data was not acquired All Call Logs (incoming, outgoing, missed) were acquired All Call Log date/time stamps data were correctly reported ALL text messages (SMS, EMS) were acquired Correct date/time stamps were reported for all text messages Correct status flags were reported for all text messages Sender and Recipient phone numbers associated with text messages were correctly reported Audio MMS messages were not acquired Image MMS messages were not acquired Video MMS messages were not acquired ALL stand-alone data files (Audio, Image, Video) were acquired All application data was acquired All Internet related data was acquired Social media related data was not acquired</p>					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.</td><td>Partial</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Partial
Assertion & Expected Result	Actual Result					
MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Partial					

<b>Test Case MDT-05 Lantern v4.5.6</b>	
Analysis:	Partial results achieved

158

## 159 1.2.64 MDT-06 – Galaxy S3

<b>Test Case MDT-06 Lantern v4.5.6</b>											
Case Summary:	MDT-06 Acquire mobile device internal memory by selecting a combination of supported data elements.										
Assertions:	MDT-CA-06 If a mobile device forensic tool provides the user with an Acquire All device data objects acquisition option then the tool shall complete the acquisition of all data objects without error. MDT-CA-07 If a mobile device forensic tool provides the user with an Select All individual device data objects then the tool shall complete the acquisition of all individually selected data objects without error. MDT-CA-08 If a mobile device forensic tool provides the user with the ability to Select Individual device data objects for acquisition then the tool shall acquire each exclusive data object without error. MDT-CA-09 If a mobile device forensic tool completes two consecutive logical acquisitions of the target device without error then the payload (data objects) on the mobile device shall remain consistent.										
Tester Name:	rpa										
Test Host:	p644381										
Test Date:	Tue Apr 7 06:59:55 EDT 2015										
Device:	GalaxyS3										
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable										
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 06:59:55 EDT 2015 Acquisition finished: Tue Apr 7 13:14:19 EDT 2015  Acquire All acquisition was successful										
Results:	<table border="1"> <thead> <tr> <th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-CA-06 Acquire-all mobile device data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-CA-07 Select-all mobile device data objects acquisition.</td><td>NA</td></tr> <tr> <td>MDT-CA-08 Select-individual mobile device data objects acquisition.</td><td>NA</td></tr> <tr> <td>MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected	MDT-CA-07 Select-all mobile device data objects acquisition.	NA	MDT-CA-08 Select-individual mobile device data objects acquisition.	NA	MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected
Assertion & Expected Result	Actual Result										
MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected										
MDT-CA-07 Select-all mobile device data objects acquisition.	NA										
MDT-CA-08 Select-individual mobile device data objects acquisition.	NA										
MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected										
Analysis:	Expected results achieved										

160

## 161 1.2.65 MDT-12 – Galaxy S3

<b>Test Case MDT-12 Lantern v4.5.6</b>	
Case Summary:	MDT-12 After a successful mobile device internal memory, alter the case file via third-party means and attempt to re-open the case.
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.
Tester Name:	rpa
Test Host:	p644381
Test Date:	Tue Apr 7 07:00:24 EDT 2015
Device:	GalaxyS3
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:00:24 EDT 2015

Test Case MDT-12 Lantern v4.5.6						
	Acquisition finished: Tue Apr 7 13:14:27 EDT 2015					
	Notification of modified device memory data was not successful					
	<b>Notes:</b> Lantern.db was modified, the case file was re-opened without informing the user that the case data was altered. The modifications made within Lantern.db were displayed within the modified case file.					
Results:						
	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-08 Notification of modified device case data.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-08 Notification of modified device case data.	Not as expected
	Assertion & Expected Result	Actual Result				
MDT-AO-08 Notification of modified device case data.	Not as expected					
Analysis:	Expected results Not achieved					

162

## 163 1.2.66 MDT-19 – Galaxy S3

Test Case MDT-19 Lantern v4.5.6						
Case Summary:	MDT-19 Acquire mobile device internal memory and review data containing non-ASCII characters.					
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:00:46 EDT 2015					
Device:	GalaxyS3					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:00:46 EDT 2015 Acquisition finished: Tue Apr 7 13:14:34 EDT 2015  Non-ASCII Address book entries were acquired and properly displayed Non-ASCII text messages were acquired and properly displayed					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected					
Analysis:	Expected results achieved					

164

## 165 1.2.67 MDT-22 – Galaxy S3

Test Case MDT-22 Lantern v4.5.6		
Case Summary:	MDT-22 Acquire mobile device internal memory and review hash values for vendor supported data objects.	
Assertions:	MDT-AO-15 If the mobile device forensic tool supports hashing for individual data objects then the tool shall present the user with a hash value for each supported data object.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Tue Apr 7 07:01:15 EDT 2015	
Device:	GalaxyS3	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:01:15 EDT 2015	

Test Case MDT-22 Lantern v4.5.6		
	Acquisition finished: Tue Apr 7 13:14:40 EDT 2015  Hash values were properly reported for individually acquired device data elements	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-AO-15 Hash values for individual data and case presented in a useable format.	as expected
Analysis:	Expected results achieved	

166

## 167 1.2.68 MDT-24 – Galaxy S3

Test Case MDT-24 Lantern v4.5.6						
Case Summary:	MDT-24 Acquire mobile device internal memory and review data containing GPS longitude and latitude coordinates					
Assertions:	MDT-AO-16 If the mobile device forensic tool supports acquisition of GPS data then the tool shall present the user with the longitude and latitude coordinates for all GPS-related data in a useable format.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:02:05 EDT 2015					
Device:	GalaxyS3					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:02:05 EDT 2015 Acquisition finished: Tue Apr 7 13:14:45 EDT 2015  GPS Coordinate data was not successfully acquired					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-16 Acquisition of GPS related data presented in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-16 Acquisition of GPS related data presented in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-AO-16 Acquisition of GPS related data presented in a useable format.	Not as expected					
Analysis:	Expected results Not achieved					

168

## 169 1.2.69 MDT-01 – Galaxy S4

Test Case MDT-01 Lantern v4.5.6		
Case Summary:	MDT-01 Acquire mobile device internal memory over tool-supported interfaces (e.g., cable, Bluetooth, IrDA).	
Assertions:	MDT-CA-01 If a mobile device forensic tool provides support for connectivity of the target device then the tool shall successfully recognize the target device via all vendor supported interfaces (e.g., cable, Bluetooth, IrDA).	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Tue Apr 7 07:02:51 EDT 2015	
Device:	GalaxyS4	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:02:51 EDT 2015 Acquisition finished: Tue Apr 7 13:14:53 EDT 2015	

Test Case MDT-01 Lantern v4.5.6		
	Device connectivity was established via supported interface	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-CA-01 Device connectivity via supported interfaces.	as expected
Analysis:	Expected results achieved	

170

## 171 1.2.70 MDT-02 – Galaxy S4

Test Case MDT-02 Lantern v4.5.6						
Case Summary:	MDT-02 Begin mobile device internal memory acquisition and interrupt connectivity by interface disengagement.					
Assertions:	MDT-CA-02 If connectivity between the mobile device and mobile device forensic tool is disrupted then the tool shall notify the user that connectivity has been disrupted.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:03:15 EDT 2015					
Device:	GalaxyS4					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:03:15 EDT 2015 Acquisition finished: Tue Apr 7 13:14:58 EDT 2015  Device acquisition disruption notification was successful					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-02 Notification of device acquisition disruption.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-02 Notification of device acquisition disruption.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-02 Notification of device acquisition disruption.	as expected					
Analysis:	Expected results achieved					

172

## 173 1.2.71 MDT-03 – Galaxy S4

Test Case MDT-03 Lantern v4.5.6				
Case Summary:	MDT-03 Acquire mobile device internal memory and review reported data via the preview-pane or generated reports for readability.			
Assertions:	MDT-CA-03 If a mobile device forensic tool completes acquisition of the target device without error then the tool shall have the ability to present acquired data objects in a useable format via either a preview-pane or generated report.			
Tester Name:	rpa			
Test Host:	p644381			
Test Date:	Tue Apr 7 07:03:38 EDT 2015			
Device:	GalaxyS4			
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable			
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:03:38 EDT 2015 Acquisition finished: Tue Apr 7 13:15:05 EDT 2015  Readability and completeness of acquired data was successful			
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr></table>		Assertion & Expected Result	Actual Result
Assertion & Expected Result	Actual Result			

Test Case MDT-03 Lantern v4.5.6		
	MDT-CA-03 Readability and completeness of acquired data via supported reports.	as expected
Analysis:	Expected results achieved	

174

## 175 1.2.72 MDT-04 – Galaxy S4

Test Case MDT-04 Lantern v4.5.6						
Case Summary:	MDT-04 Acquire mobile device internal memory and review reported subscriber and equipment related information (e.g., IMSI, IMEI, MEID/ESN, MSISDN).					
Assertions:	MDT-CA-04 If a mobile device forensic tool completes acquisition of the target device without error then subscriber and equipment related information shall be presented in a useable format.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:04:02 EDT 2015					
Device:	GalaxyS4					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:04:02 EDT 2015 Acquisition finished: Tue Apr 7 13:15:11 EDT 2015  MSISDN and IMEI were not acquired  <b>Notes:</b> The MSISDN, IMEI, or ICCID were not reported in "Info".					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected					
Analysis:	Expected results Not achieved					

176

## 177 1.2.73 MDT-05 – Galaxy S4

Test Case MDT-05 Lantern v4.5.6		
Case Summary:	MDT-05 Acquire mobile device internal memory and review supported data elements (i.e., PIM data, call logs, SMS, MMS, stand-alone files: audio, pictures, video, application related data: documents, spreadsheets, presentations, social-media data and Internet related data: bookmarks, visited sites).	
Assertions:	MDT-CA-05 If a mobile device forensic tool completes acquisition of the target device without error then all supported data elements shall be presented in a useable format.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Tue Apr 7 07:04:22 EDT 2015	
Device:	GalaxyS4	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:04:22 EDT 2015 Acquisition finished: Tue Apr 7 13:15:20 EDT 2015</p> <p>Regular Length Address Book entries were not acquired Maximum Length Address Book entries were not acquired</p>	

Test Case MDT-05 Lantern v4.5.6		
	Special Character Address Book entries were not acquired Blank Name Address Book entries were not acquired Email addresses within Address Book entries were not acquired Embedded graphics within Address Book entries were not acquired Basic PIM related data was not acquired Maximum length PIM related data was not acquired Incoming Calls were not acquired Outgoing Calls were not acquired Missed Calls were not acquired Date/Time Stamps incorrectly reported for Incoming Calls Date/Time Stamps incorrectly reported for Outgoing Calls Date/Time Stamps incorrectly reported for Missed Calls Text messages were not acquired Incorrect status flags were reported for text messages Sender and Recipient phone numbers associated with text messages were incorrectly reported Audio MMS messages were not acquired Image MMS messages were not acquired Video MMS messages were not acquired Audio files were not acquired Image files were not acquired Video files were not acquired Application data was not acquired Internet related data was not acquired Social media related data was not acquired	
Results:	<b>Assertion &amp; Expected Result</b>	
	<b>Actual Result</b>	
	MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	
Analysis:	Expected results Not achieved	

178

## 179 1.2.74 MDT-06 – Galaxy S4

Test Case MDT-06 Lantern v4.5.6	
Case Summary:	MDT-06 Acquire mobile device internal memory by selecting a combination of supported data elements.
Assertions:	MDT-CA-06 If a mobile device forensic tool provides the user with an Acquire All device data objects acquisition option then the tool shall complete the acquisition of all data objects without error. MDT-CA-07 If a mobile device forensic tool provides the user with an Select All individual device data objects then the tool shall complete the acquisition of all individually selected data objects without error. MDT-CA-08 If a mobile device forensic tool provides the user with the ability to Select Individual device data objects for acquisition then the tool shall acquire each exclusive data object without error. MDT-CA-09 If a mobile device forensic tool completes two consecutive logical acquisitions of the target device without error then the payload (data objects) on the mobile device shall remain consistent.
Tester Name:	rpa
Test Host:	p644381
Test Date:	Tue Apr 7 07:04:43 EDT 2015
Device:	GalaxyS4
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:04:43 EDT 2015 Acquisition finished: Tue Apr 7 13:15:26 EDT 2015  Acquire All acquisition was successful
Results:	

Test Case MDT-06 Lantern v4.5.6		
	Assertion & Expected Result	Actual Result
	MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected
	MDT-CA-07 Select-all mobile device data objects acquisition.	NA
	MDT-CA-08 Select-individual mobile device data objects acquisition.	NA
	MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected
Analysis:	Expected results achieved	

180

## 181 1.2.75 MDT-12 – Galaxy S4

Test Case MDT-12 Lantern v4.5.6						
Case Summary:	MDT-12 After a successful mobile device internal memory, alter the case file via third-party means and attempt to re-open the case.					
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:05:05 EDT 2015					
Device:	GalaxyS4					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:05:05 EDT 2015 Acquisition finished: Tue Apr 7 13:15:31 EDT 2015</p> <p>Notification of modified device memory data was not successful</p> <p><b>Notes:</b> Lantern.db was modified, the case file was re-opened without informing the user that the case data was altered. The modifications made within Lantern.db were displayed within the modified case file.</p>					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-08 Notification of modified device case data.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-08 Notification of modified device case data.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-AO-08 Notification of modified device case data.	Not as expected					
Analysis:	Expected results Not achieved					

182

## 183 1.2.76 MDT-22 – Galaxy S4

Test Case MDT-22 Lantern v4.5.6		
Case Summary:	MDT-22 Acquire mobile device internal memory and review hash values for vendor supported data objects.	
Assertions:	MDT-AO-15 If the mobile device forensic tool supports hashing for individual data objects then the tool shall present the user with a hash value for each supported data object.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Tue Apr 7 07:06:02 EDT 2015	
Device:	GalaxyS4	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log	Created by Lantern v4.5.6	

Test Case MDT-22 Lantern v4.5.6		
Highlights:	Acquisition started: Tue Apr 7 07:06:02 EDT 2015 Acquisition finished: Tue Apr 7 13:15:41 EDT 2015	
	Hash values were properly reported for individually acquired device data elements	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-AO-15 Hash values for individual data and case presented in a useable format.	as expected
Analysis:	Expected results achieved	

184

## 185 1.2.77 MDT-24 – Galaxy S4

Test Case MDT-24 Lantern v4.5.6						
Case Summary:	MDT-24 Acquire mobile device internal memory and review data containing GPS longitude and latitude coordinates					
Assertions:	MDT-AO-16 If the mobile device forensic tool supports acquisition of GPS data then the tool shall present the user with the longitude and latitude coordinates for all GPS-related data in a useable format.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:06:29 EDT 2015					
Device:	GalaxyS4					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:06:29 EDT 2015 Acquisition finished: Tue Apr 7 13:15:48 EDT 2015  GPS Coordinate data was not successfully acquired					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-16 Acquisition of GPS related data presented in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-16 Acquisition of GPS related data presented in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-AO-16 Acquisition of GPS related data presented in a useable format.	Not as expected					
Analysis:	Expected results Not achieved					

186

## 187 1.2.78 MDT-01 – Galaxy S5

Test Case MDT-01 Lantern v4.5.6		
Case Summary:	MDT-01 Acquire mobile device internal memory over tool-supported interfaces (e.g., cable, Bluetooth, IrDA).	
Assertions:	MDT-CA-01 If a mobile device forensic tool provides support for connectivity of the target device then the tool shall successfully recognize the target device via all vendor supported interfaces (e.g., cable, Bluetooth, IrDA).	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Tue Apr 7 07:07:00 EDT 2015	
Device:	GalaxyS5	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:07:00 EDT 2015 Acquisition finished: Tue Apr 7 13:15:55 EDT 2015	

Test Case MDT-01 Lantern v4.5.6		
	Device connectivity was established via supported interface	
	<b>Notes:</b> Info and Files were not reported after subsequent acquisitions.	
Results:		
	<b>Assertion &amp; Expected Result</b>	<b>Actual Result</b>
	MDT-CA-01 Device connectivity via supported interfaces.	as expected
Analysis:	Expected results achieved	

188

## 189 1.2.79 MDT-02 – Galaxy S5

Test Case MDT-02 Lantern v4.5.6						
Case Summary:	MDT-02 Begin mobile device internal memory acquisition and interrupt connectivity by interface disengagement.					
Assertions:	MDT-CA-02 If connectivity between the mobile device and mobile device forensic tool is disrupted then the tool shall notify the user that connectivity has been disrupted.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:07:20 EDT 2015					
Device:	GalaxyS5					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:07:20 EDT 2015 Acquisition finished: Tue Apr 7 13:16:01 EDT 2015  Device acquisition disruption notification was successful					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-02 Notification of device acquisition disruption.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-02 Notification of device acquisition disruption.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-02 Notification of device acquisition disruption.	as expected					
Analysis:	Expected results achieved					

190

## 191 1.2.80 MDT-03 – Galaxy S5

Test Case MDT-03 Lantern v4.5.6		
Case Summary:	MDT-03 Acquire mobile device internal memory and review reported data via the preview-pane or generated reports for readability.	
Assertions:	MDT-CA-03 If a mobile device forensic tool completes acquisition of the target device without error then the tool shall have the ability to present acquired data objects in a useable format via either a preview-pane or generated report.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Tue Apr 7 07:07:40 EDT 2015	
Device:	GalaxyS5	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:07:40 EDT 2015 Acquisition finished: Tue Apr 7 13:16:06 EDT 2015  Readability and completeness of acquired data was successful	

Test Case MDT-03 Lantern v4.5.6		
Results:	<b>Assertion &amp; Expected Result</b>	
	<b>Actual Result</b>	
	MDT-CA-03 Readability and completeness of acquired data via supported reports.	as expected
Analysis:	Expected results achieved	

192

## 193 1.2.81 MDT-04 – Galaxy S5

Test Case MDT-04 Lantern v4.5.6		
Case Summary:	MDT-04 Acquire mobile device internal memory and review reported subscriber and equipment related information (e.g., IMSI, IMEI, MEID/ESN, MSISDN).	
Assertions:	MDT-CA-04 If a mobile device forensic tool completes acquisition of the target device without error then subscriber and equipment related information shall be presented in a useable format.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Tue Apr 7 07:08:04 EDT 2015	
Device:	GalaxyS5	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:08:04 EDT 2015 Acquisition finished: Tue Apr 7 13:16:10 EDT 2015</p> <p>IMEI, MEID/ESN were not acquired</p> <p><b>Notes:</b> The MSISDN, IMEI, or ICCID were not reported in "Info".</p>	
Results:	<b>Assertion &amp; Expected Result</b>	
	<b>Actual Result</b>	
	MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected
Analysis:	Expected results Not achieved	

194

## 195 1.2.82 MDT-05 – Galaxy S5

Test Case MDT-05 Lantern v4.5.6		
Case Summary:	MDT-05 Acquire mobile device internal memory and review supported data elements (i.e., PIM data, call logs, SMS, MMS, stand-alone files: audio, pictures, video, application related data: documents, spreadsheets, presentations, social-media data and Internet related data: bookmarks, visited sites).	
Assertions:	MDT-CA-05 If a mobile device forensic tool completes acquisition of the target device without error then all supported data elements shall be presented in a useable format.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Tue Apr 7 07:08:54 EDT 2015	
Device:	GalaxyS5	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:08:54 EDT 2015 Acquisition finished: Tue Apr 7 13:16:15 EDT 2015</p>	

Test Case MDT-05 Lantern v4.5.6		
	Regular Length Address Book entries were acquired Maximum Length Address Book entries were acquired Special Character Address Book entries were acquired Blank Name Address Book entries were acquired Email addresses within Address Book entries were acquired Embedded graphics within Address Book entries were not acquired Basic PIM related data was not acquired Maximum length PIM related data was not acquired All Call Logs (incoming, outgoing, missed) were acquired All Call Log date/time stamps data were correctly reported ALL text messages (SMS, EMS) were acquired Correct date/time stamps were reported for all text messages Correct status flags were reported for all text messages Sender and Recipient phone numbers associated with text messages were correctly reported Audio MMS messages were not acquired Image MMS messages were not acquired Video MMS messages were not acquired Audio files were not acquired Image files were acquired Video files were acquired All application data was acquired All Internet related data was acquired Social media related data was not acquired	
Results:	<b>Assertion &amp; Expected Result</b>	
	MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	<b>Actual Result</b> Partial
Analysis:	Expected results Not achieved	

196

## 197 1.2.83 MDT-06 – Galaxy S5

Test Case MDT-06 Lantern v4.5.6	
Case Summary:	MDT-06 Acquire mobile device internal memory by selecting a combination of supported data elements.
Assertions:	MDT-CA-06 If a mobile device forensic tool provides the user with an Acquire All device data objects acquisition option then the tool shall complete the acquisition of all data objects without error. MDT-CA-07 If a mobile device forensic tool provides the user with an Select All individual device data objects then the tool shall complete the acquisition of all individually selected data objects without error. MDT-CA-08 If a mobile device forensic tool provides the user with the ability to Select Individual device data objects for acquisition then the tool shall acquire each exclusive data object without error. MDT-CA-09 If a mobile device forensic tool completes two consecutive logical acquisitions of the target device without error then the payload (data objects) on the mobile device shall remain consistent.
Tester Name:	rpa
Test Host:	p644381
Test Date:	Tue Apr 7 07:09:13 EDT 2015
Device:	GalaxyS5
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:09:13 EDT 2015 Acquisition finished: Tue Apr 7 13:16:19 EDT 2015  Acquire All acquisition was successful
Results:	

Test Case MDT-06 Lantern v4.5.6		
	Assertion & Expected Result	Actual Result
	MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected
	MDT-CA-07 Select-all mobile device data objects acquisition.	NA
	MDT-CA-08 Select-individual mobile device data objects acquisition.	NA
	MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected
Analysis:	Expected results achieved	

198

## 199 1.2.84 MDT-12 – Galaxy S5

Test Case MDT-12 Lantern v4.5.6						
Case Summary:	MDT-12 After a successful mobile device internal memory, alter the case file via third-party means and attempt to re-open the case.					
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:09:31 EDT 2015					
Device:	GalaxyS5					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:09:31 EDT 2015 Acquisition finished: Tue Apr 7 13:16:25 EDT 2015</p> <p>Notification of modified device memory data was not successful</p> <p><b>Notes:</b> Lantern.db was modified, the case file was re-opened without informing the user that the case data was altered. The modifications made within Lantern.db were displayed within the modified case file.</p>					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-08 Notification of modified device case data.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-08 Notification of modified device case data.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-AO-08 Notification of modified device case data.	Not as expected					
Analysis:	Expected results Not achieved					

200

201

202 **1.2.85 MDT-19 – Galaxy S5**

Test Case MDT-19 Lantern v4.5.6						
Case Summary:	MDT-19 Acquire mobile device internal memory and review data containing non-ASCII characters.					
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:10:05 EDT 2015					
Device:	GalaxyS5					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:10:05 EDT 2015 Acquisition finished: Tue Apr 7 13:16:32 EDT 2015  Non-ASCII Address book entries were acquired and properly displayed Non-ASCII text messages were acquired and properly displayed					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected
	Assertion & Expected Result	Actual Result				
MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected					
Analysis:	Expected results achieved					

203

204 **1.2.86 MDT-22 – Galaxy S5**

Test Case MDT-22 Lantern v4.5.6		
Case Summary:	MDT-22 Acquire mobile device internal memory and review hash values for vendor supported data objects.	
Assertions:	MDT-AO-15 If the mobile device forensic tool supports hashing for individual data objects then the tool shall present the user with a hash value for each supported data object.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Tue Apr 7 07:10:25 EDT 2015	
Device:	GalaxyS5	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:10:25 EDT 2015 Acquisition finished: Tue Apr 7 13:16:40 EDT 2015  Hash values were properly reported for individually acquired device data elements	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-AO-15 Hash values for individual data and case presented in a useable format.	as expected
Analysis:	Expected results achieved	

205

206

## 207 1.2.87 MDT-24 – Galaxy S5

Test Case MDT-24 Lantern v4.5.6						
Case Summary:	MDT-24 Acquire mobile device internal memory and review data containing GPS longitude and latitude coordinates					
Assertions:	MDT-AO-16 If the mobile device forensic tool supports acquisition of GPS data then the tool shall present the user with the longitude and latitude coordinates for all GPS-related data in a useable format.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:10:51 EDT 2015					
Device:	GalaxyS5					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:10:51 EDT 2015 Acquisition finished: Tue Apr 7 13:16:45 EDT 2015  GPS Coordinate data was not successfully acquired					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-16 Acquisition of GPS related data presented in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-16 Acquisition of GPS related data presented in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-AO-16 Acquisition of GPS related data presented in a useable format.	Not as expected					
Analysis:	Expected results Not achieved					

208  
209

## 210 1.2.88 MDT-01 – Galaxy Note 3

Test Case MDT-01 Lantern v4.5.6						
Case Summary:	MDT-01 Acquire mobile device internal memory over tool-supported interfaces (e.g., cable, Bluetooth, IrDA).					
Assertions:	MDT-CA-01 If a mobile device forensic tool provides support for connectivity of the target device then the tool shall successfully recognize the target device via all vendor supported interfaces (e.g., cable, Bluetooth, IrDA).					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:27:36 EDT 2015					
Device:	GalaxyNote3					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:27:36 EDT 2015 Acquisition finished: Tue Apr 7 13:17:15 EDT 2015  Device connectivity was established via supported interface					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-01 Device connectivity via supported interfaces.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-01 Device connectivity via supported interfaces.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-01 Device connectivity via supported interfaces.	as expected					
Analysis:	Expected results achieved					

211  
212

213 **1.2.89 MDT-02 – Galaxy Note 3**

Test Case MDT-02 Lantern v4.5.6						
Case Summary:	MDT-02 Begin mobile device internal memory acquisition and interrupt connectivity by interface disengagement.					
Assertions:	MDT-CA-02 If connectivity between the mobile device and mobile device forensic tool is disrupted then the tool shall notify the user that connectivity has been disrupted.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:27:59 EDT 2015					
Device:	GalaxyNote3					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:27:59 EDT 2015 Acquisition finished: Tue Apr 7 13:17:22 EDT 2015</p> <p>Device acquisition disruption notification was not successful</p> <p><b>Notes:</b> When disrupting the acquisition process by removing the plug from the mobile device, an error message is not produced.</p>					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-02 Notification of device acquisition disruption.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-02 Notification of device acquisition disruption.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-CA-02 Notification of device acquisition disruption.	Not as expected					
Analysis:	Expected results Not achieved					

214

215 **1.2.90 MDT-03 – Galaxy Note 3**

Test Case MDT-03 Lantern v4.5.6		
Case Summary:	MDT-03 Acquire mobile device internal memory and review reported data via the preview-pane or generated reports for readability.	
Assertions:	MDT-CA-03 If a mobile device forensic tool completes acquisition of the target device without error then the tool shall have the ability to present acquired data objects in a useable format via either a preview-pane or generated report.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Tue Apr 7 07:28:18 EDT 2015	
Device:	GalaxyNote3	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:28:18 EDT 2015 Acquisition finished: Tue Apr 7 13:17:26 EDT 2015  Readability and completeness of acquired data was successful	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-CA-03 Readability and completeness of acquired data via supported reports.	as expected
Analysis:	Expected results achieved	

216

217

218 **1.2.91 MDT-04 – Galaxy Note 3**

<b>Test Case MDT-04 Lantern v4.5.6</b>					
Case Summary:	MDT-04 Acquire mobile device internal memory and review reported subscriber and equipment related information (e.g., IMSI, IMEI, MEID/ESN, MSISDN).				
Assertions:	MDT-CA-04 If a mobile device forensic tool completes acquisition of the target device without error then subscriber and equipment related information shall be presented in a useable format.				
Tester Name:	rpa				
Test Host:	p644381				
Test Date:	Tue Apr 7 07:28:41 EDT 2015				
Device:	GalaxyNote3				
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable				
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:28:41 EDT 2015 Acquisition finished: Tue Apr 7 13:17:31 EDT 2015  IMEI, MEID/ESN were not acquired  <b>Notes:</b> The MSISDN, IMEI, or ICCID were not reported in "Info".				
Results:	<table border="1"> <thead> <tr> <th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.</td><td>Not as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected
Assertion & Expected Result	Actual Result				
MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected				
Analysis:	Expected results Not achieved				

219

220 **1.2.92 MDT-05 – Galaxy Note 3**

<b>Test Case MDT-05 Lantern v4.5.6</b>	
Case Summary:	MDT-05 Acquire mobile device internal memory and review supported data elements (i.e., PIM data, call logs, SMS, MMS, stand-alone files: audio, pictures, video, application related data: documents, spreadsheets, presentations, social-media data and Internet related data: bookmarks, visited sites).
Assertions:	MDT-CA-05 If a mobile device forensic tool completes acquisition of the target device without error then all supported data elements shall be presented in a useable format.
Tester Name:	rpa
Test Host:	p644381
Test Date:	Tue Apr 7 07:28:59 EDT 2015
Device:	GalaxyNote3
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:28:59 EDT 2015 Acquisition finished: Tue Apr 7 13:17:36 EDT 2015  Regular Length Address Book entries were acquired Maximum Length Address Book entries were acquired Special Character Address Book entries were acquired Blank Name Address Book entries were acquired Email addresses within Address Book entries were acquired Embedded graphics within Address Book entries were not acquired Basic PIM related data was not acquired Maximum length PIM related data was not acquired All Call Logs (incoming, outgoing, missed) were acquired All Call Log date/time stamps data were correctly reported ALL text messages (SMS, EMS) were acquired

Test Case MDT-05 Lantern v4.5.6						
	Correct date/time stamps were reported for all text messages Correct status flags were reported for all text messages Sender and Recipient phone numbers associated with text messages were correctly reported Audio MMS messages were not acquired Image MMS messages were not acquired Video MMS messages were not acquired Audio files were not acquired Image files were not acquired Video files were not acquired All application data was acquired Internet related data was not acquired Social media related data was not acquired					
Results:	<table><tr><td>Assertion &amp; Expected Result</td><td>Actual Result</td></tr><tr><td>MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.</td><td>Partial</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Partial
	Assertion & Expected Result	Actual Result				
	MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Partial				
Analysis:	Partial results achieved					

221

### 222 1.2.93 MDT-06 – Galaxy Note 3

Test Case MDT-06 Lantern v4.5.6												
Case Summary:	MDT-06 Acquire mobile device internal memory by selecting a combination of supported data elements.											
Assertions:	MDT-CA-06 If a mobile device forensic tool provides the user with an Acquire All device data objects acquisition option then the tool shall complete the acquisition of all data objects without error. MDT-CA-07 If a mobile device forensic tool provides the user with an Select All individual device data objects then the tool shall complete the acquisition of all individually selected data objects without error. MDT-CA-08 If a mobile device forensic tool provides the user with the ability to Select Individual device data objects for acquisition then the tool shall acquire each exclusive data object without error. MDT-CA-09 If a mobile device forensic tool completes two consecutive logical acquisitions of the target device without error then the payload (data objects) on the mobile device shall remain consistent.											
Tester Name:	rpa											
Test Host:	p644381											
Test Date:	Tue Apr 7 07:29:19 EDT 2015											
Device:	GalaxyNote3											
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable											
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:29:19 EDT 2015 Acquisition finished: Tue Apr 7 13:17:41 EDT 2015  Acquire All acquisition was successful											
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-06 Acquire-all mobile device data objects acquisition.</td><td>as expected</td></tr><tr><td>MDT-CA-07 Select-all mobile device data objects acquisition.</td><td>NA</td></tr><tr><td>MDT-CA-08 Select-individual mobile device data objects acquisition.</td><td>NA</td></tr><tr><td>MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected	MDT-CA-07 Select-all mobile device data objects acquisition.	NA	MDT-CA-08 Select-individual mobile device data objects acquisition.	NA	MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected
Assertion & Expected Result	Actual Result											
MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected											
MDT-CA-07 Select-all mobile device data objects acquisition.	NA											
MDT-CA-08 Select-individual mobile device data objects acquisition.	NA											
MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected											
Analysis:	Expected results achieved											

223 **1.2.94 MDT-12 – Galaxy Note 3**

Test Case MDT-12 Lantern v4.5.6						
Case Summary:	MDT-12 After a successful mobile device internal memory, alter the case file via third-party means and attempt to re-open the case.					
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:29:36 EDT 2015					
Device:	GalaxyNote3					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:29:36 EDT 2015 Acquisition finished: Tue Apr 7 13:17:47 EDT 2015  Notification of modified device memory data was not successful  <b>Notes:</b> Lantern.db was modified, the case file was re-opened without informing the user that the case data was altered. The modifications made within Lantern.db were displayed within the modified case file.					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-08 Notification of modified device case data.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-08 Notification of modified device case data.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-AO-08 Notification of modified device case data.	Not as expected					
Analysis:	Expected results Not achieved					

224

225 **1.2.95 MDT-19 – Galaxy Note 3**

Test Case MDT-19 Lantern v4.5.6		
Case Summary:	MDT-19 Acquire mobile device internal memory and review data containing non-ASCII characters.	
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Tue Apr 7 07:29:55 EDT 2015	
Device:	GalaxyNote3	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:29:55 EDT 2015 Acquisition finished: Tue Apr 7 13:17:54 EDT 2015  Non-ASCII Address book entries were acquired and properly displayed Non-ASCII text messages were acquired and properly displayed	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected
Analysis:	Expected results achieved	

226

227

228 **1.2.96 MDT-22 – Galaxy Note 3**

Test Case MDT-22 Lantern v4.5.6						
Case Summary:	MDT-22 Acquire mobile device internal memory and review hash values for vendor supported data objects.					
Assertions:	MDT-AO-15 If the mobile device forensic tool supports hashing for individual data objects then the tool shall present the user with a hash value for each supported data object.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:30:20 EDT 2015					
Device:	GalaxyNote3					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:30:20 EDT 2015 Acquisition finished: Tue Apr 7 13:18:00 EDT 2015  Hash values were properly reported for individually acquired device data elements					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-15 Hash values for individual data and case presented in a useable format.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-15 Hash values for individual data and case presented in a useable format.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-15 Hash values for individual data and case presented in a useable format.	as expected					
Analysis:	Expected results achieved					

229

230 **1.2.97 MDT-24 – Galaxy Note 3**

Test Case MDT-24 Lantern v4.5.6						
Case Summary:	MDT-24 Acquire mobile device internal memory and review data containing GPS longitude and latitude coordinates					
Assertions:	MDT-AO-16 If the mobile device forensic tool supports acquisition of GPS data then the tool shall present the user with the longitude and latitude coordinates for all GPS-related data in a useable format.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:30:40 EDT 2015					
Device:	GalaxyNote3					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:30:40 EDT 2015 Acquisition finished: Tue Apr 7 13:18:06 EDT 2015  GPS Coordinate data was not successfully acquired					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-16 Acquisition of GPS related data presented in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-16 Acquisition of GPS related data presented in a useable format.	Not as expected
	Assertion & Expected Result	Actual Result				
MDT-AO-16 Acquisition of GPS related data presented in a useable format.	Not as expected					
Analysis:	Expected results Not achieved					

231

232

233 **1.2.98 MDT-01 – HTC One GSM**

Test Case MDT-01 Lantern v4.5.6						
Case Summary:	MDT-01 Acquire mobile device internal memory over tool-supported interfaces (e.g., cable, Bluetooth, IrDA).					
Assertions:	MDT-CA-01 If a mobile device forensic tool provides support for connectivity of the target device then the tool shall successfully recognize the target device via all vendor supported interfaces (e.g., cable, Bluetooth, IrDA).					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:47:32 EDT 2015					
Device:	HTCOne GSM					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:47:32 EDT 2015 Acquisition finished: Tue Apr 7 13:18:17 EDT 2015  Device connectivity was established via supported interface					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-01 Device connectivity via supported interfaces.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-01 Device connectivity via supported interfaces.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-01 Device connectivity via supported interfaces.	as expected					
Analysis:	Expected results achieved					

234

235 **1.2.99 MDT-02 – HTC One GSM**

Test Case MDT-02 Lantern v4.5.6						
Case Summary:	MDT-02 Begin mobile device internal memory acquisition and interrupt connectivity by interface disengagement.					
Assertions:	MDT-CA-02 If connectivity between the mobile device and mobile device forensic tool is disrupted then the tool shall notify the user that connectivity has been disrupted.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:47:51 EDT 2015					
Device:	HTCone GSM					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:47:51 EDT 2015 Acquisition finished: Tue Apr 7 13:18:23 EDT 2015  Device acquisition disruption notification was successful					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-02 Notification of device acquisition disruption.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-02 Notification of device acquisition disruption.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-02 Notification of device acquisition disruption.	as expected					
Analysis:	Expected results achieved					

236

237

238 **1.2.100 MDT-03 – HTC One GSM**

Test Case MDT-03 Lantern v4.5.6						
Case Summary:	MDT-03 Acquire mobile device internal memory and review reported data via the preview-pane or generated reports for readability.					
Assertions:	MDT-CA-03 If a mobile device forensic tool completes acquisition of the target device without error then the tool shall have the ability to present acquired data objects in a useable format via either a preview-pane or generated report.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:48:12 EDT 2015					
Device:	HTCOne_GSM					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:48:12 EDT 2015 Acquisition finished: Tue Apr 7 13:18:29 EDT 2015  Readability and completeness of acquired data was successful					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-03 Readability and completeness of acquired data via supported reports.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-03 Readability and completeness of acquired data via supported reports.	as expected
	Assertion & Expected Result	Actual Result				
MDT-CA-03 Readability and completeness of acquired data via supported reports.	as expected					
Analysis:	Expected results achieved					

239

240 **1.2.101 MDT-04 – HTC One GSM**

Test Case MDT-04 Lantern v4.5.6						
Case Summary:	MDT-04 Acquire mobile device internal memory and review reported subscriber and equipment related information (e.g., IMSI, IMEI, MEID/ESN, MSISDN).					
Assertions:	MDT-CA-04 If a mobile device forensic tool completes acquisition of the target device without error then subscriber and equipment related information shall be presented in a useable format.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:48:30 EDT 2015					
Device:	HTCOne GSM					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:48:30 EDT 2015 Acquisition finished: Tue Apr 7 13:18:35 EDT 2015  MSISDN and IMEI were not acquired  <b>Notes:</b> The MSISDN, IMEI, or ICCID were not reported in "Info".					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected					
Analysis:	Expected results Not achieved					

241

242

243 **1.2.102 MDT-05 – HTC One GSM**

Test Case MDT-05 Lantern v4.5.6						
Case Summary:	MDT-05 Acquire mobile device internal memory and review supported data elements (i.e., PIM data, call logs, SMS, MMS, stand-alone files: audio, pictures, video, application related data: documents, spreadsheets, presentations, social-media data and Internet related data: bookmarks, visited sites).					
Assertions:	MDT-CA-05 If a mobile device forensic tool completes acquisition of the target device without error then all supported data elements shall be presented in a useable format.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:48:50 EDT 2015					
Device:	HTCOne GSM					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:48:50 EDT 2015 Acquisition finished: Tue Apr 7 13:18:40 EDT 2015</p> <p>Regular Length Address Book entries were acquired Maximum Length Address Book entries were acquired Special Character Address Book entries were acquired Blank Name Address Book entries were acquired Email addresses within Address Book entries were acquired Embedded graphics within Address Book entries were not acquired Basic PIM related data was not acquired Maximum length PIM related data was not acquired All Call Logs (incoming, outgoing, missed) were acquired All Call Log date/time stamps data were correctly reported ALL text messages (SMS, EMS) were acquired Correct date/time stamps were reported for all text messages Correct status flags were reported for all text messages Sender and Recipient phone numbers associated with text messages were correctly reported Audio MMS messages were not acquired Image MMS messages were not acquired Video MMS messages were not acquired ALL stand-alone data files (Audio, Image, Video) were acquired All application data was acquired All Internet related data was acquired Social media related data was not acquired</p>					
Results:	<table><tr><td>Assertion &amp; Expected Result</td><td>Actual Result</td></tr><tr><td>MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.</td><td>Partial</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Partial
Assertion & Expected Result	Actual Result					
MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Partial					
Analysis:	Partial results achieved					

244  
245

246 **1.2.103 MDT-06 – HTC One GSM**

<b>Test Case MDT-06 Lantern v4.5.6</b>											
Case Summary:	MDT-06 Acquire mobile device internal memory by selecting a combination of supported data elements.										
Assertions:	MDT-CA-06 If a mobile device forensic tool provides the user with an Acquire All device data objects acquisition option then the tool shall complete the acquisition of all data objects without error. MDT-CA-07 If a mobile device forensic tool provides the user with an Select All individual device data objects then the tool shall complete the acquisition of all individually selected data objects without error. MDT-CA-08 If a mobile device forensic tool provides the user with the ability to Select Individual device data objects for acquisition then the tool shall acquire each exclusive data object without error. MDT-CA-09 If a mobile device forensic tool completes two consecutive logical acquisitions of the target device without error then the payload (data objects) on the mobile device shall remain consistent.										
Tester Name:	rpa										
Test Host:	p644381										
Test Date:	Tue Apr 7 07:49:09 EDT 2015										
Device:	HTCOne GSM										
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable										
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:49:09 EDT 2015 Acquisition finished: Tue Apr 7 13:18:46 EDT 2015  Acquire All acquisition was successful										
Results:	<table border="1"> <thead> <tr> <th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-CA-06 Acquire-all mobile device data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-CA-07 Select-all mobile device data objects acquisition.</td><td>NA</td></tr> <tr> <td>MDT-CA-08 Select-individual mobile device data objects acquisition.</td><td>NA</td></tr> <tr> <td>MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected	MDT-CA-07 Select-all mobile device data objects acquisition.	NA	MDT-CA-08 Select-individual mobile device data objects acquisition.	NA	MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected
Assertion & Expected Result	Actual Result										
MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected										
MDT-CA-07 Select-all mobile device data objects acquisition.	NA										
MDT-CA-08 Select-individual mobile device data objects acquisition.	NA										
MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected										
Analysis:	Expected results achieved										

247

248 **1.2.104 MDT-12 – HTC One GSM**

<b>Test Case MDT-12 Lantern v4.5.6</b>	
Case Summary:	MDT-12 After a successful mobile device internal memory, alter the case file via third-party means and attempt to re-open the case.
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.
Tester Name:	rpa
Test Host:	p644381
Test Date:	Tue Apr 7 07:49:28 EDT 2015
Device:	HTCOne GSM
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:49:28 EDT 2015 Acquisition finished: Tue Apr 7 13:18:51 EDT 2015  Notification of modified device memory data was not successful  <b>Notes:</b>

Test Case MDT-12 Lantern v4.5.6		
	Lantern.db was modified, the case file was re-opened without informing the user that the case data was altered. The modifications made within Lantern.db were displayed within the modified case file.	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-AO-08 Notification of modified device case data.	Not as expected
Analysis:	Expected results Not achieved	

249

## 250 1.2.105 MDT-19 – HTC One GSM

Test Case MDT-19 Lantern v4.5.6						
Case Summary:	MDT-19 Acquire mobile device internal memory and review data containing non-ASCII characters.					
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:49:49 EDT 2015					
Device:	HTCOne GSM					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:49:49 EDT 2015 Acquisition finished: Tue Apr 7 13:18:58 EDT 2015  Non-ASCII Address book entries were acquired and properly displayed Non-ASCII text messages were acquired and properly displayed					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected					
Analysis:	Expected results achieved					

251

## 252 1.2.106 MDT-22 – HTC One GSM

<b>Test Case MDT-22 Lantern v4.5.6</b>		
Case Summary:	MDT-22 Acquire mobile device internal memory and review hash values for vendor supported data objects.	
Assertions:	MDT-AO-15 If the mobile device forensic tool supports hashing for individual data objects then the tool shall present the user with a hash value for each supported data object.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Tue Apr 7 07:50:08 EDT 2015	
Device:	HTCOne_GSM	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:50:08 EDT 2015 Acquisition finished: Tue Apr 7 13:19:05 EDT 2015</p> <p>Hash values were properly reported for individually acquired device data elements</p>	

Test Case MDT-22 Lantern v4.5.6		
Results:	<b>Assertion &amp; Expected Result</b>	
	<b>Actual Result</b>	
	MDT-AO-15 Hash values for individual data and case presented in a useable format.	as expected
Analysis:	Expected results achieved	

253

## 254 1.2.107 MDT-24 – HTC One GSM

Test Case MDT-24 Lantern v4.5.6		
Case Summary:	MDT-24 Acquire mobile device internal memory and review data containing GPS longitude and latitude coordinates	
Assertions:	MDT-AO-16 If the mobile device forensic tool supports acquisition of GPS data then the tool shall present the user with the longitude and latitude coordinates for all GPS-related data in a useable format.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Tue Apr 7 07:50:27 EDT 2015	
Device:	HTCOne GSM	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:50:27 EDT 2015 Acquisition finished: Tue Apr 7 13:19:12 EDT 2015  GPS Coordinate data was not successfully acquired	
Results:	<b>Assertion &amp; Expected Result</b>	
	<b>Actual Result</b>	
	MDT-AO-16 Acquisition of GPS related data presented in a useable format.	Not as expected
Analysis:	Expected results Not achieved	

255

## 256 1.2.108 MDT-01 – HTC One CDMA

Test Case MDT-01 Lantern v4.5.6		
Case Summary:	MDT-01 Acquire mobile device internal memory over tool-supported interfaces (e.g., cable, Bluetooth, IrDA).	
Assertions:	MDT-CA-01 If a mobile device forensic tool provides support for connectivity of the target device then the tool shall successfully recognize the target device via all vendor supported interfaces (e.g., cable, Bluetooth, IrDA).	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Tue Apr 7 07:50:58 EDT 2015	
Device:	HTCOne CDMA	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:50:58 EDT 2015 Acquisition finished: Tue Apr 7 13:19:21 EDT 2015  Device connectivity was established via supported interface	
Results:	<b>Assertion &amp; Expected Result</b>	
	<b>Actual Result</b>	

Test Case MDT-01 Lantern v4.5.6		
	MDT-CA-01 Device connectivity via supported interfaces.	as expected
Analysis:	Expected results achieved	

257

## 258 1.2.109 MDT-02 – HTC One CDMA

Test Case MDT-02 Lantern v4.5.6						
Case Summary:	MDT-02 Begin mobile device internal memory acquisition and interrupt connectivity by interface disengagement.					
Assertions:	MDT-CA-02 If connectivity between the mobile device and mobile device forensic tool is disrupted then the tool shall notify the user that connectivity has been disrupted.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:51:16 EDT 2015					
Device:	HTCOne CDMA					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:51:16 EDT 2015 Acquisition finished: Tue Apr 7 13:19:27 EDT 2015  Device acquisition disruption notification was successful					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-02 Notification of device acquisition disruption.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-02 Notification of device acquisition disruption.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-02 Notification of device acquisition disruption.	as expected					
Analysis:	Expected results achieved					

259

## 260 1.2.110 MDT-03 – HTC One CDMA

Test Case MDT-03 Lantern v4.5.6						
Case Summary:	MDT-03 Acquire mobile device internal memory and review reported data via the preview-pane or generated reports for readability.					
Assertions:	MDT-CA-03 If a mobile device forensic tool completes acquisition of the target device without error then the tool shall have the ability to present acquired data objects in a useable format via either a preview-pane or generated report.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:51:36 EDT 2015					
Device:	HTCOne CDMA					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:51:36 EDT 2015 Acquisition finished: Tue Apr 7 13:19:33 EDT 2015  Readability and completeness of acquired data was successful					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-03 Readability and completeness of acquired data via supported reports.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-03 Readability and completeness of acquired data via supported reports.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-03 Readability and completeness of acquired data via supported reports.	as expected					

<b>Test Case MDT-03 Lantern v4.5.6</b>	
Analysis:	Expected results achieved

261

## 262 1.2.111 MDT-04 – HTC One CDMA

<b>Test Case MDT-04 Lantern v4.5.6</b>					
Case Summary:	MDT-04 Acquire mobile device internal memory and review reported subscriber and equipment related information (e.g., IMSI, IMEI, MEID/ESN, MSISDN).				
Assertions:	MDT-CA-04 If a mobile device forensic tool completes acquisition of the target device without error then subscriber and equipment related information shall be presented in a useable format.				
Tester Name:	rpa				
Test Host:	p644381				
Test Date:	Tue Apr 7 07:51:56 EDT 2015				
Device:	HTCOne_CDMA				
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable				
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:51:56 EDT 2015 Acquisition finished: Tue Apr 7 13:19:39 EDT 2015  IMEI, MEID/ESN were not acquired  <b>Notes:</b> The MSISDN, IMEI, or ICCID were not reported in "Info".				
Results:	<table border="1"> <thead> <tr> <th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.</td><td>Not as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected
Assertion & Expected Result	Actual Result				
MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected				
Analysis:	Expected results Not achieved				

263

## 264 1.2.112 MDT-05 – HTC One CDMA

<b>Test Case MDT-05 Lantern v4.5.6</b>	
Case Summary:	MDT-05 Acquire mobile device internal memory and review supported data elements (i.e., PIM data, call logs, SMS, MMS, stand-alone files: audio, pictures, video, application related data: documents, spreadsheets, presentations, social-media data and Internet related data: bookmarks, visited sites).
Assertions:	MDT-CA-05 If a mobile device forensic tool completes acquisition of the target device without error then all supported data elements shall be presented in a useable format.
Tester Name:	rpa
Test Host:	p644381
Test Date:	Tue Apr 7 07:52:18 EDT 2015
Device:	HTCOne_CDMA
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:52:18 EDT 2015 Acquisition finished: Tue Apr 7 13:19:46 EDT 2015  Regular Length Address Book entries were acquired Maximum Length Address Book entries were acquired Special Character Address Book entries were acquired Blank Name Address Book entries were acquired Email addresses within Address Book entries were acquired Embedded graphics within Address Book entries were not acquired

Test Case MDT-05 Lantern v4.5.6						
	<p>Basic PIM related data was not acquired Maximum length PIM related data was not acquired All Call Logs (incoming, outgoing, missed) were acquired All Call Log date/time stamps data were correctly reported ALL text messages (SMS, EMS) were acquired Correct date/time stamps were reported for all text messages Correct status flags were reported for all text messages Sender and Recipient phone numbers associated with text messages were correctly reported Audio MMS messages were not acquired Image MMS messages were not acquired Video MMS messages were not acquired Audio files were not acquired Image files were acquired Video files were acquired All application data was acquired All Internet related data was acquired Social media related data was not acquired</p>					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.</td><td>Partial</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Partial
	Assertion & Expected Result	Actual Result				
MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Partial					
Analysis:	Partial results achieved					

265

## 266 1.2.113 MDT-06 – HTC One CDMA

Test Case MDT-06 Lantern v4.5.6										
Case Summary:	MDT-06 Acquire mobile device internal memory by selecting a combination of supported data elements.									
Assertions:	MDT-CA-06 If a mobile device forensic tool provides the user with an Acquire All device data objects acquisition option then the tool shall complete the acquisition of all data objects without error. MDT-CA-07 If a mobile device forensic tool provides the user with an Select All individual device data objects then the tool shall complete the acquisition of all individually selected data objects without error. MDT-CA-08 If a mobile device forensic tool provides the user with the ability to Select Individual device data objects for acquisition then the tool shall acquire each exclusive data object without error. MDT-CA-09 If a mobile device forensic tool completes two consecutive logical acquisitions of the target device without error then the payload (data objects) on the mobile device shall remain consistent.									
Tester Name:	rpa									
Test Host:	p644381									
Test Date:	Tue Apr 7 07:52:39 EDT 2015									
Device:	HTCone CDMA									
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable									
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:52:39 EDT 2015 Acquisition finished: Tue Apr 7 13:19:51 EDT 2015  Acquire All acquisition was successful									
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-06 Acquire-all mobile device data objects acquisition.</td><td>as expected</td></tr><tr><td>MDT-CA-07 Select-all mobile device data objects acquisition.</td><td>NA</td></tr><tr><td>MDT-CA-08 Select-individual mobile device data objects acquisition.</td><td>NA</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected	MDT-CA-07 Select-all mobile device data objects acquisition.	NA	MDT-CA-08 Select-individual mobile device data objects acquisition.	NA
Assertion & Expected Result	Actual Result									
MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected									
MDT-CA-07 Select-all mobile device data objects acquisition.	NA									
MDT-CA-08 Select-individual mobile device data objects acquisition.	NA									

Test Case MDT-06 Lantern v4.5.6		
	MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected
Analysis:	Expected results achieved	

267

## 268 1.2.114 MDT-12 – HTC One CDMA

Test Case MDT-12 Lantern v4.5.6						
Case Summary:	MDT-12 After a successful mobile device internal memory, alter the case file via third-party means and attempt to re-open the case.					
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:52:59 EDT 2015					
Device:	HTCone_CDMA					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:52:59 EDT 2015 Acquisition finished: Tue Apr 7 13:19:58 EDT 2015</p> <p>Notification of modified device memory data was not successful</p> <p><b>Notes:</b> Lantern.db was modified, the case file was re-opened without informing the user that the case data was altered. The modifications made within Lantern.db were displayed within the modified case file.</p>					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-08 Notification of modified device case data.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-08 Notification of modified device case data.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-AO-08 Notification of modified device case data.	Not as expected					
Analysis:	Expected results Not achieved					

269

## 270 1.2.115 MDT-19 – HTC One CDMA

Test Case MDT-19 Lantern v4.5.6						
Case Summary:	MDT-19 Acquire mobile device internal memory and review data containing non-ASCII characters.					
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:53:18 EDT 2015					
Device:	HTCone CDMA					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:53:18 EDT 2015 Acquisition finished: Tue Apr 7 13:20:04 EDT 2015  Non-ASCII Address book entries were acquired and properly displayed Non-ASCII text messages were acquired and properly displayed					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td></td><td></td></tr></table>		Assertion & Expected Result	Actual Result		
Assertion & Expected Result	Actual Result					

Test Case MDT-19 Lantern v4.5.6		
	MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected
Analysis:	Expected results achieved	

271

## 272 1.2.116 MDT-22 – HTC One CDMA

Test Case MDT-22 Lantern v4.5.6						
Case Summary:	MDT-22 Acquire mobile device internal memory and review hash values for vendor supported data objects.					
Assertions:	MDT-AO-15 If the mobile device forensic tool supports hashing for individual data objects then the tool shall present the user with a hash value for each supported data object.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:53:45 EDT 2015					
Device:	HTCOne_CDMA					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:53:45 EDT 2015 Acquisition finished: Tue Apr 7 13:20:09 EDT 2015  Hash values were properly reported for individually acquired device data elements					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-15 Hash values for individual data and case presented in a useable format.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-15 Hash values for individual data and case presented in a useable format.	as expected
	Assertion & Expected Result	Actual Result				
MDT-AO-15 Hash values for individual data and case presented in a useable format.	as expected					
Analysis:	Expected results achieved					

273

## 274 1.2.117 MDT-24 – HTC One CDMA

Test Case MDT-24 Lantern v4.5.6						
Case Summary:	MDT-24 Acquire mobile device internal memory and review data containing GPS longitude and latitude coordinates					
Assertions:	MDT-AO-16 If the mobile device forensic tool supports acquisition of GPS data then the tool shall present the user with the longitude and latitude coordinates for all GPS-related data in a useable format.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:54:05 EDT 2015					
Device:	HTCOne CDMA					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:54:05 EDT 2015 Acquisition finished: Tue Apr 7 13:20:17 EDT 2015  GPS Coordinate data was not successfully acquired					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-16 Acquisition of GPS related data presented in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-16 Acquisition of GPS related data presented in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-AO-16 Acquisition of GPS related data presented in a useable format.	Not as expected					

<b>Test Case MDT-24 Lantern v4.5.6</b>	
Analysis:	Expected results Not achieved

## 1.2.118 MDT-01 – Nexus4

<b>Test Case MDT-01 Lantern v4.5.6</b>					
Case Summary:	MDT-01 Acquire mobile device internal memory over tool-supported interfaces (e.g., cable, Bluetooth, IrDA).				
Assertions:	MDT-CA-01 If a mobile device forensic tool provides support for connectivity of the target device then the tool shall successfully recognize the target device via all vendor supported interfaces (e.g., cable, Bluetooth, IrDA).				
Tester Name:	rpa				
Test Host:	p644381				
Test Date:	Tue Apr 7 07:54:33 EDT 2015				
Device:	Nexus4				
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable				
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:54:33 EDT 2015 Acquisition finished: Tue Apr 7 13:20:24 EDT 2015  Device connectivity was established via supported interface				
Results:	<table> <tr> <th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr> <tr> <td>MDT-CA-01 Device connectivity via supported interfaces.</td><td>as expected</td></tr> </table>	Assertion & Expected Result	Actual Result	MDT-CA-01 Device connectivity via supported interfaces.	as expected
Assertion & Expected Result	Actual Result				
MDT-CA-01 Device connectivity via supported interfaces.	as expected				
Analysis:	Expected results achieved				

## 1.2.119 MDT-02 – Nexus4

<b>Test Case MDT-02 Lantern v4.5.6</b>					
Case Summary:	MDT-02 Begin mobile device internal memory acquisition and interrupt connectivity by interface disengagement.				
Assertions:	MDT-CA-02 If connectivity between the mobile device and mobile device forensic tool is disrupted then the tool shall notify the user that connectivity has been disrupted.				
Tester Name:	rpa				
Test Host:	p644381				
Test Date:	Tue Apr 7 07:54:50 EDT 2015				
Device:	Nexus4				
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable				
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:54:50 EDT 2015 Acquisition finished: Tue Apr 7 13:20:39 EDT 2015  Device acquisition disruption notification was successful				
Results:	<table> <tr> <th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr> <tr> <td>MDT-CA-02 Notification of device acquisition disruption.</td><td>as expected</td></tr> </table>	Assertion & Expected Result	Actual Result	MDT-CA-02 Notification of device acquisition disruption.	as expected
Assertion & Expected Result	Actual Result				
MDT-CA-02 Notification of device acquisition disruption.	as expected				
Analysis:	Expected results achieved				

281 **1.2.120 MDT-03 – Nexus4**

Test Case MDT-03 Lantern v4.5.6						
Case Summary:	MDT-03 Acquire mobile device internal memory and review reported data via the preview-pane or generated reports for readability.					
Assertions:	MDT-CA-03 If a mobile device forensic tool completes acquisition of the target device without error then the tool shall have the ability to present acquired data objects in a useable format via either a preview-pane or generated report.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:55:08 EDT 2015					
Device:	Nexus4					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:55:08 EDT 2015 Acquisition finished: Tue Apr 7 13:20:45 EDT 2015  Readability and completeness of acquired data was successful					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-03 Readability and completeness of acquired data via supported reports.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-03 Readability and completeness of acquired data via supported reports.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-03 Readability and completeness of acquired data via supported reports.	as expected					
Analysis:	Expected results achieved					

282

283 **1.2.121 MDT-04 – Nexus4**

Test Case MDT-04 Lantern v4.5.6						
Case Summary:	MDT-04 Acquire mobile device internal memory and review reported subscriber and equipment related information (e.g., IMSI, IMEI, MEID/ESN, MSISDN).					
Assertions:	MDT-CA-04 If a mobile device forensic tool completes acquisition of the target device without error then subscriber and equipment related information shall be presented in a useable format.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:55:27 EDT 2015					
Device:	Nexus4					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:55:27 EDT 2015 Acquisition finished: Tue Apr 7 13:20:52 EDT 2015  MSISDN and IMEI were not acquired  <b>Notes:</b> The MSISDN, IMEI, or ICCID were not reported in "Info".					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected					
Analysis:	Expected results Not achieved					

284

285

286 **1.2.122 MDT-05 – Nexus4**

Test Case MDT-05 Lantern v4.5.6						
Case Summary:	MDT-05 Acquire mobile device internal memory and review supported data elements (i.e., PIM data, call logs, SMS, MMS, stand-alone files: audio, pictures, video, application related data: documents, spreadsheets, presentations, social-media data and Internet related data: bookmarks, visited sites).					
Assertions:	MDT-CA-05 If a mobile device forensic tool completes acquisition of the target device without error then all supported data elements shall be presented in a useable format.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:55:46 EDT 2015					
Device:	Nexus4					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:55:46 EDT 2015 Acquisition finished: Tue Apr 7 13:20:58 EDT 2015</p> <p>Regular Length Address Book entries were acquired Maximum Length Address Book entries were acquired Special Character Address Book entries were acquired Blank Name Address Book entries were acquired Email addresses within Address Book entries were acquired Embedded graphics within Address Book entries were not acquired Basic PIM related data was not acquired Maximum length PIM related data was not acquired All Call Logs (incoming, outgoing, missed) were acquired All Call Log date/time stamps data were correctly reported ALL text messages (SMS, EMS) were acquired Correct date/time stamps were reported for all text messages Correct status flags were reported for all text messages Sender and Recipient phone numbers associated with text messages were correctly reported Audio MMS messages were not acquired Image MMS messages were not acquired Video MMS messages were not acquired Audio files were not acquired Image files were acquired Video files were acquired All application data was acquired All Internet related data was acquired Social media related data was not acquired</p>					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.</td><td>Partial</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Partial
	Assertion & Expected Result	Actual Result				
MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Partial					
Analysis:	Expected results Not achieved					

287  
288

289 **1.2.123 MDT-06 – Nexus4**

<b>Test Case MDT-06 Lantern v4.5.6</b>											
Case Summary:	MDT-06 Acquire mobile device internal memory by selecting a combination of supported data elements.										
Assertions:	MDT-CA-06 If a mobile device forensic tool provides the user with an Acquire All device data objects acquisition option then the tool shall complete the acquisition of all data objects without error. MDT-CA-07 If a mobile device forensic tool provides the user with an Select All individual device data objects then the tool shall complete the acquisition of all individually selected data objects without error. MDT-CA-08 If a mobile device forensic tool provides the user with the ability to Select Individual device data objects for acquisition then the tool shall acquire each exclusive data object without error. MDT-CA-09 If a mobile device forensic tool completes two consecutive logical acquisitions of the target device without error then the payload (data objects) on the mobile device shall remain consistent.										
Tester Name:	rpa										
Test Host:	p644381										
Test Date:	Tue Apr 7 07:56:05 EDT 2015										
Device:	Nexus4										
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable										
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:56:05 EDT 2015 Acquisition finished: Tue Apr 7 13:21:03 EDT 2015  Acquire All acquisition was successful										
Results:	<table border="1"> <thead> <tr> <th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-CA-06 Acquire-all mobile device data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-CA-07 Select-all mobile device data objects acquisition.</td><td>NA</td></tr> <tr> <td>MDT-CA-08 Select-individual mobile device data objects acquisition.</td><td>NA</td></tr> <tr> <td>MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected	MDT-CA-07 Select-all mobile device data objects acquisition.	NA	MDT-CA-08 Select-individual mobile device data objects acquisition.	NA	MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected
Assertion & Expected Result	Actual Result										
MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected										
MDT-CA-07 Select-all mobile device data objects acquisition.	NA										
MDT-CA-08 Select-individual mobile device data objects acquisition.	NA										
MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected										
Analysis:	Expected results achieved										

290

291 **1.2.124 MDT-12 – Nexus4**

<b>Test Case MDT-12 Lantern v4.5.6</b>	
Case Summary:	MDT-12 After a successful mobile device internal memory, alter the case file via third-party means and attempt to re-open the case.
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.
Tester Name:	rpa
Test Host:	p644381
Test Date:	Tue Apr 7 07:56:25 EDT 2015
Device:	Nexus4
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:56:25 EDT 2015 Acquisition finished: Tue Apr 7 13:21:09 EDT 2015  Notification of modified device memory data was not successful  <b>Notes:</b>

Test Case MDT-12 Lantern v4.5.6		
	Lantern.db was modified, the case file was re-opened without informing the user that the case data was altered. The modifications made within Lantern.db were displayed within the modified case file.	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-AO-08 Notification of modified device case data.	Not as expected
Analysis:	Expected results Not achieved	

292

## 293 1.2.125 MDT-19 – Nexus4

Test Case MDT-19 Lantern v4.5.6						
Case Summary:	MDT-19 Acquire mobile device internal memory and review data containing non-ASCII characters.					
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.					
Tester Name:	rpa					
Test Host:	p644381					
Test Date:	Tue Apr 7 07:56:44 EDT 2015					
Device:	Nexus4					
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable					
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:56:44 EDT 2015 Acquisition finished: Tue Apr 7 13:21:14 EDT 2015  Non-ASCII Address book entries were acquired and properly displayed Non-ASCII text messages were acquired and properly displayed					
Results:	<table><tr><th>Assertion &amp; Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected					
Analysis:	Expected results achieved					

294

## 295 1.2.126 MDT-22 – Nexus4

Test Case MDT-22 Lantern v4.5.6		
Case Summary:	MDT-22 Acquire mobile device internal memory and review hash values for vendor supported data objects.	
Assertions:	MDT-AO-15 If the mobile device forensic tool supports hashing for individual data objects then the tool shall present the user with a hash value for each supported data object.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Tue Apr 7 07:57:01 EDT 2015	
Device:	Nexus4	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	<p>Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:57:01 EDT 2015 Acquisition finished: Tue Apr 7 13:21:23 EDT 2015</p> <p>Hash values were properly reported for individually acquired device data elements</p>	

Test Case MDT-22 Lantern v4.5.6		
Results:		
	<b>Assertion &amp; Expected Result</b>	<b>Actual Result</b>
	MDT-AO-15 Hash values for individual data and case presented in a useable format.	as expected
Analysis:	Expected results achieved	

296

## 297 1.2.127 MDT-24 – Nexus4

Test Case MDT-24 Lantern v4.5.6		
Case Summary:	MDT-24 Acquire mobile device internal memory and review data containing GPS longitude and latitude coordinates	
Assertions:	MDT-AO-16 If the mobile device forensic tool supports acquisition of GPS data then the tool shall present the user with the longitude and latitude coordinates for all GPS-related data in a useable format.	
Tester Name:	rpa	
Test Host:	p644381	
Test Date:	Tue Apr 7 07:57:17 EDT 2015	
Device:	Nexus4	
Source Setup:	OS: Mac OS X v10.9.5 Interface: cable	
Log Highlights:	Created by Lantern v4.5.6 Acquisition started: Tue Apr 7 07:57:17 EDT 2015 Acquisition finished: Tue Apr 7 13:21:29 EDT 2015  GPS Coordinate data was not successfully acquired	
Results:		
	<b>Assertion &amp; Expected Result</b>	<b>Actual Result</b>
	MDT-AO-16 Acquisition of GPS related data presented in a useable format.	Not as expected
Analysis:	Expected results Not achieved	

298