

1 Test Results for Mobile Device Acquisition Tool –

2 MPE+ v5.5.3.73

3 The main item of interest for interpreting the test results is determining the conformance
4 of the tool under test. Conformance with each assertion tested by a given test case is
5 evaluated by examining the **Log Highlights** box of the test report.
6

7 1.1 Test Results Report Key

8 The following table presents an explanation of each section of the test details in section
9 1.2. The Tester Name, Test Host, Test Date, Device, Source Setup and Log Highlights
10 sections for each test case are populated by excerpts taken from the log files produced by
11 the tool under test.
12
13

Heading	Description
First Line:	Test case ID, name, and version of tool tested.
Case Summary:	Test case summary from <i>Mobile Device Tool Test Assertions and Test Plan (Draft 1 Version 1.0, July 8, 2014)</i> .
Assertions:	The test assertions applicable to the test case, selected from <i>Mobile Device Tool Test Assertions and Test Plan (Draft 1 Version 1.0, July 8, 2014)</i> .
Tester Name:	Name or initials of person executing test procedure.
Test Host:	Host computer executing the test.
Test Date:	Time and date that test was started.
Device:	Source mobile device, SIM.
Source Setup:	Acquisition interface.
Log Highlights:	Information extracted from various log files to illustrate conformance or non-conformance to the test assertions.

14 **Table 1: Test Results Report Key**
15

1.2 Test Results

The test results are presented in this section.

1.2.1 MDT-01 – Samsung Galaxy Note 3 (CDMA)

Test Case MDT-01 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-01 Acquire mobile device internal memory over tool-supported interfaces (e.g., cable, Bluetooth, IrDA).					
Assertions:	MDT-CA-01 If a mobile device forensic tool provides support for connectivity of the target device then the tool shall successfully recognize the target device via all vendor supported interfaces (e.g., cable, Bluetooth, IrDA).					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Fri Jul 18 15:21:26 EDT 2014					
Device:	Samsung GalaxyNote					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Jul 18 15:21:26 EDT 2014 Acquisition finished: Fri Jul 18 15:25:13 EDT 2014 Device connectivity was established via supported interface					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-01 Device connectivity via supported interfaces.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-01 Device connectivity via supported interfaces.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-01 Device connectivity via supported interfaces.	as expected					
Analysis:	Expected results achieved					

1.2.2 MDT-02 – Samsung Galaxy Note 3 (CDMA)

Test Case MDT-02 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-02 Begin mobile device internal memory acquisition and interrupt connectivity by interface disengagement.					
Assertions:	MDT-CA-02 If connectivity between the mobile device and mobile device forensic tool is disrupted then the tool shall notify the user that connectivity has been disrupted.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Fri Jul 18 15:26:01 EDT 2014					
Device:	Samsung_GalaxyNote					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Jul 18 15:26:01 EDT 2014 Acquisition finished: Fri Jul 18 15:49:13 EDT 2014 Device acquisition disruption notification was successful					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-02 Notification of device acquisition disruption.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-02 Notification of device acquisition disruption.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-02 Notification of device acquisition disruption.	as expected					
Analysis:	Expected results achieved					

23 **1.2.3 MDT-03 – Samsung Galaxy Note 3 (CDMA)**

Test Case MDT-03 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-03 Acquire mobile device internal memory and review reported data via the preview-pane or generated reports for readability.	
Assertions:	MDT-CA-03 If a mobile device forensic tool completes acquisition of the target device without error then the tool shall have the ability to present acquired data objects in a useable format via either a preview-pane or generated report.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Fri Jul 18 15:54:59 EDT 2014	
Device:	Samsung_GalaxyNote	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Jul 18 15:54:59 EDT 2014 Acquisition finished: Fri Jul 18 17:03:25 EDT 2014 Readability and completeness of acquired data was successful	
Results:	Assertion & Expected Result	
	MDT-CA-03 Readability and completeness of acquired data via supported reports.	Actual Result as expected
Analysis:	Expected results achieved	

24

25 **1.2.4 MDT-04 – Samsung Galaxy Note 3 (CDMA)**

Test Case MDT-04 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-04 Acquire mobile device internal memory and review reported subscriber and equipment related information (e.g., IMSI, IMEI, MEID/ESN, MSISDN).					
Assertions:	MDT-CA-04 If a mobile device forensic tool completes acquisition of the target device without error then subscriber and equipment related information shall be presented in a useable format.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Tue Jul 22 13:31:41 EDT 2014					
Device:	Samsung GalaxyNote					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Jul 22 13:31:41 EDT 2014 Acquisition finished: Tue Jul 22 15:56:44 EDT 2014 MEID/ESN was acquired Notes: The MSISDN was not reported.					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected					
Analysis:	Partial results achieved					

26

1.2.5 MDT-05 – Samsung Galaxy Note 3 (CDMA)

Test Case MDT-05 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-05 Acquire mobile device internal memory and review supported data elements (i.e., PIM data, call logs, SMS, MMS, stand-alone files: audio, pictures, video, application related data: documents, spreadsheets, presentations, social-media data and Internet related data: bookmarks, visited sites).					
Assertions:	MDT-CA-05 If a mobile device forensic tool completes acquisition of the target device without error then all supported data elements shall be presented in a useable format.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Tue Jul 22 16:01:32 EDT 2014					
Device:	Samsung GalaxyNote					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Jul 22 16:01:32 EDT 2014 Acquisition finished: Tue Jul 22 16:27:36 EDT 2014</p> <p>All address book entries were successfully acquired All PIM related data was acquired All Call Logs (incoming, outgoing, missed) were acquired All Call Log date/time stamps data were correctly reported ALL text messages (SMS, EMS) were acquired Correct date/time stamps were reported for all text messages Correct status flags were reported for all text messages Sender and Recipient phone numbers associated with text messages were correctly reported ALL MMS messages (Audio, Image, Video) were acquired ALL stand-alone data files (Audio, Image, Video) were acquired Application data was not acquired Internet related data was not acquired All Social media related data was acquired</p> <p>Notes: Graphic files associated with contact entries were not acquired. Internet related data (bookmarks) were not acquired.</p>					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Not as expected					
Analysis:	Partial results achieved					

29 1.2.6 MDT-06 – Samsung Galaxy Note 3 (CDMA)

Test Case MDT-06 Access Data MPE+ v5.5.2.60											
Case Summary:	MDT-06 Acquire mobile device internal memory by selecting a combination of supported data elements.										
Assertions:	MDT-CA-06 If a mobile device forensic tool provides the user with an Acquire All device data objects acquisition option then the tool shall complete the acquisition of all data objects without error. MDT-CA-07 If a mobile device forensic tool provides the user with an Select All individual device data objects then the tool shall complete the acquisition of all individually selected data objects without error. MDT-CA-08 If a mobile device forensic tool provides the user with the ability to Select Individual device data objects for acquisition then the tool shall acquire each exclusive data object without error. MDT-CA-09 If a mobile device forensic tool completes two consecutive logical acquisitions of the target device without error then the payload (data objects) on the mobile device shall remain consistent.										
Tester Name:	jrr										
Test Host:	pN100919										
Test Date:	Tue Jul 22 16:41:33 EDT 2014										
Device:	Samsung_GalaxyNote										
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable										
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Jul 22 16:41:33 EDT 2014 Acquisition finished: Tue Jul 22 16:47:03 EDT 2014 Acquire All acquisition was successful Select All acquisition was successful Individual data element acquisition was successful										
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-CA-06 Acquire-all mobile device data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-CA-07 Select-all mobile device data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-CA-08 Select-individual mobile device data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected	MDT-CA-07 Select-all mobile device data objects acquisition.	as expected	MDT-CA-08 Select-individual mobile device data objects acquisition.	as expected	MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected
Assertion & Expected Result	Actual Result										
MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected										
MDT-CA-07 Select-all mobile device data objects acquisition.	as expected										
MDT-CA-08 Select-individual mobile device data objects acquisition.	as expected										
MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected										
Analysis:	Expected results achieved										

30

31 1.2.7 MDT-12 – Samsung Galaxy Note 3 (CDMA)

Test Case MDT-12 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-12 After a successful mobile device internal memory, alter the case file via third-party means and attempt to re-open the case.
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.
Tester Name:	jrr
Test Host:	pN100919
Test Date:	Wed Jul 23 10:54:24 EDT 2014
Device:	Samsung_GalaxyNote
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Jul 23 10:54:24 EDT 2014 Acquisition finished: Wed Jul 23 11:13:39 EDT 2014

Test Case MDT-12 Access Data MPE+ v5.5.2.60						
	Notification of modified device memory data was successful Notes: Case file data can be modified without warning when re-opening the test case. However, when the test case is re-opened the original data is reported.					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-08 Notification of modified device case data.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-08 Notification of modified device case data.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-08 Notification of modified device case data.	as expected					
Analysis:	Expected results achieved					

32

33 1.2.8 MDT-19 – Samsung Galaxy Note 3 (CDMA)

Test Case MDT-19 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-19 Acquire mobile device internal memory and review data containing non-ASCII characters.					
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Wed Jul 23 11:17:16 EDT 2014					
Device:	Samsung GalaxyNote					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Jul 23 11:17:16 EDT 2014 Acquisition finished: Wed Jul 23 12:01:50 EDT 2014 Non-ASCII Address book entries were acquired and properly displayed Non-ASCII text messages were acquired and properly displayed					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected					
Analysis:	Expected results achieved					

34

35 1.2.9 MDT-22 – Samsung Galaxy Note 3 (CDMA)

Test Case MDT-22 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-22 Acquire mobile device internal memory and review hash values for vendor supported data objects.	
Assertions:	MDT-AO-15 If the mobile device forensic tool supports hashing for individual data objects then the tool shall present the user with a hash value for each supported data object.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Wed Jul 23 12:02:41 EDT 2014	
Device:	Samsung GalaxyNote	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Jul 23 12:02:41 EDT 2014 Acquisition finished: Wed Jul 23 13:27:38 EDT 2014	

Test Case MDT-22 Access Data MPE+ v5.5.2.60		
	Hash values were properly reported for individually acquired device data elements	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-AO-15 Hash values for individual data and case presented in a useable format.	as expected
Analysis:	Expected results achieved	

36

37 1.2.10 MDT-01 – Samsung Galaxy S3 (GSM)

Test Case MDT-01 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-01 Acquire mobile device internal memory over tool-supported interfaces (e.g., cable, Bluetooth, IrDA).	
Assertions:	MDT-CA-01 If a mobile device forensic tool provides support for connectivity of the target device then the tool shall successfully recognize the target device via all vendor supported interfaces (e.g., cable, Bluetooth, IrDA).	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Tue Aug 19 14:55:45 EDT 2014	
Device:	Samsung GalaxyS3	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Aug 19 14:55:45 EDT 2014 Acquisition finished: Tue Aug 19 15:33:07 EDT 2014 Device connectivity was established via supported interface	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-CA-01 Device connectivity via supported interfaces.	as expected
Analysis:	Expected results achieved	

38

39 1.2.11 MDT-02 – Samsung Galaxy S3 (GSM)

Test Case MDT-02 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-02 Begin mobile device internal memory acquisition and interrupt connectivity by interface disengagement.	
Assertions:	MDT-CA-02 If connectivity between the mobile device and mobile device forensic tool is disrupted then the tool shall notify the user that connectivity has been disrupted.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Tue Aug 19 14:56:50 EDT 2014	
Device:	Samsung GalaxyS3	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Aug 19 14:56:50 EDT 2014 Acquisition finished: Tue Aug 19 15:33:25 EDT 2014 Device acquisition disruption notification was successful	
Results:		

Test Case MDT-02 Access Data MPE+ v5.5.2.60		
	Assertion & Expected Result	Actual Result
	MDT-CA-02 Notification of device acquisition disruption.	as expected
Analysis:	Expected results achieved	

40

41 1.2.12 MDT-03 – Samsung Galaxy S3 (GSM)

Test Case MDT-03 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-03 Acquire mobile device internal memory and review reported data via the preview-pane or generated reports for readability.					
Assertions:	MDT-CA-03 If a mobile device forensic tool completes acquisition of the target device without error then the tool shall have the ability to present acquired data objects in a useable format via either a preview-pane or generated report.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Tue Aug 19 14:57:42 EDT 2014					
Device:	Samsung GalaxyS3					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Aug 19 14:57:42 EDT 2014 Acquisition finished: Thu Aug 21 11:53:50 EDT 2014 Readability and completeness of acquired data was successful					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-03 Readability and completeness of acquired data via supported reports.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-03 Readability and completeness of acquired data via supported reports.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-03 Readability and completeness of acquired data via supported reports.	as expected					
Analysis:	Expected results achieved					

42

43 1.2.13 MDT-04 – Samsung Galaxy S3 (GSM)

Test Case MDT-04 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-04 Acquire mobile device internal memory and review reported subscriber and equipment related information (e.g., IMSI, IMEI, MEID/ESN, MSISDN).	
Assertions:	MDT-CA-04 If a mobile device forensic tool completes acquisition of the target device without error then subscriber and equipment related information shall be presented in a useable format.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Tue Aug 19 14:58:24 EDT 2014	
Device:	Samsung_GalaxyS3	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Aug 19 14:58:24 EDT 2014 Acquisition finished: Thu Aug 21 11:55:31 EDT 2014 IMEI was acquired Notes: The MSISDN was not reported.	
Results:		

Test Case MDT-04 Access Data MPE+ v5.5.2.60		
	Assertion & Expected Result	Actual Result
	MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected
Analysis:	Partial results achieved	

44

45 1.2.14 MDT-05 – Samsung Galaxy S3 (GSM)

Test Case MDT-05 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-05 Acquire mobile device internal memory and review supported data elements (i.e., PIM data, call logs, SMS, MMS, stand-alone files: audio, pictures, video, application related data: documents, spreadsheets, presentations, social-media data and Internet related data: bookmarks, visited sites).					
Assertions:	MDT-CA-05 If a mobile device forensic tool completes acquisition of the target device without error then all supported data elements shall be presented in a useable format.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Tue Aug 19 14:59:11 EDT 2014					
Device:	Samsung GalaxyS3					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Aug 19 14:59:11 EDT 2014 Acquisition finished: Thu Aug 21 12:00:11 EDT 2014</p> <p>All address book entries were successfully acquired Partial PIM related data was acquired All Call Logs (incoming, outgoing, missed) were acquired All Call Log date/time stamps data were correctly reported ALL text messages (SMS, EMS) were acquired Correct date/time stamps were reported for all text messages Correct status flags were reported for all text messages Sender and Recipient phone numbers associated with text messages were correctly reported ALL MMS messages (Audio, Image, Video) were acquired ALL stand-alone data files (Audio, Image, Video) were acquired Application data was not acquired All Internet related data was acquired All Social media related data was acquired</p> <p>Notes: Graphic files associated with contact entries were not acquired.</p>					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Not as expected					
Analysis:	Partial results achieved					

46

47 1.2.15 MDT-06 – Samsung Galaxy S3 (GSM)

Test Case MDT-06 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-06 Acquire mobile device internal memory by selecting a combination of supported data elements.
Assertions:	MDT-CA-06 If a mobile device forensic tool provides the user with an Acquire All device data objects acquisition option then the tool shall

Test Case MDT-06 Access Data MPE+ v5.5.2.60											
	complete the acquisition of all data objects without error. MDT-CA-07 If a mobile device forensic tool provides the user with an Select All individual device data objects then the tool shall complete the acquisition of all individually selected data objects without error. MDT-CA-08 If a mobile device forensic tool provides the user with the ability to Select Individual device data objects for acquisition then the tool shall acquire each exclusive data object without error. MDT-CA-09 If a mobile device forensic tool completes two consecutive logical acquisitions of the target device without error then the payload (data objects) on the mobile device shall remain consistent.										
Tester Name:	jrr										
Test Host:	pN100919										
Test Date:	Tue Aug 19 14:59:58 EDT 2014										
Device:	Samsung GalaxyS3										
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable										
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Aug 19 14:59:58 EDT 2014 Acquisition finished: Thu Aug 21 12:06:33 EDT 2014 Acquire All acquisition was successful Select All acquisition was successful Individual data element acquisition was successful										
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-CA-06 Acquire-all mobile device data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-CA-07 Select-all mobile device data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-CA-08 Select-individual mobile device data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected	MDT-CA-07 Select-all mobile device data objects acquisition.	as expected	MDT-CA-08 Select-individual mobile device data objects acquisition.	as expected	MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected
Assertion & Expected Result	Actual Result										
MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected										
MDT-CA-07 Select-all mobile device data objects acquisition.	as expected										
MDT-CA-08 Select-individual mobile device data objects acquisition.	as expected										
MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected										
Analysis:	Expected results achieved										

48

49 1.2.16 MDT-07 – Samsung Galaxy S3 (GSM)

Test Case MDT-07 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-07 Acquire UICC memory over supported interfaces (e.g., PC/SC reader).
Assertions:	MDT-AO-01 If a mobile device forensic tool provides support for connectivity of the target UICC then the tool shall successfully recognize the target SIM via all tool-supported interfaces (e.g., PC/SC reader, proprietary reader, smart phone itself).
Tester Name:	jrr
Test Host:	pN100919
Test Date:	Thu Aug 21 13:55:47 EDT 2014
Device:	Samsung GalaxyS3
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Aug 21 13:55:47 EDT 2014 Acquisition finished: Thu Aug 21 15:48:05 EDT 2014 UICC connectivity was established via supported interface
Results:	

Test Case MDT-07 Access Data MPE+ v5.5.2.60		
	Assertion & Expected Result	Actual Result
	MDT-AO-01 UICC connectivity via supported interfaces.	as expected
Analysis:	Expected results achieved	

50

51 1.2.17 MDT-08 – Samsung Galaxy S3 (GSM)

Test Case MDT-08 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-08 Begin UICC acquisition and interrupt connectivity by interface disengagement.					
Assertions:	MDT-AO-02 If a mobile device forensic tool loses connectivity with the UICC reader then the tool shall notify the user that connectivity has been disrupted.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Thu Aug 21 13:57:32 EDT 2014					
Device:	Samsung GalaxyS3					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB					
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Aug 21 13:57:32 EDT 2014 Acquisition finished: Thu Aug 21 15:48:36 EDT 2014</p> <p>Media acquisition disruption notification was not successful</p> <p>Notes: No error message when disrupting connectivity, it stopped and reported the data recovered until connectivity was disrupted.</p>					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-02 Notification of SIM acquisition disruption.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-02 Notification of SIM acquisition disruption.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-AO-02 Notification of SIM acquisition disruption.	Not as expected					
Analysis:	Expected results not achieved					

52

53 1.2.18 MDT-09 – Samsung Galaxy S3 (GSM)

Test Case MDT-09 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-09Acquire UICC memory and review reported subscriber and equipment related information (i.e., SPN, ICCID, IMSI, MSISDN).	
Assertions:	MDT-AO-03 If a mobile device forensic tool completes acquisition of the target UICC without error then the subscriber and equipment related data shall be presented in a useable format.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Thu Aug 21 13:58:32 EDT 2014	
Device:	Samsung GalaxyS3	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB	
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Aug 21 13:58:32 EDT 2014 Acquisition finished: Thu Aug 21 15:54:51 EDT 2014</p> <p>SPN was not acquired ICCID was acquired IMSI was acquired MSISDN was acquired</p>	
Results:		

Test Case MDT-09 Access Data MPE+ v5.5.2.60		
	Assertion & Expected Result	Actual Result
	MDT-AO-03 Acquisition of UICC subscriber and equipment related data in a useable format.	Not as expected
Analysis:	Partial results not achieved	

54

55 1.2.19 MDT-10 – Samsung Galaxy S3 (GSM)

Test Case MDT-10 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-10 Acquire UICC memory and review supported data elements (i.e., Abbreviated Dialing Numbers, Last Numbers Dialed, SMS/EMS text messages, and location related data: LOCI, GPRSLOCI).					
Assertions:	MDT-AO-04 If a mobile device forensic tool completes acquisition of the target UICC without error then all acquired data shall be presented in a useable format.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Thu Aug 21 13:59:24 EDT 2014					
Device:	Samsung GalaxyS3					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB					
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Aug 21 13:59:24 EDT 2014 Acquisition finished: Thu Aug 21 15:55:17 EDT 2014</p> <p>All ADNs were acquired LNDs were acquired Date/Time Stamps correctly reported for LNDs ALL text messages (SMS, EMS) were acquired All date/time stamps were reported for text messages Correct status flags were reported for text messages Sender and Recipient phone numbers associated with text messages were correctly reported Deleted text message data was recovered LOCI data was acquired GPRSLOCI data was acquired</p> <p>Notes: French contact entry was incorrectly reported as Aur[0x05]lien instead of Aurélien.</p>					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-04 Acquisition of all UICC supported data elements in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-04 Acquisition of all UICC supported data elements in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-AO-04 Acquisition of all UICC supported data elements in a useable format.	Not as expected					
Analysis:	Partial results achieved					

56

57 1.2.20 MDT-11 – Samsung Galaxy S3 (GSM)

Test Case MDT-11 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-11 Acquire UICC memory by selecting a combination of supported data elements.
Assertions:	MDT-AO-05 If a mobile device forensic tool provides the user with an Acquire All UICC data objects acquisition option then the tool shall complete the acquisition of all data objects without error. MDT-AO-06 If a mobile device forensic tool provides the user with an Select All individual UICC data objects then the tool shall complete the acquisition of all individually selected data objects without error. MDT-AO-07 If a mobile device forensic tool provides the user with the

Test Case MDT-11 Access Data MPE+ v5.5.2.60									
	ability to Select Individual UICC data objects for acquisition then the tool shall acquire each exclusive data object without error.								
Tester Name:	jrr								
Test Host:	pN100919								
Test Date:	Thu Aug 21 14:00:00 EDT 2014								
Device:	Samsung_GalaxyS3								
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB								
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Aug 21 14:00:00 EDT 2014 Acquisition finished: Thu Aug 21 15:57:02 EDT 2014 Acquire All acquisition was successful Select All acquisition was successful Individual data element acquisition was successful								
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-AO-05 Acquire-all UICC data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-AO-06 Select-all UICC data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-AO-07 Select-individual UICC data objects acquisition.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-AO-05 Acquire-all UICC data objects acquisition.	as expected	MDT-AO-06 Select-all UICC data objects acquisition.	as expected	MDT-AO-07 Select-individual UICC data objects acquisition.	as expected
Assertion & Expected Result	Actual Result								
MDT-AO-05 Acquire-all UICC data objects acquisition.	as expected								
MDT-AO-06 Select-all UICC data objects acquisition.	as expected								
MDT-AO-07 Select-individual UICC data objects acquisition.	as expected								
Analysis:	Expected results achieved								

58

59 1.2.21 MDT-12 – Samsung Galaxy S3 (GSM)

Test Case MDT-12 Access Data MPE+ v5.5.2.60					
Case Summary:	MDT-12 After a successful mobile device internal memory, alter the case file via third-party means and attempt to re-open the case.				
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.				
Tester Name:	jrr				
Test Host:	pN100919				
Test Date:	Tue Aug 19 15:00:33 EDT 2014				
Device:	Samsung_GalaxyS3				
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable				
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Aug 19 15:00:33 EDT 2014 Acquisition finished: Thu Aug 21 12:07:14 EDT 2014 Notification of modified device memory data was successful Notes: Case file data can be modified without warning when re-opening the test case. However, when the test case is re-opened the original data is reported.				
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-AO-08 Notification of modified device case data.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-AO-08 Notification of modified device case data.	as expected
Assertion & Expected Result	Actual Result				
MDT-AO-08 Notification of modified device case data.	as expected				
Analysis:	Expected results achieved				

60

61

62 1.2.22 MDT-13 – Samsung Galaxy S3 (GSM)

Test Case MDT-13 Access Data MPE+ v5.5.2.60					
Case Summary:	MDT-13 After a successful UICC acquisition, alter the case file via third-party means and attempt to re-open the case.				
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.				
Tester Name:	jrr				
Test Host:	pN100919				
Test Date:	Thu Aug 21 14:00:42 EDT 2014				
Device:	Samsung_GalaxyS3				
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB				
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Aug 21 14:00:42 EDT 2014 Acquisition finished: Thu Aug 21 15:57:35 EDT 2014</p> <p>Notification of modified SIM data was successful</p> <p>Notes: Case file data can be modified without warning when re-opening the test case. However, when the test case is re-opened only the device information data is reported. Tool only gives warning when the case size changes.</p>				
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-AO-08 Notification of modified device case data.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-AO-08 Notification of modified device case data.	as expected
Assertion & Expected Result	Actual Result				
MDT-AO-08 Notification of modified device case data.	as expected				
Analysis:	Expected results achieved				

63

64 1.2.23 MDT-14 – Samsung Galaxy S3 (GSM)

Test Case MDT-14 Access Data MPE+ v5.5.2.60					
Case Summary:	MDT-14 Attempt acquisition of a password-protected UICC.				
Assertions:	MDT-AO-09 If the UICC is password-protected then the mobile device forensic tool shall provide the examiner with the opportunity to input the PIN before acquisition.				
Tester Name:	jrr				
Test Host:	pN100919				
Test Date:	Thu Aug 21 14:01:21 EDT 2014				
Device:	Samsung_GalaxyS3				
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB				
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Aug 21 14:01:21 EDT 2014 Acquisition finished: Thu Aug 21 16:09:02 EDT 2014</p> <p>Ability to enter PIN on protected media before acquisition was successful</p>				
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-AO-09 Acquisition of password protected UICC.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-AO-09 Acquisition of password protected UICC.	as expected
Assertion & Expected Result	Actual Result				
MDT-AO-09 Acquisition of password protected UICC.	as expected				
Analysis:	Expected results achieved				

65

66

67

68 **1.2.24 MDT-15 – Samsung Galaxy S3 (GSM)**

Test Case MDT-15 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-15 Begin acquisition on a PIN protected UICC to determine if the tool provides an accurate count of the remaining number of PIN attempts and if the PIN attempts are decremented when entering an incorrect value.					
Assertions:	MDT-AO-10 If a mobile device forensic tool provides the examiner with the remaining number of authentication attempts then the application should provide an accurate count of the remaining PIN attempts.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Thu Aug 21 14:02:18 EDT 2014					
Device:	Samsung GalaxyS3					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Aug 21 14:02:18 EDT 2014 Acquisition finished: Thu Aug 21 16:09:43 EDT 2014 The remaining number of PIN attempts were properly displayed					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-10 Remaining number of PIN attempts properly displayed.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-10 Remaining number of PIN attempts properly displayed.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-10 Remaining number of PIN attempts properly displayed.	as expected					
Analysis:	Expected results achieved					

69

70 **1.2.25 MDT-16 – Samsung Galaxy S3 (GSM)**

Test Case MDT-16 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-16 Begin acquisition on a UICC whose PIN attempts have been exhausted to determine if the tool provides an accurate count of the remaining number of PUK attempts and if the PUK attempts are decremented when entering an incorrect value.					
Assertions:	MDT-AO-11 If a mobile device forensic tool provides the examiner with the remaining number of PUK attempts then the application should provide an accurate count of the remaining PUK attempts.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Fri Sep 5 14:37:40 EDT 2014					
Device:	SamsungGalaxyS3 GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Sep 5 14:37:40 EDT 2014 Acquisition finished: Fri Sep 5 15:37:00 EDT 2014 Remaining number of PUK attempts were properly displayed					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-11 Remaining number of PUK attempts properly displayed.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-11 Remaining number of PUK attempts properly displayed.	as expected
	Assertion & Expected Result	Actual Result				
MDT-AO-11 Remaining number of PUK attempts properly displayed.	as expected					
Analysis:	Expected results achieved					

71

72 1.2.26 MDT-19 – Samsung Galaxy S3 (GSM)

Test Case MDT-19 Access Data MPE+ v5.5.2.60					
Case Summary:	MDT-19 Acquire mobile device internal memory and review data containing non-ASCII characters.				
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.				
Tester Name:	jrr				
Test Host:	PN100919				
Test Date:	Tue Aug 19 15:01:03 EDT 2014				
Device:	Samsung_GalaxyS3				
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable				
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Aug 19 15:01:03 EDT 2014 Acquisition finished: Thu Aug 21 12:12:15 EDT 2014 Non-ASCII Address book entries were acquired and properly displayed Non-ASCII text messages were acquired and properly displayed				
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected
Assertion & Expected Result	Actual Result				
MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected				
Analysis:	Expected results achieved				

73

74 1.2.27 MDT-20 – Samsung Galaxy S3 (GSM)

Test Case MDT-20 Access Data MPE+ v5.5.2.60					
Case Summary:	MDT-20 Acquire UICC memory and review data containing non-ASCII characters.				
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.				
Tester Name:	jrr				
Test Host:	PN100919				
Test Date:	Thu Aug 21 14:03:27 EDT 2014				
Device:	Samsung_GalaxyS3				
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB				
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Aug 21 14:03:27 EDT 2014 Acquisition finished: Thu Aug 21 16:10:26 EDT 2014 Non-ASCII ADNs were acquired and properly displayed Non-ASCII text messages were acquired and properly displayed				
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected
Assertion & Expected Result	Actual Result				
MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected				
Analysis:	Expected results achieved				

75

76

77 1.2.28 MDT-22 – Samsung Galaxy S3 (GSM)

Test Case MDT-22 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-22 Acquire mobile device internal memory and review hash values for vendor supported data objects.					
Assertions:	MDT-AO-15 If the mobile device forensic tool supports hashing for individual data objects then the tool shall present the user with a hash value for each supported data object.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Tue Aug 19 15:01:36 EDT 2014					
Device:	Samsung GalaxyS3					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Aug 19 15:01:36 EDT 2014 Acquisition finished: Thu Aug 21 12:12:42 EDT 2014 Hash values were properly reported for individually acquired device data elements					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-15 Hash values for individual data and case presented in a useable format.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-15 Hash values for individual data and case presented in a useable format.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-15 Hash values for individual data and case presented in a useable format.	as expected					
Analysis:	Expected results achieved					

78

79 1.2.29 MDT-01 – Samsung Galaxy S4 (GSM)

Test Case MDT-01 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-01 Acquire mobile device internal memory over tool-supported interfaces (e.g., cable, Bluetooth, IrDA).					
Assertions:	MDT-CA-01 If a mobile device forensic tool provides support for connectivity of the target device then the tool shall successfully recognize the target device via all vendor supported interfaces (e.g., cable, Bluetooth, IrDA).					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Tue Aug 26 10:57:21 EDT 2014					
Device:	SamsungGalaxyS4					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Aug 26 10:57:21 EDT 2014 Acquisition finished: Tue Aug 26 15:52:13 EDT 2014 Device connectivity was established via supported interface					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-01 Device connectivity via supported interfaces.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-01 Device connectivity via supported interfaces.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-01 Device connectivity via supported interfaces.	as expected					
Analysis:	Expected results achieved					

80

81 1.2.30 MDT-02 – Samsung Galaxy S4 (GSM)

Test Case MDT-02 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-02 Begin mobile device internal memory acquisition and interrupt connectivity by interface disengagement.

Test Case MDT-02 Access Data MPE+ v5.5.2.60						
Assertions:	MDT-CA-02 If connectivity between the mobile device and mobile device forensic tool is disrupted then the tool shall notify the user that connectivity has been disrupted.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Thu Aug 28 16:03:53 EDT 2014					
Device:	SamsungGalaxy_S4					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Aug 28 16:03:53 EDT 2014 Acquisition finished: Fri Aug 29 11:15:24 EDT 2014 Device acquisition disruption notification was successful					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-02 Notification of device acquisition disruption.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-02 Notification of device acquisition disruption.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-02 Notification of device acquisition disruption.	as expected					
Analysis:	Expected results achieved					

82

83 1.2.31 MDT-03 – Samsung Galaxy S4 (GSM)

Test Case MDT-03 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-03 Acquire mobile device internal memory and review reported data via the preview-pane or generated reports for readability.					
Assertions:	MDT-CA-03 If a mobile device forensic tool completes acquisition of the target device without error then the tool shall have the ability to present acquired data objects in a useable format via either a preview-pane or generated report.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Thu Aug 28 16:06:34 EDT 2014					
Device:	SamsungGalaxyS4 GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Aug 28 16:06:34 EDT 2014 Acquisition finished: Fri Aug 29 11:15:51 EDT 2014 Readability and completeness of acquired data was successful					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-03 Readability and completeness of acquired data via supported reports.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-03 Readability and completeness of acquired data via supported reports.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-03 Readability and completeness of acquired data via supported reports.	as expected					
Analysis:	Expected results achieved					

84

85 1.2.32 MDT-04 – Samsung Galaxy S4 (GSM)

Test Case MDT-04 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-04 Acquire mobile device internal memory and review reported subscriber and equipment related information (e.g., IMSI, IMEI, MEID/ESN, MSISDN).	
Assertions:	MDT-CA-04 If a mobile device forensic tool completes acquisition of the target device without error then subscriber and equipment related information shall be presented in a useable format.	

Test Case MDT-04 Access Data MPE+ v5.5.2.60						
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Thu Aug 28 16:07:11 EDT 2014					
Device:	SamsungGalaxyS4 GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Aug 28 16:07:11 EDT 2014 Acquisition finished: Fri Aug 29 11:16:11 EDT 2014 MEID/ESN was acquired Notes: The MSISDN was not reported.					
Results:	<table><tr><td>Assertion & Expected Result</td><td>Actual Result</td></tr><tr><td>MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected					
Analysis:	Partial results achieved					

86

87 1.2.33 MDT-05 – Samsung Galaxy S4 (GSM)

Test Case MDT-05 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-05 Acquire mobile device internal memory and review supported data elements (i.e., PIM data, call logs, SMS, MMS, stand-alone files: audio, pictures, video, application related data: documents, spreadsheets, presentations, social-media data and Internet related data: bookmarks, visited sites).	
Assertions:	MDT-CA-05 If a mobile device forensic tool completes acquisition of the target device without error then all supported data elements shall be presented in a useable format.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Thu Aug 28 16:08:03 EDT 2014	
Device:	SamsungGalaxyS4 GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Aug 28 16:08:03 EDT 2014 Acquisition finished: Fri Aug 29 11:18:54 EDT 2014</p> <p>All address book entries were successfully acquired ALL PIM related data was acquired All Call Logs (incoming, outgoing, missed) were acquired All Call Log date/time stamps data were correctly reported ALL text messages (SMS, EMS) were acquired Correct date/time stamps were reported for all text messages Correct status flags were reported for all text messages Sender and Recipient phone numbers associated with text messages were correctly reported ALL MMS messages (Audio, Image, Video) were acquired ALL stand-alone data files (Audio, Image, Video) were acquired Application data was not acquired All Internet related data was acquired All Social media related data was acquired</p> <p>Notes: Graphic files associated with contact entries were not acquired.</p>	
Results:		

Test Case MDT-05 Access Data MPE+ v5.5.2.60		
	Assertion & Expected Result	Actual Result
	MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Not as expected
Analysis:	Partial results achieved	

88

89 1.2.34 MDT-06 – Samsung Galaxy S4 (GSM)

Test Case MDT-06 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-06 Acquire mobile device internal memory by selecting a combination of supported data elements.	
Assertions:	<p>MDT-CA-06 If a mobile device forensic tool provides the user with an Acquire All device data objects acquisition option then the tool shall complete the acquisition of all data objects without error.</p> <p>MDT-CA-07 If a mobile device forensic tool provides the user with an Select All individual device data objects then the tool shall complete the acquisition of all individually selected data objects without error.</p> <p>MDT-CA-08 If a mobile device forensic tool provides the user with the ability to Select Individual device data objects for acquisition then the tool shall acquire each exclusive data object without error.</p> <p>MDT-CA-09 If a mobile device forensic tool completes two consecutive logical acquisitions of the target device without error then the payload (data objects) on the mobile device shall remain consistent.</p>	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Thu Aug 28 16:08:42 EDT 2014	
Device:	SamsungGalaxyS4_GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Aug 28 16:08:42 EDT 2014 Acquisition finished: Fri Aug 29 11:21:43 EDT 2014</p> <p>Acquire All acquisition was successful</p> <p>Select All acquisition was successful</p> <p>Individual data element acquisition was successful</p>	
Results:	Assertion & Expected Result	
	MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected
	MDT-CA-07 Select-all mobile device data objects acquisition.	as expected
	MDT-CA-08 Select-individual mobile device data objects acquisition.	as expected
	MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected
Analysis:	Expected results achieved	

90

91 1.2.35 MDT-07 – Samsung Galaxy S4 (GSM)

Test Case MDT-07 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-07 Acquire UICC memory over supported interfaces (e.g., PC/SC reader).
Assertions:	MDT-AO-01 If a mobile device forensic tool provides support for connectivity of the target UICC then the tool shall successfully recognize the target SIM via all tool-supported interfaces (e.g., PC/SC reader,

Test Case MDT-07 Access Data MPE+ v5.5.2.60						
	proprietary reader, smart phone itself).					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Fri Aug 29 11:25:29 EDT 2014					
Device:	SamsungGalaxyS4 GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Aug 29 11:25:29 EDT 2014 Acquisition finished: Tue Sep 2 14:11:25 EDT 2014 UICC connectivity was established via supported interface					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-01 UICC connectivity via supported interfaces.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-01 UICC connectivity via supported interfaces.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-01 UICC connectivity via supported interfaces.	as expected					
Analysis:	Expected results achieved					

92

93 1.2.36 MDT-08 – Samsung Galaxy S4 (GSM)

Test Case MDT-08 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-08 Begin UICC acquisition and interrupt connectivity by interface disengagement.					
Assertions:	MDT-AO-02 If a mobile device forensic tool loses connectivity with the UICC reader then the tool shall notify the user that connectivity has been disrupted.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Fri Aug 29 11:26:14 EDT 2014					
Device:	SamsungGalaxyS4 GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Aug 29 11:26:14 EDT 2014 Acquisition finished: Tue Sep 2 14:11:46 EDT 2014 Media acquisition disruption notification was not successful Notes: No error message when disrupting connectivity, it stopped and reported the data recovered until connectivity was disrupted.					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-02 Notification of SIM acquisition disruption.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-02 Notification of SIM acquisition disruption.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-AO-02 Notification of SIM acquisition disruption.	Not as expected					
Analysis:	Expected results not achieved					

94 1.2.37 MDT-09 – Samsung Galaxy S4 (GSM)

Test Case MDT-09 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-09Acquire UICC memory and review reported subscriber and equipment related information (i.e., SPN, ICCID, IMSI, MSISDN).	
Assertions:	MDT-AO-03 If a mobile device forensic tool completes acquisition of the target UICC without error then the subscriber and equipment related data shall be presented in a useable format.	
Tester Name:	jrr	
Test Host:	pN100919	

Test Case MDT-09 Access Data MPE+ v5.5.2.60						
Test Date:	Fri Aug 29 11:26:56 EDT 2014					
Device:	SamsungGalaxyS4_GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Aug 29 11:26:56 EDT 2014 Acquisition finished: Tue Sep 2 14:13:22 EDT 2014 SPN was not acquired ICCID was acquired IMSI was acquired MSISDN was acquired					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-03 Acquisition of UICC subscriber and equipment related data in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-03 Acquisition of UICC subscriber and equipment related data in a useable format.	Not as expected
	Assertion & Expected Result	Actual Result				
MDT-AO-03 Acquisition of UICC subscriber and equipment related data in a useable format.	Not as expected					
Analysis:	Partial results not achieved					

95

96 1.2.38 MDT-10 – Samsung Galaxy S4 (GSM)

Test Case MDT-10 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-10 Acquire UICC memory and review supported data elements (i.e., Abbreviated Dialing Numbers, Last Numbers Dialed, SMS/EMS text messages, and location related data: LOCI, GPRSLOCI).					
Assertions:	MDT-AO-04 If a mobile device forensic tool completes acquisition of the target UICC without error then all acquired data shall be presented in a useable format.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Fri Aug 29 11:27:39 EDT 2014					
Device:	SamsungGalaxyS4_GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB					
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Aug 29 11:27:39 EDT 2014 Acquisition finished: Tue Sep 2 14:13:46 EDT 2014</p> <p>All ADNs were acquired LNDs were acquired Date/Time Stamps correctly reported for LNDs ALL text messages (SMS, EMS) were acquired All date/time stamps were reported for text messages Correct status flags were reported for text messages Sender and Recipient phone numbers associated with text messages were correctly reported Deleted text message data was recovered LOCI data was acquired GPRSLOCI data was acquired</p> <p>Notes: French contact entry was incorrectly reported as Aur[0x05]lien instead of Aurélien.</p>					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-04 Acquisition f all UICC supported data elements in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-04 Acquisition f all UICC supported data elements in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-AO-04 Acquisition f all UICC supported data elements in a useable format.	Not as expected					
Analysis:	Partial results achieved					

97 **1.2.39 MDT-11 – Samsung Galaxy S4 (GSM)**

Test Case MDT-11 Access Data MPE+ v5.5.2.60										
Case Summary:	MDT-11 Acquire UICC memory by selecting a combination of supported data elements.									
Assertions:	MDT-AO-05 If a mobile device forensic tool provides the user with an Acquire All UICC data objects acquisition option then the tool shall complete the acquisition of all data objects without error. MDT-AO-06 If a mobile device forensic tool provides the user with an Select All individual UICC data objects then the tool shall complete the acquisition of all individually selected data objects without error. MDT-AO-07 If a mobile device forensic tool provides the user with the ability to Select Individual UICC data objects for acquisition then the tool shall acquire each exclusive data object without error.									
Tester Name:	jrr									
Test Host:	pN100919									
Test Date:	Fri Aug 29 11:28:13 EDT 2014									
Device:	SamsungGalaxyS4 GSM									
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB									
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Aug 29 11:28:13 EDT 2014 Acquisition finished: Tue Sep 2 14:15:47 EDT 2014 Acquire All acquisition was successful Select All acquisition was successful Individual data element acquisition was successful									
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-05 Acquire-all UICC data objects acquisition.</td><td>as expected</td></tr><tr><td>MDT-AO-06 Select-all UICC data objects acquisition.</td><td>as expected</td></tr><tr><td>MDT-AO-07 Select-individual UICC data objects acquisition.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-05 Acquire-all UICC data objects acquisition.	as expected	MDT-AO-06 Select-all UICC data objects acquisition.	as expected	MDT-AO-07 Select-individual UICC data objects acquisition.	as expected
Assertion & Expected Result	Actual Result									
MDT-AO-05 Acquire-all UICC data objects acquisition.	as expected									
MDT-AO-06 Select-all UICC data objects acquisition.	as expected									
MDT-AO-07 Select-individual UICC data objects acquisition.	as expected									
Analysis:	Expected results achieved									

98

99 **1.2.40 MDT-12 – Samsung Galaxy S4 (GSM)**

Test Case MDT-12 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-12 After a successful mobile device internal memory, alter the case file via third-party means and attempt to re-open the case.	
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Thu Aug 28 16:09:16 EDT 2014	
Device:	SamsungGalaxyS4 GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Aug 28 16:09:16 EDT 2014 Acquisition finished: Fri Aug 29 11:22:17 EDT 2014</p> <p>Notification of modified device memory data was successful</p> <p>Notes: Case file data can be modified without warning when re-opening the test case. However, when the test case is re-opened the original data is reported.</p>	
Results:		

Test Case MDT-12 Access Data MPE+ v5.5.2.60		
	Assertion & Expected Result	Actual Result
	MDT-AO-08 Notification of modified device case data.	as expected
Analysis:	Expected results achieved	

100

101 1.2.41 MDT-13 – Samsung Galaxy S4 (GSM)

Test Case MDT-13 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-13 After a successful UICC acquisition, alter the case file via third-party means and attempt to re-open the case.	
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Fri Aug 29 11:29:58 EDT 2014	
Device:	SamsungGalaxyS4_GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB	
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Aug 29 11:29:58 EDT 2014 Acquisition finished: Tue Sep 2 14:16:17 EDT 2014</p> <p>Notification of modified SIM data was successful</p> <p>Notes: Case file data can be modified without warning when re-opening the test case. However, when the case is re-opened the original data is reported. Tool only gives warning when file size changes.</p>	
Results:	Assertion & Expected Result	Actual Result
	MDT-AO-08 Notification of modified device case data.	as expected
Analysis:	Expected results achieved	

102

103 1.2.42 MDT-14 – Samsung Galaxy S4 (GSM)

Test Case MDT-14 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-14 Attempt acquisition of a password-protected UICC.	
Assertions:	MDT-AO-09 If the UICC is password-protected then the mobile device forensic tool shall provide the examiner with the opportunity to input the PIN before acquisition.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Fri Aug 29 11:30:46 EDT 2014	
Device:	SamsungGalaxyS4_GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB	
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Aug 29 11:30:46 EDT 2014 Acquisition finished: Tue Sep 2 14:18:23 EDT 2014</p> <p>Ability to enter PIN on protected media before acquisition was successful</p>	
Results:	Assertion & Expected Result	Actual Result
	MDT-AO-09 Acquisition of password protected UICC.	as expected

Test Case MDT-14 Access Data MPE+ v5.5.2.60	
Analysis:	Expected results achieved

1.2.43 MDT-15 – Samsung Galaxy S4 (GSM)

Test Case MDT-15 Access Data MPE+ v5.5.2.60					
Case Summary:	MDT-15 Begin acquisition on a PIN protected UICC to determine if the tool provides an accurate count of the remaining number of PIN attempts and if the PIN attempts are decremented when entering an incorrect value.				
Assertions:	MDT-AO-10 If a mobile device forensic tool provides the examiner with the remaining number of authentication attempts then the application should provide an accurate count of the remaining PIN attempts.				
Tester Name:	jrr				
Test Host:	pN100919				
Test Date:	Fri Aug 29 11:31:20 EDT 2014				
Device:	SamsungGalaxyS4_GSM				
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB				
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Aug 29 11:31:20 EDT 2014 Acquisition finished: Tue Sep 2 14:18:46 EDT 2014 The remaining number of PIN attempts were properly displayed				
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-AO-10 Remaining number of PIN attempts properly displayed.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-AO-10 Remaining number of PIN attempts properly displayed.	as expected
Assertion & Expected Result	Actual Result				
MDT-AO-10 Remaining number of PIN attempts properly displayed.	as expected				
Analysis:	Expected results achieved				

1.2.44 MDT-16 – Samsung Galaxy S4 (GSM)

Test Case MDT-16 Access Data MPE+ v5.5.2.60					
Case Summary:	MDT-16 Begin acquisition on a UICC whose PIN attempts have been exhausted to determine if the tool provides an accurate count of the remaining number of PUK attempts and if the PUK attempts are decremented when entering an incorrect value.				
Assertions:	MDT-AO-11 If a mobile device forensic tool provides the examiner with the remaining number of PUK attempts then the application should provide an accurate count of the remaining PUK attempts.				
Tester Name:	jrr				
Test Host:	pN100919				
Test Date:	Fri Sep 5 14:50:13 EDT 2014				
Device:	SamsungGalaxyS4_GSM				
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB				
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Sep 5 14:50:13 EDT 2014 Acquisition finished: Fri Sep 5 15:46:36 EDT 2014 Remaining number of PUK attempts were properly displayed				
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-AO-11 Remaining number of PUK attempts properly displayed.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-AO-11 Remaining number of PUK attempts properly displayed.	as expected
Assertion & Expected Result	Actual Result				
MDT-AO-11 Remaining number of PUK attempts properly displayed.	as expected				

Test Case MDT-16 Access Data MPE+ v5.5.2.60	
Analysis:	Expected results achieved

108

109 1.2.45 MDT-19 – Samsung Galaxy S4 (GSM)

Test Case MDT-19 Access Data MPE+ v5.5.2.60					
Case Summary:	MDT-19 Acquire mobile device internal memory and review data containing non-ASCII characters.				
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.				
Tester Name:	jrr				
Test Host:	pN100919				
Test Date:	Thu Aug 28 16:09:49 EDT 2014				
Device:	SamsungGalaxyS4 GSM				
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable				
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Aug 28 16:09:49 EDT 2014 Acquisition finished: Fri Aug 29 11:23:53 EDT 2014 Non-ASCII Address book entries were acquired and properly displayed Non-ASCII text messages were acquired and properly displayed				
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected
Assertion & Expected Result	Actual Result				
MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected				
Analysis:	Expected results achieved				

110

111 1.2.46 MDT-20 – Samsung Galaxy S4 (GSM)

Test Case MDT-20 Access Data MPE+ v5.5.2.60					
Case Summary:	MDT-20 Acquire UICC memory and review data containing non-ASCII characters.				
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.				
Tester Name:	jrr				
Test Host:	pN100919				
Test Date:	Fri Aug 29 11:32:38 EDT 2014				
Device:	SamsungGalaxyS4 GSM				
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB				
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Aug 29 11:32:38 EDT 2014 Acquisition finished: Tue Sep 2 14:19:07 EDT 2014 Non-ASCII ADNs were acquired and properly displayed Non-ASCII text messages were acquired and properly displayed				
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected
Assertion & Expected Result	Actual Result				
MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected				
Analysis:	Expected results achieved				

112 1.2.47 MDT-22 – Samsung Galaxy S4 (GSM)

Test Case MDT-22 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-22 Acquire mobile device internal memory and review hash values for vendor supported data objects.					
Assertions:	MDT-AO-15 If the mobile device forensic tool supports hashing for individual data objects then the tool shall present the user with a hash value for each supported data object.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Thu Aug 28 16:10:24 EDT 2014					
Device:	SamsungGalaxyS4_GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Aug 28 16:10:24 EDT 2014 Acquisition finished: Fri Aug 29 11:24:19 EDT 2014 Hash values were properly reported for individually acquired device data elements					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-15 Hash values for individual data and case presented in a useable format.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-15 Hash values for individual data and case presented in a useable format.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-15 Hash values for individual data and case presented in a useable format.	as expected					
Analysis:	Expected results achieved					

113

114 1.2.48 MDT-01 – Samsung Galaxy S5 (CDMA)

Test Case MDT-01 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-01 Acquire mobile device internal memory over tool-supported interfaces (e.g., cable, Bluetooth, IrDA).					
Assertions:	MDT-CA-01 If a mobile device forensic tool provides support for connectivity of the target device then the tool shall successfully recognize the target device via all vendor supported interfaces (e.g., cable, Bluetooth, IrDA).					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Thu Jul 24 13:44:14 EDT 2014					
Device:	Samsung GalaxyS5					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Jul 24 13:44:14 EDT 2014 Acquisition finished: Thu Jul 24 13:59:53 EDT 2014 Device connectivity was established via supported interface					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-01 Device connectivity via supported interfaces.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-01 Device connectivity via supported interfaces.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-01 Device connectivity via supported interfaces.	as expected					
Analysis:	Expected results achieved					

115 1.2.49 MDT-02- Samsung Galaxy S5 (CDMA)

Test Case MDT-02 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-02 Begin mobile device internal memory acquisition and interrupt connectivity by interface disengagement.
Assertions:	MDT-CA-02 If connectivity between the mobile device and mobile device forensic tool is disrupted then the tool shall notify the user that

Test Case MDT-02 Access Data MPE+ v5.5.2.60						
	connectivity has been disrupted.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Thu Jul 24 14:00:38 EDT 2014					
Device:	Samsung GalaxyS5					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Jul 24 14:00:38 EDT 2014 Acquisition finished: Thu Jul 24 14:19:09 EDT 2014 Device acquisition disruption notification was successful					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-02 Notification of device acquisition disruption.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-02 Notification of device acquisition disruption.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-02 Notification of device acquisition disruption.	as expected					
Analysis:	Expected results achieved					

116

117 1.2.50 MDT-03 – Samsung Galaxy S5 (CDMA)

Test Case MDT-03 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-03 Acquire mobile device internal memory and review reported data via the preview-pane or generated reports for readability.					
Assertions:	MDT-CA-03 If a mobile device forensic tool completes acquisition of the target device without error then the tool shall have the ability to present acquired data objects in a useable format via either a preview-pane or generated report.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Thu Jul 24 14:25:49 EDT 2014					
Device:	Samsung GalaxyS5					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Jul 24 14:25:49 EDT 2014 Acquisition finished: Fri Jul 25 12:01:52 EDT 2014 Readability and completeness of acquired data was successful					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-03 Readability and completeness of acquired data via supported reports.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-03 Readability and completeness of acquired data via supported reports.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-03 Readability and completeness of acquired data via supported reports.	as expected					
Analysis:	Expected results achieved					

118

119 1.2.51 MDT-04 – Samsung Galaxy S5 (CDMA)

Test Case MDT-04 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-04 Acquire mobile device internal memory and review reported subscriber and equipment related information (e.g., IMSI, IMEI, MEID/ESN, MSISDN).	
Assertions:	MDT-CA-04 If a mobile device forensic tool completes acquisition of the target device without error then subscriber and equipment related information shall be presented in a useable format.	
Tester Name:	jrr	
Test Host:	pN100919	

Test Case MDT-04 Access Data MPE+ v5.5.2.60						
Test Date:	Fri Jul 25 12:02:31 EDT 2014					
Device:	Samsung_GalaxyS5					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Jul 25 12:02:31 EDT 2014 Acquisition finished: Fri Jul 25 12:06:12 EDT 2014 MEID/ESN was acquired Notes: The MSISDN was not reported.					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected					
Analysis:	Partial results achieved					

120

121 1.2.52 MDT-05 – Samsung Galaxy S5 (CDMA)

Test Case MDT-05 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-05 Acquire mobile device internal memory and review supported data elements (i.e., PIM data, call logs, SMS, MMS, stand-alone files: audio, pictures, video, application related data: documents, spreadsheets, presentations, social-media data and Internet related data: bookmarks, visited sites).					
Assertions:	MDT-CA-05 If a mobile device forensic tool completes acquisition of the target device without error then all supported data elements shall be presented in a useable format.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Fri Jul 25 12:08:28 EDT 2014					
Device:	Samsung GalaxyS5					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Jul 25 12:08:28 EDT 2014 Acquisition finished: Fri Jul 25 15:06:19 EDT 2014</p> <p>All address book entries were successfully acquired ALL PIM related data was acquired All Call Logs (incoming, outgoing, missed) were acquired All Call Log date/time stamps data were correctly reported ALL text messages (SMS, EMS) were acquired Correct date/time stamps were reported for all text messages Correct status flags were reported for all text messages Sender and Recipient phone numbers associated with text messages were correctly reported ALL MMS messages (Audio, Image, Video) were acquired ALL stand-alone data files (Audio, Image, Video) were acquired Application data was not acquired All Internet related data was acquired All Social media related data was acquired</p> <p>Notes: Graphic files associated with contact entries were not acquired.</p>					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-05 Acquisition of all mobile device supported data</td><td>Not as</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-05 Acquisition of all mobile device supported data	Not as
Assertion & Expected Result	Actual Result					
MDT-CA-05 Acquisition of all mobile device supported data	Not as					

Test Case MDT-05 Access Data MPE+ v5.5.2.60		
	elements in a useable format.	expected
Analysis:	Partial results not achieved	

122

123 1.2.53 MDT-06 – Samsung Galaxy S5 (CDMA)

Test Case MDT-06 Access Data MPE+ v5.5.2.60												
Case Summary:	MDT-06 Acquire mobile device internal memory by selecting a combination of supported data elements.											
Assertions:	MDT-CA-06 If a mobile device forensic tool provides the user with an Acquire All device data objects acquisition option then the tool shall complete the acquisition of all data objects without error. MDT-CA-07 If a mobile device forensic tool provides the user with an Select All individual device data objects then the tool shall complete the acquisition of all individually selected data objects without error. MDT-CA-08 If a mobile device forensic tool provides the user with the ability to Select Individual device data objects for acquisition then the tool shall acquire each exclusive data object without error. MDT-CA-09 If a mobile device forensic tool completes two consecutive logical acquisitions of the target device without error then the payload (data objects) on the mobile device shall remain consistent.											
Tester Name:	jrr											
Test Host:	pN100919											
Test Date:	Fri Jul 25 15:12:27 EDT 2014											
Device:	Samsung GalaxyS5											
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable											
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Jul 25 15:12:27 EDT 2014 Acquisition finished: Fri Jul 25 15:51:51 EDT 2014 Acquire All acquisition was successful Select All acquisition was successful Individual data element acquisition was successful											
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-06 Acquire-all mobile device data objects acquisition.</td><td>as expected</td></tr><tr><td>MDT-CA-07 Select-all mobile device data objects acquisition.</td><td>as expected</td></tr><tr><td>MDT-CA-08 Select-individual mobile device data objects acquisition.</td><td>as expected</td></tr><tr><td>MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected	MDT-CA-07 Select-all mobile device data objects acquisition.	as expected	MDT-CA-08 Select-individual mobile device data objects acquisition.	as expected	MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected
Assertion & Expected Result	Actual Result											
MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected											
MDT-CA-07 Select-all mobile device data objects acquisition.	as expected											
MDT-CA-08 Select-individual mobile device data objects acquisition.	as expected											
MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected											
Analysis:	Expected results achieved											

124

125 1.2.54 MDT-12 – Samsung Galaxy S5 (CDMA)

Test Case MDT-12 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-12 After a successful mobile device internal memory, alter the case file via third-party means and attempt to re-open the case.
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.
Tester Name:	jrr
Test Host:	pN100919

Test Case MDT-12 Access Data MPE+ v5.5.2.60						
Test Date:	Fri Jul 25 15:52:41 EDT 2014					
Device:	Samsung_GalaxyS5					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Jul 25 15:52:41 EDT 2014 Acquisition finished: Fri Jul 25 15:58:30 EDT 2014 Notification of modified device memory data was successful Notes: Case file data can be modified without warning when re-opening the test case. However, when the test case is re-opened the original data is reported.					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-08 Notification of modified device case data.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-08 Notification of modified device case data.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-08 Notification of modified device case data.	as expected					
Analysis:	Expected results achieved					

126

127 1.2.55 MDT-19 – Samsung Galaxy S5 (CDMA)

Test Case MDT-19 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-19 Acquire mobile device internal memory and review data containing non-ASCII characters.					
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Fri Jul 25 16:04:00 EDT 2014					
Device:	Samsung GalaxyS5					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Jul 25 16:04:00 EDT 2014 Acquisition finished: Fri Jul 25 16:09:51 EDT 2014 Non-ASCII Address book entries were acquired and properly displayed Non-ASCII text messages were acquired and properly displayed					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected					
Analysis:	Expected results achieved					

128

129 1.2.56 MDT-22 – Samsung Galaxy S5 (CDMA)

Test Case MDT-22 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-22 Acquire mobile device internal memory and review hash values for vendor supported data objects.	
Assertions:	MDT-AO-15 If the mobile device forensic tool supports hashing for individual data objects then the tool shall present the user with a hash value for each supported data object.	
Tester Name:	jrr	
Test Host:	pN100919	

Test Case MDT-22 Access Data MPE+ v5.5.2.60						
Test Date:	Fri Jul 25 16:10:40 EDT 2014					
Device:	Samsung_GalaxyS5					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Jul 25 16:10:40 EDT 2014 Acquisition finished: Fri Jul 25 16:12:39 EDT 2014 Hash values were properly reported for individually acquired device data elements					
Results:	<table><tr><td>Assertion & Expected Result</td><td>Actual Result</td></tr><tr><td>MDT-AO-15 Hash values for individual data and case presented in a useable format.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-15 Hash values for individual data and case presented in a useable format.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-15 Hash values for individual data and case presented in a useable format.	as expected					
Analysis:	Expected results achieved					

130

131 1.2.57 MDT-01 – HTC One (CDMA)

Test Case MDT-01 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-01 Acquire mobile device internal memory over tool-supported interfaces (e.g., cable, Bluetooth, IrDA).					
Assertions:	MDT-CA-01 If a mobile device forensic tool provides support for connectivity of the target device then the tool shall successfully recognize the target device via all vendor supported interfaces (e.g., cable, Bluetooth, IrDA).					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Wed Jul 23 14:10:44 EDT 2014					
Device:	HTCOne_CDMA					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Jul 23 14:10:44 EDT 2014 Acquisition finished: Wed Jul 23 14:14:55 EDT 2014 Device connectivity was established via supported interface					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-01 Device connectivity via supported interfaces.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-01 Device connectivity via supported interfaces.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-01 Device connectivity via supported interfaces.	as expected					
Analysis:	Expected results achieved					

132

133 1.2.58 MDT-02 – HTC One (CDMA)

Test Case MDT-02 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-02 Begin mobile device internal memory acquisition and interrupt connectivity by interface disengagement.	
Assertions:	MDT-CA-02 If connectivity between the mobile device and mobile device forensic tool is disrupted then the tool shall notify the user that connectivity has been disrupted.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Wed Jul 23 14:15:45 EDT 2014	
Device:	HTCOne_CDMA	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	

Test Case MDT-02 Access Data MPE+ v5.5.2.60						
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Jul 23 14:15:45 EDT 2014 Acquisition finished: Wed Jul 23 14:24:10 EDT 2014 Device acquisition disruption notification was successful					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-02 Notification of device acquisition disruption.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-02 Notification of device acquisition disruption.	as expected
	Assertion & Expected Result	Actual Result				
MDT-CA-02 Notification of device acquisition disruption.	as expected					
Analysis:	Expected results achieved					

134

135 1.2.59 MDT-03 – HTC One (CDMA)

Test Case MDT-03 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-03 Acquire mobile device internal memory and review reported data via the preview-pane or generated reports for readability.					
Assertions:	MDT-CA-03 If a mobile device forensic tool completes acquisition of the target device without error then the tool shall have the ability to present acquired data objects in a useable format via either a preview-pane or generated report.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Wed Jul 23 14:24:49 EDT 2014					
Device:	HTCOne CDMA					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Jul 23 14:24:49 EDT 2014 Acquisition finished: Wed Jul 23 14:56:22 EDT 2014 Readability and completeness of acquired data was successful					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-03 Readability and completeness of acquired data via supported reports.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-03 Readability and completeness of acquired data via supported reports.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-03 Readability and completeness of acquired data via supported reports.	as expected					
Analysis:	Expected results achieved					

136

137 1.2.60 MDT-04 – HTC One (CDMA)

Test Case MDT-04 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-04 Acquire mobile device internal memory and review reported subscriber and equipment related information (e.g., IMSI, IMEI, MEID/ESN, MSISDN).	
Assertions:	MDT-CA-04 If a mobile device forensic tool completes acquisition of the target device without error then subscriber and equipment related information shall be presented in a useable format.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Wed Jul 23 15:06:37 EDT 2014	
Device:	HTCOne_CDMA	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Jul 23 15:06:37 EDT 2014 Acquisition finished: Wed Jul 23 15:06:53 EDT 2014</p>	

Test Case MDT-04 Access Data MPE+ v5.5.2.60		
	MEID/ESN was acquired Notes: The MSISDN was not reported.	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected
Analysis:	Partial results achieved	

138

139 1.2.61 MDT-05 – HTC One (CDMA)

Test Case MDT-05 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-05 Acquire mobile device internal memory and review supported data elements (i.e., PIM data, call logs, SMS, MMS, stand-alone files: audio, pictures, video, application related data: documents, spreadsheets, presentations, social-media data and Internet related data: bookmarks, visited sites).					
Assertions:	MDT-CA-05 If a mobile device forensic tool completes acquisition of the target device without error then all supported data elements shall be presented in a useable format.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Wed Jul 23 15:09:36 EDT 2014					
Device:	HTCOne_CDMA					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Jul 23 15:09:36 EDT 2014 Acquisition finished: Wed Jul 23 16:23:57 EDT 2014</p> <p>All address book entries were successfully acquired ALL PIM related data was acquired All Call Logs (incoming, outgoing, missed) were acquired All Call Log date/time stamps data were correctly reported ALL text messages (SMS, EMS) were acquired Correct date/time stamps were reported for all text messages Correct status flags were reported for all text messages Sender and Recipient phone numbers associated with text messages were correctly reported Audio MMS messages were not acquired Image MMS messages were not acquired Video MMS messages were not acquired Audio files were not acquired Image files were acquired Video files were acquired Application data was not acquired All Internet related data was acquired All Social media related data was acquired</p> <p>Notes: Graphic files associated with contact entries were not acquired.</p>					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Not as expected					
Analysis:	Partial results achieved					

140

1.2.62 MDT-06 – HTC One (CDMA)

Test Case MDT-06 Access Data MPE+ v5.5.2.60											
Case Summary:	MDT-06 Acquire mobile device internal memory by selecting a combination of supported data elements.										
Assertions:	MDT-CA-06 If a mobile device forensic tool provides the user with an Acquire All device data objects acquisition option then the tool shall complete the acquisition of all data objects without error. MDT-CA-07 If a mobile device forensic tool provides the user with an Select All individual device data objects then the tool shall complete the acquisition of all individually selected data objects without error. MDT-CA-08 If a mobile device forensic tool provides the user with the ability to Select Individual device data objects for acquisition then the tool shall acquire each exclusive data object without error. MDT-CA-09 If a mobile device forensic tool completes two consecutive logical acquisitions of the target device without error then the payload (data objects) on the mobile device shall remain consistent.										
Tester Name:	jrr										
Test Host:	pN100919										
Test Date:	Thu Jul 24 10:20:11 EDT 2014										
Device:	HTCOne CDMA										
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable										
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Jul 24 10:20:11 EDT 2014 Acquisition finished: Thu Jul 24 10:20:27 EDT 2014 Acquire All acquisition was successful Select All acquisition was successful Individual data element acquisition was successful										
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-CA-06 Acquire-all mobile device data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-CA-07 Select-all mobile device data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-CA-08 Select-individual mobile device data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected	MDT-CA-07 Select-all mobile device data objects acquisition.	as expected	MDT-CA-08 Select-individual mobile device data objects acquisition.	as expected	MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected
Assertion & Expected Result	Actual Result										
MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected										
MDT-CA-07 Select-all mobile device data objects acquisition.	as expected										
MDT-CA-08 Select-individual mobile device data objects acquisition.	as expected										
MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected										
Analysis:	Expected results achieved										

141

142 **1.2.63 MDT-12 – HTC One (CDMA)**

Test Case MDT-12 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-12 After a successful mobile device internal memory, alter the case file via third-party means and attempt to re-open the case.
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.
Tester Name:	jrr
Test Host:	pN100919
Test Date:	Thu Jul 24 10:28:57 EDT 2014
Device:	HTCOne CDMA
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Jul 24 10:28:57 EDT 2014 Acquisition finished: Thu Jul 24 10:46:45 EDT 2014

Test Case MDT-12 Access Data MPE+ v5.5.2.60					
	<p>Notification of modified device memory data was successful</p> <p>Notes: Case data can be modified without warning when re-opening the test case. However, when the test case is re-opened the original data is reported.</p>				
Results:	<table> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> <tr> <td>MDT-AO-08 Notification of modified device case data.</td><td>as expected</td></tr> </table>	Assertion & Expected Result	Actual Result	MDT-AO-08 Notification of modified device case data.	as expected
Assertion & Expected Result	Actual Result				
MDT-AO-08 Notification of modified device case data.	as expected				
Analysis:	Expected results achieved				

143

144 1.2.64 MDT-19 – HTC One (CDMA)

Test Case MDT-19 Access Data MPE+ v5.5.2.60					
Case Summary:	MDT-19 Acquire mobile device internal memory and review data containing non-ASCII characters.				
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.				
Tester Name:	jrr				
Test Host:	pN100919				
Test Date:	Thu Jul 24 11:03:36 EDT 2014				
Device:	HTOne CDMA				
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable				
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Jul 24 11:03:36 EDT 2014 Acquisition finished: Thu Jul 24 11:06:14 EDT 2014</p> <p>Non-ASCII Address book entries were acquired and properly displayed Non-ASCII text messages were acquired and properly displayed</p>				
Results:	<table> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> <tr> <td>MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.</td><td>as expected</td></tr> </table>	Assertion & Expected Result	Actual Result	MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected
Assertion & Expected Result	Actual Result				
MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected				
Analysis:	Expected results achieved				

145

146 1.2.65 MDT-22 – HTC One (CDMA)

Test Case MDT-22 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-22 Acquire mobile device internal memory and review hash values for vendor supported data objects.
Assertions:	MDT-AO-15 If the mobile device forensic tool supports hashing for individual data objects then the tool shall present the user with a hash value for each supported data object.
Tester Name:	jrr
Test Host:	pN100919
Test Date:	Thu Jul 24 11:07:34 EDT 2014
Device:	HTCOne CDMA
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Jul 24 11:07:34 EDT 2014 Acquisition finished: Thu Jul 24 11:10:22 EDT 2014</p> <p>Hash values were properly reported for individually acquired device data</p>

Test Case MDT-22 Access Data MPE+ v5.5.2.60		
	elements	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-AO-15 Hash values for individual data and case presented in a useable format.	as expected
Analysis:	Expected results achieved	

147

148 1.2.66 MDT-01 – HTC One (GSM)

Test Case MDT-01 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-01 Acquire mobile device internal memory over tool-supported interfaces (e.g., cable, Bluetooth, IrDA).	
Assertions:	MDT-CA-01 If a mobile device forensic tool provides support for connectivity of the target device then the tool shall successfully recognize the target device via all vendor supported interfaces (e.g., cable, Bluetooth, IrDA).	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Tue Aug 26 10:57:21 EDT 2014	
Device:	HTCOne GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Aug 26 10:57:21 EDT 2014 Acquisition finished: Tue Aug 26 15:52:13 EDT 2014 Device connectivity was established via supported interface	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-CA-01 Device connectivity via supported interfaces.	as expected
Analysis:	Expected results achieved	

149

150 1.2.67 MDT-02 – HTC One (GSM)

Test Case MDT-02 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-02 Begin mobile device internal memory acquisition and interrupt connectivity by interface disengagement.	
Assertions:	MDT-CA-02 If connectivity between the mobile device and mobile device forensic tool is disrupted then the tool shall notify the user that connectivity has been disrupted.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Tue Aug 26 11:00:03 EDT 2014	
Device:	HTCOne GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Aug 26 11:00:03 EDT 2014 Acquisition finished: Tue Aug 26 15:52:42 EDT 2014 Device acquisition disruption notification was successful	
Results:		

Test Case MDT-02 Access Data MPE+ v5.5.2.60		
	Assertion & Expected Result	Actual Result
	MDT-CA-02 Notification of device acquisition disruption.	as expected
Analysis:	Expected results achieved	

151

152 1.2.68 MDT-03 – HTC One (GSM)

Test Case MDT-03 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-03 Acquire mobile device internal memory and review reported data via the preview-pane or generated reports for readability.	
Assertions:	MDT-CA-03 If a mobile device forensic tool completes acquisition of the target device without error then the tool shall have the ability to present acquired data objects in a useable format via either a preview-pane or generated report.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Tue Aug 26 11:00:40 EDT 2014	
Device:	HTCOne_GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Aug 26 11:00:40 EDT 2014 Acquisition finished: Tue Aug 26 15:53:09 EDT 2014 Readability and completeness of acquired data was successful	
Results:	Assertion & Expected Result	Actual Result
	MDT-CA-03 Readability and completeness of acquired data via supported reports.	as expected
Analysis:	Expected results achieved	

153

154 1.2.69 MDT-04 – HTC One (GSM)

Test Case MDT-04 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-04 Acquire mobile device internal memory and review reported subscriber and equipment related information (e.g., IMSI, IMEI, MEID/ESN, MSISDN).	
Assertions:	MDT-CA-04 If a mobile device forensic tool completes acquisition of the target device without error then subscriber and equipment related information shall be presented in a useable format.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Tue Aug 26 11:01:17 EDT 2014	
Device:	HTCOne_GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Aug 26 11:01:17 EDT 2014 Acquisition finished: Wed Aug 27 15:07:48 EDT 2014 IMEI was acquired Notes: The MSISDN was not reported.	
Results:		

Test Case MDT-04 Access Data MPE+ v5.5.2.60		
	Assertion & Expected Result	Actual Result
	MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected
Analysis:	Partial results achieved	

155

156 1.2.70 MDT-05 – HTC One (GSM)

Test Case MDT-05 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-05 Acquire mobile device internal memory and review supported data elements (i.e., PIM data, call logs, SMS, MMS, stand-alone files: audio, pictures, video, application related data: documents, spreadsheets, presentations, social-media data and Internet related data: bookmarks, visited sites).	
Assertions:	MDT-CA-05 If a mobile device forensic tool completes acquisition of the target device without error then all supported data elements shall be presented in a useable format.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Tue Aug 26 11:01:52 EDT 2014	
Device:	HTCOne_GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Aug 26 11:01:52 EDT 2014 Acquisition finished: Wed Aug 27 15:08:23 EDT 2014</p> <p>All address book entries were successfully acquired ALL PIM related data was acquired All Call Logs (incoming, outgoing, missed) were acquired All Call Log date/time stamps data were correctly reported ALL text messages (SMS, EMS) were acquired Correct date/time stamps were reported for all text messages Correct status flags were reported for all text messages Sender and Recipient phone numbers associated with text messages were correctly reported ALL MMS messages (Audio, Image, Video) were acquired Audio files were not acquired Image files were acquired Video files were acquired Application data was not acquired All Internet related data was acquired All Social media related data was acquired</p> <p>Notes: Graphic files associated with contact entries were not acquired.</p>	
Results:	Assertion & Expected Result	Actual Result
	MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Not as expected
Analysis:	Partial results achieved	

157

158 1.2.71 MDT-06 – HTC One (GSM)

Test Case MDT-06 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-06 Acquire mobile device internal memory by selecting a combination of supported data elements.

Test Case MDT-06 Access Data MPE+ v5.5.2.60											
Assertions:	MDT-CA-06 If a mobile device forensic tool provides the user with an Acquire All device data objects acquisition option then the tool shall complete the acquisition of all data objects without error. MDT-CA-07 If a mobile device forensic tool provides the user with an Select All individual device data objects then the tool shall complete the acquisition of all individually selected data objects without error. MDT-CA-08 If a mobile device forensic tool provides the user with the ability to Select Individual device data objects for acquisition then the tool shall acquire each exclusive data object without error. MDT-CA-09 If a mobile device forensic tool completes two consecutive logical acquisitions of the target device without error then the payload (data objects) on the mobile device shall remain consistent.										
Tester Name:	jrr										
Test Host:	pN100919										
Test Date:	Tue Aug 26 11:02:26 EDT 2014										
Device:	HTCOne_GSM										
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable										
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Aug 26 11:02:26 EDT 2014 Acquisition finished: Wed Aug 27 15:13:05 EDT 2014 Acquire All acquisition was successful Select All acquisition was successful Individual data element acquisition was successful										
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-CA-06 Acquire-all mobile device data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-CA-07 Select-all mobile device data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-CA-08 Select-individual mobile device data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected	MDT-CA-07 Select-all mobile device data objects acquisition.	as expected	MDT-CA-08 Select-individual mobile device data objects acquisition.	as expected	MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected
Assertion & Expected Result	Actual Result										
MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected										
MDT-CA-07 Select-all mobile device data objects acquisition.	as expected										
MDT-CA-08 Select-individual mobile device data objects acquisition.	as expected										
MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected										
Analysis:	Expected results achieved										

159

160 1.2.72 MDT-07 – HTC One (GSM)

Test Case MDT-07 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-07 Acquire UICC memory over supported interfaces (e.g., PC/SC reader).
Assertions:	MDT-AO-01 If a mobile device forensic tool provides support for connectivity of the target UICC then the tool shall successfully recognize the target SIM via all tool-supported interfaces (e.g., PC/SC reader, proprietary reader, smart phone itself).
Tester Name:	jrr
Test Host:	pN100919
Test Date:	Wed Aug 27 15:18:06 EDT 2014
Device:	HTCOne_GSM
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Aug 27 15:18:06 EDT 2014 Acquisition finished: Thu Aug 28 14:05:23 EDT 2014 UICC connectivity was established via supported interface

Test Case MDT-07 Access Data MPE+ v5.5.2.60				
Results:				
	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-01 UICC connectivity via supported interfaces.</td><td>as expected</td></tr></table>	Assertion & Expected Result	Actual Result	MDT-AO-01 UICC connectivity via supported interfaces.
Assertion & Expected Result	Actual Result			
MDT-AO-01 UICC connectivity via supported interfaces.	as expected			
Analysis:	Expected results achieved			

161

162 1.2.73 MDT-08 – HTC One (GSM)

Test Case MDT-08 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-08 Begin UICC acquisition and interrupt connectivity by interface disengagement.					
Assertions:	MDT-AO-02 If a mobile device forensic tool loses connectivity with the UICC reader then the tool shall notify the user that connectivity has been disrupted.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Wed Aug 27 15:18:41 EDT 2014					
Device:	HTCOne GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB					
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Aug 27 15:18:41 EDT 2014 Acquisition finished: Thu Aug 28 14:05:49 EDT 2014</p> <p>Media acquisition disruption notification was not successful</p> <p>Notes: No error message when disrupting connectivity, it stopped and reported the data recovered until connectivity was disrupted.</p>					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-02 Notification of SIM acquisition disruption.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-02 Notification of SIM acquisition disruption.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-AO-02 Notification of SIM acquisition disruption.	Not as expected					
Analysis:	Expected results not achieved					

163

164 1.2.74 MDT-09 – HTC One (GSM)

Test Case MDT-09 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-09Acquire UICC memory and review reported subscriber and equipment related information (i.e., SPN, ICCID, IMSI, MSISDN).	
Assertions:	MDT-AO-03 If a mobile device forensic tool completes acquisition of the target UICC without error then the subscriber and equipment related data shall be presented in a useable format.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Wed Aug 27 15:19:16 EDT 2014	
Device:	HTCOne GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB	
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Aug 27 15:19:16 EDT 2014 Acquisition finished: Thu Aug 28 14:09:15 EDT 2014</p> <p>SPN was not acquired ICCID was acquired IMSI was acquired MSISDN was acquired</p>	

Test Case MDT-09 Access Data MPE+ v5.5.2.60		
Results:		
	Assertion & Expected Result	Actual Result
	MDT-AO-03 Acquisition of UICC subscriber and equipment related data in a useable format.	Not as expected
Analysis:	Partial results achieved	

165

166 1.2.75 MDT-10 – HTC One (GSM)

Test Case MDT-10 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-10 Acquire UICC memory and review supported data elements (i.e., Abbreviated Dialing Numbers, Last Numbers Dialed, SMS/EMS text messages, and location related data: LOCI, GPRSLOCI).	
Assertions:	MDT-AO-04 If a mobile device forensic tool completes acquisition of the target UICC without error then all acquired data shall be presented in a useable format.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Wed Aug 27 15:19:48 EDT 2014	
Device:	HTCOne GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB	
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Aug 27 15:19:48 EDT 2014 Acquisition finished: Thu Aug 28 14:09:46 EDT 2014</p> <p>All ADNs were acquired LNDs were acquired Date/Time Stamps correctly reported for LNDs ALL text messages (SMS, EMS) were acquired All date/time stamps were reported for text messages Correct status flags were reported for text messages Sender and Recipient phone numbers associated with text messages were correctly reported Deleted text message data was recovered LOCI data was acquired GPRSLOCI data was acquired</p> <p>Notes: French contact entry was incorrectly reported as Aur[0x05]lien instead of Aurélien.</p>	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-AO-04 Acquisition of all UICC supported data elements in a useable format.	Not as expected
Analysis:	Partial results achieved	

167

168 1.2.76 MDT-11 – HTC One (GSM)

Test Case MDT-11 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-11 Acquire UICC memory by selecting a combination of supported data elements.	
Assertions:	MDT-AO-05 If a mobile device forensic tool provides the user with an Acquire All UICC data objects acquisition option then the tool shall complete the acquisition of all data objects without error. MDT-AO-06 If a mobile device forensic tool provides the user with an Select All individual UICC data objects then the tool shall complete the	

Test Case MDT-11 Access Data MPE+ v5.5.2.60										
	acquisition of all individually selected data objects without error. MDT-AO-07 If a mobile device forensic tool provides the user with the ability to Select Individual UICC data objects for acquisition then the tool shall acquire each exclusive data object without error.									
Tester Name:	jrr									
Test Host:	pN100919									
Test Date:	Wed Aug 27 15:20:22 EDT 2014									
Device:	HTCOne GSM									
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB									
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Aug 27 15:20:22 EDT 2014 Acquisition finished: Thu Aug 28 14:13:00 EDT 2014 Acquire All acquisition was successful Select All acquisition was successful Individual data element acquisition was successful									
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-05 Acquire-all UICC data objects acquisition.</td><td>as expected</td></tr><tr><td>MDT-AO-06 Select-all UICC data objects acquisition.</td><td>as expected</td></tr><tr><td>MDT-AO-07 Select-individual UICC data objects acquisition.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-05 Acquire-all UICC data objects acquisition.	as expected	MDT-AO-06 Select-all UICC data objects acquisition.	as expected	MDT-AO-07 Select-individual UICC data objects acquisition.	as expected
Assertion & Expected Result	Actual Result									
MDT-AO-05 Acquire-all UICC data objects acquisition.	as expected									
MDT-AO-06 Select-all UICC data objects acquisition.	as expected									
MDT-AO-07 Select-individual UICC data objects acquisition.	as expected									
Analysis:	Expected results achieved									

169

170 1.2.77 MDT-12 – HTC One (GSM)

Test Case MDT-12 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-12 After a successful mobile device internal memory, alter the case file via third-party means and attempt to re-open the case.					
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Tue Aug 26 11:03:00 EDT 2014					
Device:	HTCOne GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Aug 26 11:03:00 EDT 2014 Acquisition finished: Wed Aug 27 15:13:43 EDT 2014 Notification of modified device memory data was successful Notes: Case file data can be modified without warning when re-opening the test case. However, when the test case is re-opened the original data is reported.					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-08 Notification of modified device case data.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-08 Notification of modified device case data.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-08 Notification of modified device case data.	as expected					
Analysis:	Expected results achieved					

171

172 **1.2.78 MDT-13 – HTC One (GSM)**

Test Case MDT-13 Access Data MPE+ v5.5.2.60					
Case Summary:	MDT-13 After a successful UICC acquisition, alter the case file via third-party means and attempt to re-open the case.				
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.				
Tester Name:	jrr				
Test Host:	pN100919				
Test Date:	Wed Aug 27 15:20:51 EDT 2014				
Device:	HTCOne GSM				
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB				
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Aug 27 15:20:51 EDT 2014 Acquisition finished: Thu Aug 28 14:13:35 EDT 2014 Notification of modified SIM data was successful Notes: Case file data can be modified without warning when re-opening the test case. However, when the case is re-opened the original data is reported. Tool only gives warning when file size changes.				
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-AO-08 Notification of modified device case data.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-AO-08 Notification of modified device case data.	as expected
Assertion & Expected Result	Actual Result				
MDT-AO-08 Notification of modified device case data.	as expected				
Analysis:	Expected results achieved				

173

174 **1.2.79 MDT-14 – HTC One (GSM)**

Test Case MDT-14 Access Data MPE+ v5.5.2.60					
Case Summary:	MDT-14 Attempt acquisition of a password-protected UICC.				
Assertions:	MDT-AO-09 If the UICC is password-protected then the mobile device forensic tool shall provide the examiner with the opportunity to input the PIN before acquisition.				
Tester Name:	jrr				
Test Host:	pN100919				
Test Date:	Wed Aug 27 15:21:25 EDT 2014				
Device:	HTCOne GSM				
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB				
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Aug 27 15:21:25 EDT 2014 Acquisition finished: Thu Aug 28 14:15:30 EDT 2014 Ability to enter PIN on protected media before acquisition was successful				
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-AO-09 Acquisition of password protected UICC.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-AO-09 Acquisition of password protected UICC.	as expected
Assertion & Expected Result	Actual Result				
MDT-AO-09 Acquisition of password protected UICC.	as expected				
Analysis:	Expected results achieved				

175

176 **1.2.80 MDT-15 – HTC One (GSM)**

Test Case MDT-15 Access Data MPE+ v5.5.2.60	
Case	MDT-15 Begin acquisition on a PIN protected UICC to determine if the tool

Test Case MDT-15 Access Data MPE+ v5.5.2.60						
Summary:	provides an accurate count of the remaining number of PIN attempts and if the PIN attempts are decremented when entering an incorrect value.					
Assertions:	MDT-AO-10 If a mobile device forensic tool provides the examiner with the remaining number of authentication attempts then the application should provide an accurate count of the remaining PIN attempts.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Wed Aug 27 15:21:57 EDT 2014					
Device:	HTCone GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Aug 27 15:21:57 EDT 2014 Acquisition finished: Thu Aug 28 14:15:53 EDT 2014 The remaining number of PIN attempts were properly displayed					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-10 Remaining number of PIN attempts properly displayed.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-10 Remaining number of PIN attempts properly displayed.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-10 Remaining number of PIN attempts properly displayed.	as expected					
Analysis:	Expected results achieved					

177

178 1.2.81 MDT-16 – HTC One (GSM)

Test Case MDT-16 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-16 Begin acquisition on a UICC whose PIN attempts have been exhausted to determine if the tool provides an accurate count of the remaining number of PUK attempts and if the PUK attempts are decremented when entering an incorrect value.					
Assertions:	MDT-AO-11 If a mobile device forensic tool provides the examiner with the remaining number of PUK attempts then the application should provide an accurate count of the remaining PUK attempts.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Fri Sep 5 14:44:55 EDT 2014					
Device:	HTCOne GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Sep 5 14:44:55 EDT 2014 Acquisition finished: Fri Sep 5 15:44:52 EDT 2014 Remaining number of PUK attempts were properly displayed					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-11 Remaining number of PUK attempts properly displayed.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-11 Remaining number of PUK attempts properly displayed.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-11 Remaining number of PUK attempts properly displayed.	as expected					
Analysis:	Expected results achieved					

179

180 1.2.82 MDT-19 – HTC One (GSM)

Test Case MDT-19 Access Data MPE+ v5.5.2.60	
Case	MDT-19 Acquire mobile device internal memory and review data containing

Test Case MDT-19 Access Data MPE+ v5.5.2.60						
Summary:	non-ASCII characters.					
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Tue Aug 26 11:03:31 EDT 2014					
Device:	HTCOne_GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Aug 26 11:03:31 EDT 2014 Acquisition finished: Wed Aug 27 15:15:30 EDT 2014 Non-ASCII Address book entries were acquired and properly displayed Non-ASCII text messages were acquired and properly displayed					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected					
Analysis:	Expected results achieved					

181

182 1.2.83 MDT-20 – HTC One (GSM)

Test Case MDT-20 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-20 Acquire UICC memory and review data containing non-ASCII characters.					
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Wed Aug 27 15:23:01 EDT 2014					
Device:	HTCOne GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Aug 27 15:23:01 EDT 2014 Acquisition finished: Thu Aug 28 14:16:23 EDT 2014 Non-ASCII ADNs were acquired and properly displayed Non-ASCII text messages were acquired and properly displayed					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected					
Analysis:	Expected results achieved					

183

184 1.2.84 MDT-22 – HTC One (GSM)

Test Case MDT-22 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-22 Acquire mobile device internal memory and review hash values for vendor supported data objects.	
Assertions:	MDT-AO-15 If the mobile device forensic tool supports hashing for individual data objects then the tool shall present the user with a hash	

Test Case MDT-22 Access Data MPE+ v5.5.2.60						
	value for each supported data object.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Tue Aug 26 11:04:02 EDT 2014					
Device:	HTCone GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Aug 26 11:04:02 EDT 2014 Acquisition finished: Wed Aug 27 15:16:05 EDT 2014 Hash values were properly reported for individually acquired device data elements					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-15 Hash values for individual data and case presented in a useable format.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-15 Hash values for individual data and case presented in a useable format.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-15 Hash values for individual data and case presented in a useable format.	as expected					
Analysis:	Expected results achieved					

185

186 1.2.85 MDT-01 – iPad (CDMA)

Test Case MDT-01 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-01 Acquire mobile device internal memory over tool-supported interfaces (e.g., cable, Bluetooth, IrDA).					
Assertions:	MDT-CA-01 If a mobile device forensic tool provides support for connectivity of the target device then the tool shall successfully recognize the target device via all vendor supported interfaces (e.g., cable, Bluetooth, IrDA).					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Thu Jul 17 11:22:32 EDT 2014					
Device:	iPad CDMA					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Jul 17 11:22:32 EDT 2014 Acquisition finished: Thu Jul 17 11:33:11 EDT 2014 Device connectivity was established via supported interface					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-01 Device connectivity via supported interfaces.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-01 Device connectivity via supported interfaces.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-01 Device connectivity via supported interfaces.	as expected					
Analysis:	Expected results achieved					

187

188 1.2.86 MDT-02 – iPad (CDMA)

Test Case MDT-02 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-02 Begin mobile device internal memory acquisition and interrupt connectivity by interface disengagement.	
Assertions:	MDT-CA-02 If connectivity between the mobile device and mobile device forensic tool is disrupted then the tool shall notify the user that connectivity has been disrupted.	
Tester Name:	jrr	
Test Host:	pN100919	

Test Case MDT-02 Access Data MPE+ v5.5.2.60					
Test Date:	Thu Jul 17 11:33:46 EDT 2014				
Device:	iPad_CDMA				
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable				
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Jul 17 11:33:46 EDT 2014 Acquisition finished: Thu Jul 17 11:36:54 EDT 2014 Device acquisition disruption notification was successful				
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-CA-02 Notification of device acquisition disruption.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-CA-02 Notification of device acquisition disruption.	as expected
Assertion & Expected Result	Actual Result				
MDT-CA-02 Notification of device acquisition disruption.	as expected				
Analysis:	Expected results achieved				

189

190 1.2.87 MDT-03 – iPad (CDMA)

Test Case MDT-03 Access Data MPE+ v5.5.2.60					
Case Summary:	MDT-03 Acquire mobile device internal memory and review reported data via the preview-pane or generated reports for readability.				
Assertions:	MDT-CA-03 If a mobile device forensic tool completes acquisition of the target device without error then the tool shall have the ability to present acquired data objects in a useable format via either a preview-pane or generated report.				
Tester Name:	jrr				
Test Host:	pN100919				
Test Date:	Thu Jul 17 11:37:41 EDT 2014				
Device:	iPad_CDMA				
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable				
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Jul 17 11:37:41 EDT 2014 Acquisition finished: Thu Jul 17 13:22:51 EDT 2014 Readability and completeness of acquired data was not successful Notes: When generating report (.pdf file format) stand-alone data files were not reported.				
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-CA-03 Readability and completeness of acquired data via supported reports.</td><td>Not as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-CA-03 Readability and completeness of acquired data via supported reports.	Not as expected
Assertion & Expected Result	Actual Result				
MDT-CA-03 Readability and completeness of acquired data via supported reports.	Not as expected				
Analysis:	Partial results achieved				

191

192 1.2.88 MDT-04 – iPad (CDMA)

Test Case MDT-04 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-04 Acquire mobile device internal memory and review reported subscriber and equipment related information (e.g., IMSI, IMEI, MEID/ESN, MSISDN).
Assertions:	MDT-CA-04 If a mobile device forensic tool completes acquisition of the target device without error then subscriber and equipment related information shall be presented in a useable format.
Tester Name:	jrr
Test Host:	pN100919

Test Case MDT-04 Access Data MPE+ v5.5.2.60						
Test Date:	Thu Jul 17 13:23:32 EDT 2014					
Device:	iPad CDMA					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Jul 17 13:23:32 EDT 2014 Acquisition finished: Thu Jul 17 13:58:14 EDT 2014 IMEI was acquired Notes: MEID not reported, tool says not applicable. Model Number reported doesn't match the model number displayed on the tablet.					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected					
Analysis:	Partial results achieved					

193

194 1.2.89 MDT-05 – iPad (CDMA)

Test Case MDT-05 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-05 Acquire mobile device internal memory and review supported data elements (i.e., PIM data, call logs, SMS, MMS, stand-alone files: audio, pictures, video, application related data: documents, spreadsheets, presentations, social-media data and Internet related data: bookmarks, visited sites).
Assertions:	MDT-CA-05 If a mobile device forensic tool completes acquisition of the target device without error then all supported data elements shall be presented in a useable format.
Tester Name:	jrr
Test Host:	pN100919
Test Date:	Thu Jul 17 14:09:44 EDT 2014
Device:	iPad CDMA
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Jul 17 14:09:44 EDT 2014 Acquisition finished: Thu Jul 17 14:25:56 EDT 2014</p> <p>All address book entries were successfully acquired Basic PIM related data was acquired Partial Maximum length PIM related data was acquired ALL text messages (SMS, EMS) were acquired Correct date/time stamps were reported for all text messages Correct status flags were reported for all text messages Sender and Recipient phone numbers associated with text messages were correctly reported ALL MMS messages (Audio, Image, Video) were acquired ALL stand-alone data files (Audio, Image, Video) were acquired All application data was acquired All Internet related data was acquired Partial Social media related data was acquired</p> <p>Notes: Active contact entry with long name was partially acquired. Only the first name and very last name were acquired, everything in between was not acquired. Active contact entry with regular name containing a middle name was partially acquired. Middle name was not acquired.</p>

Test Case MDT-05 Access Data MPE+ v5.5.2.60		
	When a case file (AD1) is re-opened calendar entries are not present. Screenshots were reported for Twitter and LinkedIn conversations only. Graphic files from LinkedIn were acquired.	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Not as expected
Analysis:	Partial results achieved	

195

1.2.90 MDT-06 – iPad (CDMA)

Test Case MDT-06 Access Data MPE+ v5.5.2.60												
Case Summary:	MDT-06 Acquire mobile device internal memory by selecting a combination of supported data elements.											
Assertions:	MDT-CA-06 If a mobile device forensic tool provides the user with an Acquire All device data objects acquisition option then the tool shall complete the acquisition of all data objects without error. MDT-CA-07 If a mobile device forensic tool provides the user with an Select All individual device data objects then the tool shall complete the acquisition of all individually selected data objects without error. MDT-CA-08 If a mobile device forensic tool provides the user with the ability to Select Individual device data objects for acquisition then the tool shall acquire each exclusive data object without error. MDT-CA-09 If a mobile device forensic tool completes two consecutive logical acquisitions of the target device without error then the payload (data objects) on the mobile device shall remain consistent.											
Tester Name:	jrr											
Test Host:	pN100919											
Test Date:	Thu Jul 17 14:29:28 EDT 2014											
Device:	iPad_CDMA											
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable											
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Jul 17 14:29:28 EDT 2014 Acquisition finished: Thu Jul 17 14:39:49 EDT 2014 Acquire All acquisition was successful Select All acquisition was successful Individual data element acquisition was successful											
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-06 Acquire-all mobile device data objects acquisition.</td><td>as expected</td></tr><tr><td>MDT-CA-07 Select-all mobile device data objects acquisition.</td><td>as expected</td></tr><tr><td>MDT-CA-08 Select-individual mobile device data objects acquisition.</td><td>as expected</td></tr><tr><td>MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected	MDT-CA-07 Select-all mobile device data objects acquisition.	as expected	MDT-CA-08 Select-individual mobile device data objects acquisition.	as expected	MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected
Assertion & Expected Result	Actual Result											
MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected											
MDT-CA-07 Select-all mobile device data objects acquisition.	as expected											
MDT-CA-08 Select-individual mobile device data objects acquisition.	as expected											
MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected											
Analysis:	Expected results achieved											

197

198

199 **1.2.91 MDT-12 – iPad (CDMA)**

Test Case MDT-12 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-12 After a successful mobile device internal memory, alter the case file via third-party means and attempt to re-open the case.					
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Thu Jul 17 14:40:36 EDT 2014					
Device:	iPad_CDMA					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Jul 17 14:40:36 EDT 2014 Acquisition finished: Thu Jul 17 14:46:11 EDT 2014 Notification of modified device memory data was successful Notes: Case file data can be modified without warning when re-opening the test case. However, when the case is re-opened the original data is reported.					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-08 Notification of modified device case data.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-08 Notification of modified device case data.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-08 Notification of modified device case data.	as expected					
Analysis:	Expected results achieved					

200

201 **1.2.92 MDT-19 – iPad (CDMA)**

Test Case MDT-19 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-19 Acquire mobile device internal memory and review data containing non-ASCII characters.					
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Thu Jul 17 14:49:28 EDT 2014					
Device:	iPad CDMA					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Jul 17 14:49:28 EDT 2014 Acquisition finished: Thu Jul 17 14:54:04 EDT 2014</p> <p>Non-ASCII Address book entries were acquired but not properly displayed Non-ASCII text messages were acquired and properly displayed</p> <p>Notes: Non-ASCII characters displayed in different order for address book entries.</p>					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	Not as expected					
Analysis:	Partial results achieved					

202

203

1.2.93 MDT-22 – iPad (CDMA)

Test Case MDT-22 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-22 Acquire mobile device internal memory and review hash values for vendor supported data objects.					
Assertions:	MDT-AO-15 If the mobile device forensic tool supports hashing for individual data objects then the tool shall present the user with a hash value for each supported data object.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Thu Jul 17 14:57:10 EDT 2014					
Device:	iPad_CDMA					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Jul 17 14:57:10 EDT 2014 Acquisition finished: Thu Jul 17 15:05:36 EDT 2014</p> <p>Hash values were properly reported for individually acquired device data elements</p> <p>Notes: Hashes were not reported in preview pane but they were included in the exported (.pdf file format) report.</p>					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-15 Hash values for individual data and case presented in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-15 Hash values for individual data and case presented in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-AO-15 Hash values for individual data and case presented in a useable format.	Not as expected					
Analysis:	Partial results achieved					

204

205 **1.2.94 MDT-24 – iPad (CDMA)**

Test Case MDT-24 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-24 Acquire mobile device internal memory and review data containing GPS longitude and latitude coordinates					
Assertions:	MDT-AO-16 If the mobile device forensic tool supports acquisition of GPS data then the tool shall present the user with the longitude and latitude coordinates for all GPS-related data in a useable format.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Thu Jul 17 15:09:00 EDT 2014					
Device:	iPad_CDMA					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Jul 17 15:09:00 EDT 2014 Acquisition finished: Thu Jul 17 15:13:17 EDT 2014 GPS Coordinate data was successfully acquired Notes: GPS latitude and longitude were not reported, but the physical address and a map screenshot of the place were reported.					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-16 Acquisition of GPS related data presented in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-16 Acquisition of GPS related data presented in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-AO-16 Acquisition of GPS related data presented in a useable format.	Not as expected					

Test Case MDT-24 Access Data MPE+ v5.5.2.60	
Analysis:	Partial results achieved

206

207 1.2.95 MDT-01 – iPad (GSM)

Test Case MDT-01 Access Data MPE+ v5.5.2.60					
Case Summary:	MDT-01 Acquire mobile device internal memory over tool-supported interfaces (e.g., cable, Bluetooth, IrDA).				
Assertions:	MDT-CA-01 If a mobile device forensic tool provides support for connectivity of the target device then the tool shall successfully recognize the target device via all vendor supported interfaces (e.g., cable, Bluetooth, IrDA).				
Tester Name:	jrr				
Test Host:	pN100919				
Test Date:	Mon Jul 28 15:11:14 EDT 2014				
Device:	iPad GSM				
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable				
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Mon Jul 28 15:11:14 EDT 2014 Acquisition finished: Mon Jul 28 15:19:53 EDT 2014 Device connectivity was established via supported interface				
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-CA-01 Device connectivity via supported interfaces.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-CA-01 Device connectivity via supported interfaces.	as expected
Assertion & Expected Result	Actual Result				
MDT-CA-01 Device connectivity via supported interfaces.	as expected				
Analysis:	Expected results achieved				

208

209 1.2.96 MDT-02 – iPad (GSM)

Test Case MDT-02 Access Data MPE+ v5.5.2.60					
Case Summary:	MDT-02 Begin mobile device internal memory acquisition and interrupt connectivity by interface disengagement.				
Assertions:	MDT-CA-02 If connectivity between the mobile device and mobile device forensic tool is disrupted then the tool shall notify the user that connectivity has been disrupted.				
Tester Name:	jrr				
Test Host:	pN100919				
Test Date:	Mon Jul 28 15:20:37 EDT 2014				
Device:	iPad GSM				
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable				
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Mon Jul 28 15:20:37 EDT 2014 Acquisition finished: Mon Jul 28 15:34:33 EDT 2014 Device acquisition disruption notification was successful				
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-CA-02 Notification of device acquisition disruption.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-CA-02 Notification of device acquisition disruption.	as expected
Assertion & Expected Result	Actual Result				
MDT-CA-02 Notification of device acquisition disruption.	as expected				
Analysis:	Expected results achieved				

210

211

212 **1.2.97 MDT-03 – iPad (GSM)**

Test Case MDT-03 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-03 Acquire mobile device internal memory and review reported data via the preview-pane or generated reports for readability.					
Assertions:	MDT-CA-03 If a mobile device forensic tool completes acquisition of the target device without error then the tool shall have the ability to present acquired data objects in a useable format via either a preview-pane or generated report.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Mon Jul 28 15:35:07 EDT 2014					
Device:	iPad GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Mon Jul 28 15:35:07 EDT 2014 Acquisition finished: Mon Jul 28 16:29:27 EDT 2014</p> <p>Readability and completeness of acquired data was successful</p> <p>Notes: When generating report (.pdf file format), stand-alone data files were not reported.</p>					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-03 Readability and completeness of acquired data via supported reports.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-03 Readability and completeness of acquired data via supported reports.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-CA-03 Readability and completeness of acquired data via supported reports.	Not as expected					
Analysis:	Partial results achieved					

213

214 **1.2.98 MDT-04 – iPad (GSM)**

Test Case MDT-04 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-04 Acquire mobile device internal memory and review reported subscriber and equipment related information (e.g., IMSI, IMEI, MEID/ESN, MSISDN).					
Assertions:	MDT-CA-04 If a mobile device forensic tool completes acquisition of the target device without error then subscriber and equipment related information shall be presented in a useable format.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Tue Jul 29 09:43:30 EDT 2014					
Device:	iPad GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Jul 29 09:43:30 EDT 2014 Acquisition finished: Tue Jul 29 09:49:37 EDT 2014 IMEI was acquired Notes: MEID not reported, tool says not applicable. Model Number reported doesn't match the model number displayed on the tablet.					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected					

Test Case MDT-04 Access Data MPE+ v5.5.2.60	
Analysis:	Partial results achieved

215

216 1.2.99 MDT-05 – iPad (GSM)

Test Case MDT-05 Access Data MPE+ v5.5.2.60					
Case Summary:	MDT-05 Acquire mobile device internal memory and review supported data elements (i.e., PIM data, call logs, SMS, MMS, stand-alone files: audio, pictures, video, application related data: documents, spreadsheets, presentations, social-media data and Internet related data: bookmarks, visited sites).				
Assertions:	MDT-CA-05 If a mobile device forensic tool completes acquisition of the target device without error then all supported data elements shall be presented in a useable format.				
Tester Name:	jrr				
Test Host:	pN100919				
Test Date:	Tue Jul 29 09:51:25 EDT 2014				
Device:	iPad GSM				
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable				
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Jul 29 09:51:25 EDT 2014 Acquisition finished: Tue Jul 29 11:50:16 EDT 2014</p> <p>All address book entries were successfully acquired ALL PIM related data was acquired All Call Logs (incoming, outgoing, missed) were acquired All Call Log date/time stamps data were correctly reported ALL text messages (SMS, EMS) were acquired Correct date/time stamps were reported for all text messages Correct status flags were reported for all text messages Sender and Recipient phone numbers associated with text messages were correctly reported ALL MMS messages (Audio, Image, Video) were acquired ALL stand-alone data files (Audio, Image, Video) were acquired Application data was not acquired All Internet related data was acquired Partial Social media related data was acquired</p> <p>Notes: Active contact entry with long name was partially acquired. Only the first name and very last name was acquired, everything in between was not acquired. Active contact entry with regular name containing a middle name was partially acquired. Middle name was not acquired. When a case file (AD1) is re-opened calendar entries are not present. Screenshots were reported for Twitter conversations only.</p>				
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.</td><td>Not as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Not as expected
Assertion & Expected Result	Actual Result				
MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Not as expected				
Analysis:	Partial results achieved				

217

218 1.2.100 MDT-06 – iPad (GSM)

Test Case MDT-06 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-06 Acquire mobile device internal memory by selecting a combination of supported data elements.
Assertions:	MDT-CA-06 If a mobile device forensic tool provides the user with an

Test Case MDT-06 Access Data MPE+ v5.5.2.60											
	<p>Acquire All device data objects acquisition option then the tool shall complete the acquisition of all data objects without error.</p> <p>MDT-CA-07 If a mobile device forensic tool provides the user with an Select All individual device data objects then the tool shall complete the acquisition of all individually selected data objects without error.</p> <p>MDT-CA-08 If a mobile device forensic tool provides the user with the ability to Select Individual device data objects for acquisition then the tool shall acquire each exclusive data object without error.</p> <p>MDT-CA-09 If a mobile device forensic tool completes two consecutive logical acquisitions of the target device without error then the payload (data objects) on the mobile device shall remain consistent.</p>										
Tester Name:	jrr										
Test Host:	pN100919										
Test Date:	Tue Jul 29 11:53:49 EDT 2014										
Device:	iPad GSM										
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable										
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60</p> <p>Acquisition started: Tue Jul 29 11:53:49 EDT 2014</p> <p>Acquisition finished: Tue Jul 29 15:26:53 EDT 2014</p> <p>Acquire All acquisition was successful</p> <p>Select All acquisition was successful</p> <p>Individual data element acquisition was successful</p>										
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-CA-06 Acquire-all mobile device data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-CA-07 Select-all mobile device data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-CA-08 Select-individual mobile device data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected	MDT-CA-07 Select-all mobile device data objects acquisition.	as expected	MDT-CA-08 Select-individual mobile device data objects acquisition.	as expected	MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected
Assertion & Expected Result	Actual Result										
MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected										
MDT-CA-07 Select-all mobile device data objects acquisition.	as expected										
MDT-CA-08 Select-individual mobile device data objects acquisition.	as expected										
MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected										
Analysis:	Expected results achieved										

219

220 1.2.101 MDT-07 – iPad (GSM)

Test Case MDT-07 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-07 Acquire UICC memory over supported interfaces (e.g., PC/SC reader).
Assertions:	MDT-AO-01 If a mobile device forensic tool provides support for connectivity of the target UICC then the tool shall successfully recognize the target SIM via all tool-supported interfaces (e.g., PC/SC reader, proprietary reader, smart phone itself).
Tester Name:	jrr
Test Host:	pN100919
Test Date:	Tue Jul 29 15:27:56 EDT 2014
Device:	iPad GSM
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60</p> <p>Acquisition started: Tue Jul 29 15:27:56 EDT 2014</p> <p>Acquisition finished: Tue Jul 29 16:24:32 EDT 2014</p> <p>UICC connectivity was established via supported interface</p>

Test Case MDT-07 Access Data MPE+ v5.5.2.60		
Results:	Assertion & Expected Result	Actual Result
	MDT-AO-01 UICC connectivity via supported interfaces.	as expected
Analysis:	Expected results achieved	

221

222 1.2.102 MDT-08 – iPad (GSM)

Test Case MDT-08 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-08 Begin UICC acquisition and interrupt connectivity by interface disengagement.	
Assertions:	MDT-AO-02 If a mobile device forensic tool loses connectivity with the UICC reader then the tool shall notify the user that connectivity has been disrupted.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Tue Jul 29 16:25:20 EDT 2014	
Device:	iPad GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB	
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Jul 29 16:25:20 EDT 2014 Acquisition finished: Tue Jul 29 16:33:54 EDT 2014</p> <p>Media acquisition disruption notification was not successful</p> <p>Notes: No error message when disrupting connectivity, it stopped and reported the data recovered until connectivity was disrupted.</p>	
Results:	Assertion & Expected Result	Actual Result
	MDT-AO-02 Notification of SIM acquisition disruption.	Not as expected
Analysis:	Expected results not achieved	

223

224 1.2.103 MDT-09 – iPad (GSM)

Test Case MDT-09 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-09Acquire UICC memory and review reported subscriber and equipment related information (i.e., SPN, ICCID, IMSI, MSISDN).	
Assertions:	MDT-AO-03 If a mobile device forensic tool completes acquisition of the target UICC without error then the subscriber and equipment related data shall be presented in a useable format.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Wed Jul 30 09:21:59 EDT 2014	
Device:	iPad GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB	
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Jul 30 09:21:59 EDT 2014 Acquisition finished: Wed Jul 30 09:27:47 EDT 2014</p> <p>SPN was not acquired ICCID was acquired IMSI was acquired MSISDN was acquired</p>	
Results:		

Test Case MDT-09 Access Data MPE+ v5.5.2.60		
	Assertion & Expected Result	Actual Result
	MDT-AO-03 Acquisition of UICC subscriber and equipment related data in a useable format.	Not as expected
Analysis:	Partial results achieved	

225 1.2.104 MDT-10 – iPad (GSM)

Test Case MDT-10 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-10 Acquire UICC memory and review supported data elements (i.e., Abbreviated Dialing Numbers, Last Numbers Dialed, SMS/EMS text messages, and location related data: LOCI, GPRSLOCI).					
Assertions:	MDT-AO-04 If a mobile device forensic tool completes acquisition of the target UICC without error then all acquired data shall be presented in a useable format.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Wed Jul 30 09:28:23 EDT 2014					
Device:	iPad GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB					
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Jul 30 09:28:23 EDT 2014 Acquisition finished: Wed Jul 30 09:41:12 EDT 2014</p> <p>All ADNs were acquired LNDs were acquired Date/Time Stamps correctly reported for LNDs ALL text messages (SMS, EMS) were acquired All date/time stamps were reported for text messages Correct status flags were reported for text messages Sender and Recipient phone numbers associated with text messages were correctly reported Deleted text message data was recovered LOCI data was acquired GPRSLOCI data was acquired</p> <p>Notes: French contact entry was incorrectly reported as Aur[0x05]lien instead of Aurélien.</p>					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-04 Acquisition of all UICC supported data elements in a us able format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-04 Acquisition of all UICC supported data elements in a us able format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-AO-04 Acquisition of all UICC supported data elements in a us able format.	Not as expected					
Analysis:	Partial results achieved					

226

227 1.2.105 MDT-11 – iPad (GSM)

Test Case MDT-11 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-11 Acquire UICC memory by selecting a combination of supported data elements.
Assertions:	<p>MDT-AO-05 If a mobile device forensic tool provides the user with an Acquire All UICC data objects acquisition option then the tool shall complete the acquisition of all data objects without error.</p> <p>MDT-AO-06 If a mobile device forensic tool provides the user with an Select All individual UICC data objects then the tool shall complete the acquisition of all individually selected data objects without error.</p> <p>MDT-AO-07 If a mobile device forensic tool provides the user with the ability to Select Individual UICC data objects for acquisition then the tool shall acquire each exclusive data object without error.</p>

Test Case MDT-11 Access Data MPE+ v5.5.2.60										
Tester Name:	jrr									
Test Host:	pN100919									
Test Date:	Wed Jul 30 09:52:48 EDT 2014									
Device:	iPad_GSM									
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB									
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Jul 30 09:52:48 EDT 2014 Acquisition finished: Wed Jul 30 10:02:14 EDT 2014 Acquire All acquisition was successful Select All acquisition was successful Individual data element acquisition was successful									
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-05 Acquire-all UICC data objects acquisition.</td><td>as expected</td></tr><tr><td>MDT-AO-06 Select-all UICC data objects acquisition.</td><td>as expected</td></tr><tr><td>MDT-AO-07 Select-individual UICC data objects acquisition.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-05 Acquire-all UICC data objects acquisition.	as expected	MDT-AO-06 Select-all UICC data objects acquisition.	as expected	MDT-AO-07 Select-individual UICC data objects acquisition.	as expected
Assertion & Expected Result	Actual Result									
MDT-AO-05 Acquire-all UICC data objects acquisition.	as expected									
MDT-AO-06 Select-all UICC data objects acquisition.	as expected									
MDT-AO-07 Select-individual UICC data objects acquisition.	as expected									
Analysis:	Expected results achieved									

228

229 1.2.106 MDT-12 – iPad (GSM)

Test Case MDT-12 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-12 After a successful mobile device internal memory, alter the case file via third-party means and attempt to re-open the case.					
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Wed Jul 30 10:02:59 EDT 2014					
Device:	iPad GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Jul 30 10:02:59 EDT 2014 Acquisition finished: Wed Jul 30 10:11:57 EDT 2014 Notification of modified device memory data was successful Notes: Case file data can be modified without warning when re-opening the test case. However, when the case is re-opened the original data is reported.					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-08 Notification of modified device case data.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-08 Notification of modified device case data.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-08 Notification of modified device case data.	as expected					
Analysis:	Expected results achieved					

230

231 1.2.107 MDT-13 – iPad (GSM)

Test Case MDT-13 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-13 After a successful UICC acquisition, alter the case file via third-party means and attempt to re-open the case.	
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via	

Test Case MDT-13 Access Data MPE+ v5.5.2.60						
	third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Wed Jul 30 10:15:04 EDT 2014					
Device:	iPad GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB					
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Jul 30 10:15:04 EDT 2014 Acquisition finished: Wed Jul 30 10:21:19 EDT 2014</p> <p>Notification of modified SIM data was successful</p> <p>Notes: Case file data can be modified without warning when re-opening the test case. However, when the case is re-opened the original data is reported. Tool only gives warning when file size changes.</p>					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-08 Notification of modified device case data.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-08 Notification of modified device case data.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-08 Notification of modified device case data.	as expected					
Analysis:	Expected results achieved					

232

233 1.2.108 MDT-14 – iPad (GSM)

Test Case MDT-14 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-14 Attempt acquisition of a password-protected UICC.					
Assertions:	MDT-AO-09 If the UICC is password-protected then the mobile device forensic tool shall provide the examiner with the opportunity to input the PIN before acquisition.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Wed Jul 30 15:05:16 EDT 2014					
Device:	iPad_GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Jul 30 15:05:16 EDT 2014 Acquisition finished: Wed Jul 30 15:13:00 EDT 2014 Ability to enter PIN on protected media before acquisition was successful					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-09 Acquisition of password protected UICC.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-09 Acquisition of password protected UICC.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-09 Acquisition of password protected UICC.	as expected					
Analysis:	Expected results achieved					

234

235 1.2.109 MDT-15 – iPad (GSM)

Test Case MDT-15 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-15 Begin acquisition on a PIN protected UICC to determine if the tool provides an accurate count of the remaining number of PIN attempts and if the PIN attempts are decremented when entering an incorrect value.	
Assertions:	MDT-AO-10 If a mobile device forensic tool provides the examiner with the remaining number of authentication attempts then the application should provide an accurate count of the remaining PIN attempts.	

Test Case MDT-15 Access Data MPE+ v5.5.2.60		
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Wed Jul 30 15:13:34 EDT 2014	
Device:	iPad GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB	
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Jul 30 15:13:34 EDT 2014 Acquisition finished: Wed Jul 30 16:26:25 EDT 2014 The remaining number of PIN attempts were properly displayed	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-AO-10 Remaining number of PIN attempts properly displayed.	as expected
Analysis:	Expected results achieved	

236

237 1.2.110 MDT-16 – iPad (GSM)

Test Case MDT-16 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-16 Begin acquisition on a UICC whose PIN attempts have been exhausted to determine if the tool provides an accurate count of the remaining number of PUK attempts and if the PUK attempts are decremented when entering an incorrect value.					
Assertions:	MDT-AO-11 If a mobile device forensic tool provides the examiner with the remaining number of PUK attempts then the application should provide an accurate count of the remaining PUK attempts.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Fri Sep 5 14:31:02 EDT 2014					
Device:	iPad GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Sep 5 14:31:02 EDT 2014 Acquisition finished: Fri Sep 5 15:15:52 EDT 2014 Remaining number of PUK attempts were properly displayed					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-11 Remaining number of PUK attempts properly displayed.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-11 Remaining number of PUK attempts properly displayed.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-11 Remaining number of PUK attempts properly displayed.	as expected					
Analysis:	Expected results achieved					

238

239 1.2.111 MDT-19 – iPad (GSM)

Test Case MDT-19 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-19 Acquire mobile device internal memory and review data containing non-ASCII characters.
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.

Test Case MDT-19 Access Data MPE+ v5.5.2.60					
Tester Name:	jrr				
Test Host:	pn100919				
Test Date:	Wed Jul 30 16:27:14 EDT 2014				
Device:	iPad GSM				
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable				
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Jul 30 16:27:14 EDT 2014 Acquisition finished: Wed Jul 30 16:29:58 EDT 2014 Non-ASCII Address book entries were acquired and properly displayed Non-ASCII text messages were acquired and properly displayed				
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected
Assertion & Expected Result	Actual Result				
MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected				
Analysis:	Expected results achieved				

240

241 1.2.112 MDT-20 – iPad (GSM)

Test Case MDT-20 Access Data MPE+ v5.5.2.60					
Case Summary:	MDT-20 Acquire UICC memory and review data containing non-ASCII characters.				
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.				
Tester Name:	jrr				
Test Host:	pn100919				
Test Date:	Wed Jul 30 16:33:52 EDT 2014				
Device:	iPad GSM				
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB				
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Jul 30 16:33:52 EDT 2014 Acquisition finished: Wed Jul 30 16:35:46 EDT 2014 Non-ASCII ADNs were acquired and properly displayed Non-ASCII text messages were acquired and properly displayed				
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected
Assertion & Expected Result	Actual Result				
MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected				
Analysis:	Expected results achieved				

242

243 1.2.113 MDT-22 – iPad (GSM)

Test Case MDT-22 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-22 Acquire mobile device internal memory and review hash values for vendor supported data objects.
Assertions:	MDT-AO-15 If the mobile device forensic tool supports hashing for individual data objects then the tool shall present the user with a hash value for each supported data object.
Tester Name:	jrr
Test Host:	pn100919

Test Case MDT-22 Access Data MPE+ v5.5.2.60						
Test Date:	Thu Jul 31 10:13:27 EDT 2014					
Device:	iPad GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Jul 31 10:13:27 EDT 2014 Acquisition finished: Thu Jul 31 10:25:21 EDT 2014</p> <p>Hash values were properly reported for individually acquired device data elements</p> <p>Notes: Hashes were not reported in preview pane but they were included in the exported (.pdf file format) report.</p>					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-15 Hash values for individual data and case presented in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-15 Hash values for individual data and case presented in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-AO-15 Hash values for individual data and case presented in a useable format.	Not as expected					
Analysis:	Partial results achieved					

244

245 1.2.114 MDT-24 – iPad (GSM)

Test Case MDT-24 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-24 Acquire mobile device internal memory and review data containing GPS longitude and latitude coordinates					
Assertions:	MDT-AO-16 If the mobile device forensic tool supports acquisition of GPS data then the tool shall present the user with the longitude and latitude coordinates for all GPS-related data in a useable format.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Thu Jul 31 10:34:10 EDT 2014					
Device:	iPad GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Jul 31 10:34:10 EDT 2014 Acquisition finished: Thu Jul 31 11:02:11 EDT 2014 GPS Coordinate data was successfully acquired					
Results:	<table><tr><td>Assertion & Expected Result</td><td>Actual Result</td></tr><tr><td>MDT-AO-16 Acquisition of GPS related data presented in a useable format.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-16 Acquisition of GPS related data presented in a useable format.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-16 Acquisition of GPS related data presented in a useable format.	as expected					
Analysis:	Expected results achieved					

246 1.2.115 MDT-01 – iPad Mini (GSM)

Test Case MDT-01 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-01 Acquire mobile device internal memory over tool-supported interfaces (e.g., cable, Bluetooth, IrDA).	
Assertions:	MDT-CA-01 If a mobile device forensic tool provides support for connectivity of the target device then the tool shall successfully recognize the target device via all vendor supported interfaces (e.g., cable, Bluetooth, IrDA).	
Tester Name:	jrr	

Test Case MDT-01 Access Data MPE+ v5.5.2.60						
Test Host:	pN100919					
Test Date:	Wed Sep 3 14:43:22 EDT 2014					
Device:	iPadMini GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Sep 3 14:43:22 EDT 2014 Acquisition finished: Thu Sep 4 13:37:12 EDT 2014 Device connectivity was established via supported interface					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-01 Device connectivity via supported interfaces.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-01 Device connectivity via supported interfaces.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-01 Device connectivity via supported interfaces.	as expected					
Analysis:	Expected results achieved					

247

248 1.2.116 MDT-02 – iPad Mini (GSM)

Test Case MDT-02 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-02 Begin mobile device internal memory acquisition and interrupt connectivity by interface disengagement.					
Assertions:	MDT-CA-02 If connectivity between the mobile device and mobile device forensic tool is disrupted then the tool shall notify the user that connectivity has been disrupted.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Wed Sep 3 14:43:53 EDT 2014					
Device:	iPadMini GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Sep 3 14:43:53 EDT 2014 Acquisition finished: Thu Sep 4 13:37:46 EDT 2014 Device acquisition disruption notification was successful					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-02 Notification of device acquisition disruption.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-02 Notification of device acquisition disruption.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-02 Notification of device acquisition disruption.	as expected					
Analysis:	Expected results achieved					

249

250 1.2.117 MDT-03 – iPad Mini (GSM)

Test Case MDT-03 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-03 Acquire mobile device internal memory and review reported data via the preview-pane or generated reports for readability.	
Assertions:	MDT-CA-03 If a mobile device forensic tool completes acquisition of the target device without error then the tool shall have the ability to present acquired data objects in a useable format via either a preview-pane or generated report.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Wed Sep 3 14:44:27 EDT 2014	
Device:	iPadMini GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	

Test Case MDT-03 Access Data MPE+ v5.5.2.60						
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Sep 3 14:44:27 EDT 2014 Acquisition finished: Thu Sep 4 13:40:26 EDT 2014 Readability and completeness of acquired data was not successful Notes: When generating report (.pdf file format), stand-alone data files were not reported.					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-03 Readability and completeness of acquired data via supported reports.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-03 Readability and completeness of acquired data via supported reports.	Not as expected
	Assertion & Expected Result	Actual Result				
MDT-CA-03 Readability and completeness of acquired data via supported reports.	Not as expected					
Analysis:	Partial results achieved					

251

252 1.2.118 MDT-04 – iPad Mini (GSM)

Test Case MDT-04 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-04 Acquire mobile device internal memory and review reported subscriber and equipment related information (e.g., IMSI, IMEI, MEID/ESN, MSISDN).					
Assertions:	MDT-CA-04 If a mobile device forensic tool completes acquisition of the target device without error then subscriber and equipment related information shall be presented in a useable format.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Wed Sep 3 14:44:58 EDT 2014					
Device:	iPadMini GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Sep 3 14:44:58 EDT 2014 Acquisition finished: Thu Sep 4 13:41:14 EDT 2014 IMEI was acquired Notes: MEID not reported, tool says not applicable. Model Number reported doesn't match the model number displayed on the tablet.					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected					
Analysis:	Partial results achieved					

253

254 1.2.119 MDT-05 – iPad Mini (GSM)

Test Case MDT-05 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-05 Acquire mobile device internal memory and review supported data elements (i.e., PIM data, call logs, SMS, MMS, stand-alone files: audio, pictures, video, application related data: documents, spreadsheets, presentations, social-media data and Internet related data: bookmarks, visited sites).
Assertions:	MDT-CA-05 If a mobile device forensic tool completes acquisition of the target device without error then all supported data elements shall be presented in a useable format.

Test Case MDT-05 Access Data MPE+ v5.5.2.60					
Tester Name:	jrr				
Test Host:	pN100919				
Test Date:	Wed Sep 3 14:45:27 EDT 2014				
Device:	iPadMini GSM				
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable				
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Sep 3 14:45:27 EDT 2014 Acquisition finished: Thu Sep 4 13:41:55 EDT 2014</p> <p>All address book entries were successfully acquired Basic PIM related data was acquired Partial Maximum length PIM related data was acquired ALL text messages (SMS, EMS) were acquired Correct date/time stamps were reported for all text messages Correct status flags were reported for all text messages Sender and Recipient phone numbers associated with text messages were correctly reported ALL MMS messages (Audio, Image, Video) were acquired ALL stand-alone data files (Audio, Image, Video) were acquired Application data was not acquired Partial Internet related data was acquired Partial Social media related data was acquired</p> <p>Notes: Active contact entry with long name was partially acquired. Only the first name and very last name was acquired, everything in between was not acquired. Active contact entry with regular name containing a middle name was partially acquired. Middle name was not acquired. Browser history partially acquired. When a case file (AD1) is re-opened calendar entries are not present. Screenshots were reported for Twitter conversations only.</p>				
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.</td><td>Not as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Not as expected
Assertion & Expected Result	Actual Result				
MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Not as expected				
Analysis:	Partial results achieved				

255

256 1.2.120 MDT-06 – iPad Mini (GSM)

Test Case MDT-06 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-06 Acquire mobile device internal memory by selecting a combination of supported data elements.
Assertions:	<p>MDT-CA-06 If a mobile device forensic tool provides the user with an Acquire All device data objects acquisition option then the tool shall complete the acquisition of all data objects without error.</p> <p>MDT-CA-07 If a mobile device forensic tool provides the user with an Select All individual device data objects then the tool shall complete the acquisition of all individually selected data objects without error.</p> <p>MDT-CA-08 If a mobile device forensic tool provides the user with the ability to Select Individual device data objects for acquisition then the tool shall acquire each exclusive data object without error.</p> <p>MDT-CA-09 If a mobile device forensic tool completes two consecutive logical acquisitions of the target device without error then the payload (data objects) on the mobile device shall remain consistent.</p>
Tester Name:	jrr
Test Host:	pN100919
Test Date:	Wed Sep 3 14:45:57 EDT 2014
Device:	iPadMini GSM
Source	OS: WIN 7 v6.1.7601

Test Case MDT-06 Access Data MPE+ v5.5.2.60											
Setup:	Interface: cable										
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Sep 3 14:45:57 EDT 2014 Acquisition finished: Thu Sep 4 13:45:45 EDT 2014</p> <p>Acquire All acquisition was successful</p> <p>Select All acquisition was successful</p> <p>Individual data element acquisition was successful</p>										
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-CA-06 Acquire-all mobile device data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-CA-07 Select-all mobile device data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-CA-08 Select-individual mobile device data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected	MDT-CA-07 Select-all mobile device data objects acquisition.	as expected	MDT-CA-08 Select-individual mobile device data objects acquisition.	as expected	MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected
Assertion & Expected Result	Actual Result										
MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected										
MDT-CA-07 Select-all mobile device data objects acquisition.	as expected										
MDT-CA-08 Select-individual mobile device data objects acquisition.	as expected										
MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected										
Analysis:	Expected results achieved										

257 1.2.121 MDT-07 – iPad Mini (GSM)

Test Case MDT-07 Access Data MPE+ v5.5.2.60					
Case Summary:	MDT-07 Acquire UICC memory over supported interfaces (e.g., PC/SC reader).				
Assertions:	MDT-AO-01 If a mobile device forensic tool provides support for connectivity of the target UICC then the tool shall successfully recognize the target SIM via all tool-supported interfaces (e.g., PC/SC reader, proprietary reader, smart phone itself).				
Tester Name:	jrr				
Test Host:	pN100919				
Test Date:	Wed Sep 3 14:48:10 EDT 2014				
Device:	iPadMini GSM				
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB				
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Sep 3 14:48:10 EDT 2014 Acquisition finished: Thu Sep 4 13:52:37 EDT 2014</p> <p>UICC connectivity was established via supported interface</p>				
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-AO-01 UICC connectivity via supported interfaces.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-AO-01 UICC connectivity via supported interfaces.	as expected
Assertion & Expected Result	Actual Result				
MDT-AO-01 UICC connectivity via supported interfaces.	as expected				
Analysis:	Expected results achieved				

258

259 1.2.122 MDT-08 – iPad Mini (GSM)

Test Case MDT-08 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-08 Begin UICC acquisition and interrupt connectivity by interface disengagement.
Assertions:	MDT-AO-02 If a mobile device forensic tool loses connectivity with the UICC reader then the tool shall notify the user that connectivity has been disrupted.
Tester Name:	jrr

Test Case MDT-08 Access Data MPE+ v5.5.2.60						
Test Host:	pN100919					
Test Date:	Wed Sep 3 14:48:46 EDT 2014					
Device:	iPadMini GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB					
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Sep 3 14:48:46 EDT 2014 Acquisition finished: Thu Sep 4 13:53:09 EDT 2014</p> <p>Media acquisition disruption notification was not successful</p> <p>Notes: No error message when disrupting connectivity, it stopped and reported the data recovered until connectivity was disrupted.</p>					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-02 Notification of SIM acquisition disruption.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-02 Notification of SIM acquisition disruption.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-AO-02 Notification of SIM acquisition disruption.	Not as expected					
Analysis:	Expected results not achieved					

260

261 1.2.123 MDT-09 – iPad Mini (GSM)

Test Case MDT-09 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-09Acquire UICC memory and review reported subscriber and equipment related information (i.e., SPN, ICCID, IMSI, MSISDN).					
Assertions:	MDT-AO-03 If a mobile device forensic tool completes acquisition of the target UICC without error then the subscriber and equipment related data shall be presented in a useable format.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Wed Sep 3 14:49:17 EDT 2014					
Device:	iPadMini GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Sep 3 14:49:17 EDT 2014 Acquisition finished: Thu Sep 4 13:53:39 EDT 2014 SPN was not acquired ICCID was acquired IMSI was acquired MSISDN was acquired					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-03 Acquisition of UICC subscriber and equipment related data in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-03 Acquisition of UICC subscriber and equipment related data in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-AO-03 Acquisition of UICC subscriber and equipment related data in a useable format.	Not as expected					
Analysis:	Partial results achieved					

262

263 1.2.124 MDT-10 – iPad Mini (GSM)

Test Case MDT-10 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-10 Acquire UICC memory and review supported data elements (i.e., Abbreviated Dialing Numbers, Last Numbers Dialed, SMS/EMS text messages, and location related data: LOCI, GPRSLOCI).	
Assertions:	MDT-AO-04 If a mobile device forensic tool completes acquisition of the target UICC without error then all acquired data shall be presented in a useable format.	

Test Case MDT-10 Access Data MPE+ v5.5.2.60						
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Wed Sep 3 14:50:16 EDT 2014					
Device:	iPadMini GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB					
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Sep 3 14:50:16 EDT 2014 Acquisition finished: Thu Sep 4 13:54:04 EDT 2014</p> <p>All ADNs were acquired LNDs were acquired Date/Time Stamps correctly reported for LNDs ALL text messages (SMS, EMS) were acquired All date/time stamps were reported for text messages Correct status flags were reported for text messages Sender and Recipient phone numbers associated with text messages were correctly reported Deleted text message data was recovered LOCI data was acquired GPRSLOCI data was acquired</p> <p>Notes: French contact entry was incorrectly reported as Aur[0x05]lien instead of Aurélien.</p>					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-04 Acquisition of all UICC supported data elements in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-04 Acquisition of all UICC supported data elements in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-AO-04 Acquisition of all UICC supported data elements in a useable format.	Not as expected					
Analysis:	Partial results achieved					

264

265 1.2.125 MDT-11 – iPad Mini (GSM)

Test Case MDT-11 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-11 Acquire UICC memory by selecting a combination of supported data elements.	
Assertions:	<p>MDT-AO-05 If a mobile device forensic tool provides the user with an Acquire All UICC data objects acquisition option then the tool shall complete the acquisition of all data objects without error. MDT-AO-06 If a mobile device forensic tool provides the user with an Select All individual UICC data objects then the tool shall complete the acquisition of all individually selected data objects without error. MDT-AO-07 If a mobile device forensic tool provides the user with the ability to Select Individual UICC data objects for acquisition then the tool shall acquire each exclusive data object without error.</p>	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Wed Sep 3 14:50:50 EDT 2014	
Device:	iPadMini GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB	
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Sep 3 14:50:50 EDT 2014 Acquisition finished: Thu Sep 4 13:55:44 EDT 2014</p> <p>Acquire All acquisition was successful Select All acquisition was successful Individual data element acquisition was successful</p>	
Results:		

Test Case MDT-11 Access Data MPE+ v5.5.2.60		
	Assertion & Expected Result	Actual Result
	MDT-AO-05 Acquire-all UICC data objects acquisition.	as expected
	MDT-AO-06 Select-all UICC data objects acquisition.	as expected
	MDT-AO-07 Select-individual UICC data objects acquisition.	as expected
Analysis:	Expected results achieved	

266

267 1.2.126 MDT-12 – iPad Mini (GSM)

Test Case MDT-12 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-12 After a successful mobile device internal memory, alter the case file via third-party means and attempt to re-open the case.					
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Wed Sep 3 14:46:27 EDT 2014					
Device:	iPadMini GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Sep 3 14:46:27 EDT 2014 Acquisition finished: Thu Sep 4 13:46:15 EDT 2014</p> <p>Notification of modified device memory data was successful</p> <p>Notes: Case file data can be modified without warning when re-opening the test case. However, when the case is re-opened the original data is reported. Calendar entries were not reported when re-opening a saved case file (AD1 image).</p>					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-08 Notification of modified device case data.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-08 Notification of modified device case data.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-08 Notification of modified device case data.	as expected					
Analysis:	Expected results achieved					

268

269 1.2.127 MDT-13 – iPad Mini (GSM)

Test Case MDT-13 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-13 After a successful UICC acquisition, alter the case file via third-party means and attempt to re-open the case.	
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Wed Sep 3 14:51:23 EDT 2014	
Device:	iPadMini GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB	
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Sep 3 14:51:23 EDT 2014 Acquisition finished: Thu Sep 4 13:56:20 EDT 2014</p> <p>Notification of modified SIM data was successful</p>	

Test Case MDT-13 Access Data MPE+ v5.5.2.60						
	Notes: Case file data can be modified without warning when re-opening the test case. However, when the case is re-opened the original data is reported. Tool only gives warning when file size changes					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-08 Notification of modified device case data.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-08 Notification of modified device case data.	as expected
	Assertion & Expected Result	Actual Result				
MDT-AO-08 Notification of modified device case data.	as expected					
Analysis:	Expected results achieved					

270 **1.2.128 MDT-14 – iPad Mini (GSM)**

Test Case MDT-14 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-14 Attempt acquisition of a password-protected UICC.					
Assertions:	MDT-AO-09 If the UICC is password-protected then the mobile device forensic tool shall provide the examiner with the opportunity to input the PIN before acquisition.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Wed Sep 3 14:51:50 EDT 2014					
Device:	iPadMini_GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Sep 3 14:51:50 EDT 2014 Acquisition finished: Thu Sep 4 13:57:45 EDT 2014 Ability to enter PIN on protected media before acquisition was successful					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-09 Acquisition of password protected UICC.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-09 Acquisition of password protected UICC.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-09 Acquisition of password protected UICC.	as expected					
Analysis:	Expected results achieved					

271

272 **1.2.129 MDT-15 – iPad Mini (GSM)**

Test Case MDT-15 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-15 Begin acquisition on a PIN protected UICC to determine if the tool provides an accurate count of the remaining number of PIN attempts and if the PIN attempts are decremented when entering an incorrect value.	
Assertions:	MDT-AO-10 If a mobile device forensic tool provides the examiner with the remaining number of authentication attempts then the application should provide an accurate count of the remaining PIN attempts.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Wed Sep 3 14:52:15 EDT 2014	
Device:	iPadMini GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB	
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Sep 3 14:52:15 EDT 2014 Acquisition finished: Thu Sep 4 13:58:07 EDT 2014 The remaining number of PIN attempts were properly displayed	
Results:		

Test Case MDT-15 Access Data MPE+ v5.5.2.60		
	Assertion & Expected Result	Actual Result
	MDT-AO-10 Remaining number of PIN attempts properly displayed.	as expected
Analysis:	Expected results achieved	

273

274 1.2.130 MDT-16 – iPad Mini (GSM)

Test Case MDT-16 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-16 Begin acquisition on a UICC whose PIN attempts have been exhausted to determine if the tool provides an accurate count of the remaining number of PUK attempts and if the PUK attempts are decremented when entering an incorrect value.	
Assertions:	MDT-AO-11 If a mobile device forensic tool provides the examiner with the remaining number of PUK attempts then the application should provide an accurate count of the remaining PUK attempts.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Fri Sep 5 14:54:33 EDT 2014	
Device:	iPadMini GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB	
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Sep 5 14:54:33 EDT 2014 Acquisition finished: Fri Sep 5 15:48:51 EDT 2014 Remaining number of PUK attempts were properly displayed	
Results:	Assertion & Expected Result	Actual Result
	MDT-AO-11 Remaining number of PUK attempts properly displayed.	as expected
Analysis:	Expected results achieved	

275

276 1.2.131 MDT-19 – iPad Mini (GSM)

Test Case MDT-19 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-19 Acquire mobile device internal memory and review data containing non-ASCII characters.	
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Wed Sep 3 14:46:55 EDT 2014	
Device:	iPadMini GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Sep 3 14:46:55 EDT 2014 Acquisition finished: Thu Sep 4 13:50:14 EDT 2014 Non-ASCII Address book entries were acquired and properly displayed Non-ASCII text messages were acquired and properly displayed	
Results:		

Test Case MDT-19 Access Data MPE+ v5.5.2.60		
	Assertion & Expected Result	Actual Result
	MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected
Analysis:	Expected results achieved	

277

278 1.2.132 MDT-20 – iPad Mini (GSM)

Test Case MDT-20 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-20 Acquire UICC memory and review data containing non-ASCII characters.	
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Wed Sep 3 14:52:40 EDT 2014	
Device:	iPadMini_GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB	
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Sep 3 14:52:40 EDT 2014 Acquisition finished: Thu Sep 4 13:58:30 EDT 2014 Non-ASCII ADNs were acquired and properly displayed Non-ASCII text messages were acquired and properly displayed	
Results:	Assertion & Expected Result	Actual Result
	MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected
Analysis:	Expected results achieved	

279

280 1.2.133 MDT-22 – iPad Mini (GSM)

Test Case MDT-22 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-22 Acquire mobile device internal memory and review hash values for vendor supported data objects.	
Assertions:	MDT-AO-15 If the mobile device forensic tool supports hashing for individual data objects then the tool shall present the user with a hash value for each supported data object.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Wed Sep 3 14:47:33 EDT 2014	
Device:	iPadMini_GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Sep 3 14:47:33 EDT 2014 Acquisition finished: Thu Sep 4 13:50:36 EDT 2014 Hash values were properly reported for individually acquired device data elements Notes: Hashes were not reported in preview pane but they were included in the exported (.pdf file format) report.	

Test Case MDT-22 Access Data MPE+ v5.5.2.60		
Results:		
	Assertion & Expected Result	Actual Result
	MDT-AO-15 Hash values for individual data and case presented in a useable format.	Not as expected
Analysis:	Partial results achieved	

281

282 1.2.134 MDT-24 – iPad Mini (GSM)

Test Case MDT-24 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-24 Acquire mobile device internal memory and review data containing GPS longitude and latitude coordinates					
Assertions:	MDT-AO-16 If the mobile device forensic tool supports acquisition of GPS data then the tool shall present the user with the longitude and latitude coordinates for all GPS-related data in a useable format.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Wed Sep 3 15:01:21 EDT 2014					
Device:	iPadMini GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Sep 3 15:01:21 EDT 2014 Acquisition finished: Thu Sep 4 13:52:17 EDT 2014 GPS Coordinate data was successfully acquired					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-16 Acquisition of GPS related data presented in a useable format.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-16 Acquisition of GPS related data presented in a useable format.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-16 Acquisition of GPS related data presented in a useable format.	as expected					
Analysis:	Expected results achieved					

283

284 1.2.135 MDT-01 – iPad Mini (CDMA)

Test Case MDT-01 Access Data MPE+ v5.5.2.60				
Case Summary:	MDT-01 Acquire mobile device internal memory over tool-supported interfaces (e.g., cable, Bluetooth, IrDA).			
Assertions:	MDT-CA-01 If a mobile device forensic tool provides support for connectivity of the target device then the tool shall successfully recognize the target device via all vendor supported interfaces (e.g., cable, Bluetooth, IrDA).			
Tester Name:	jrr			
Test Host:	pN100919			
Test Date:	Tue Jul 15 13:26:40 EDT 2014			
Device:	iPadMini CDMA			
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable			
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Jul 15 13:26:40 EDT 2014 Acquisition finished: Tue Jul 15 13:29:52 EDT 2014 Device connectivity was established via supported interface			
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr></table>		Assertion & Expected Result	Actual Result
Assertion & Expected Result	Actual Result			

Test Case MDT-01 Access Data MPE+ v5.5.2.60		
	MDT-CA-01 Device connectivity via supported interfaces.	as expected
Analysis:	Expected results achieved	

285

286 1.2.136 MDT-02 – iPad Mini (CDMA)

Test Case MDT-02 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-02 Begin mobile device internal memory acquisition and interrupt connectivity by interface disengagement.					
Assertions:	MDT-CA-02 If connectivity between the mobile device and mobile device forensic tool is disrupted then the tool shall notify the user that connectivity has been disrupted.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Tue Jul 15 13:30:38 EDT 2014					
Device:	iPadMini CDMA					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Jul 15 13:30:38 EDT 2014 Acquisition finished: Tue Jul 15 13:48:45 EDT 2014 Device acquisition disruption notification was successful					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-02 Notification of device acquisition disruption.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-02 Notification of device acquisition disruption.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-02 Notification of device acquisition disruption.	as expected					
Analysis:	Expected results achieved					

287

288 1.2.137 MDT-03 – iPad Mini (CDMA)

Test Case MDT-03 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-03 Acquire mobile device internal memory and review reported data via the preview-pane or generated reports for readability.					
Assertions:	MDT-CA-03 If a mobile device forensic tool completes acquisition of the target device without error then the tool shall have the ability to present acquired data objects in a useable format via either a preview-pane or generated report.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Tue Jul 15 15:28:11 EDT 2014					
Device:	iPadMini CDMA					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Jul 15 15:28:11 EDT 2014 Acquisition finished: Thu Jul 15 15:36:22 EDT 2014</p> <p>Readability and completeness of acquired data was successful</p> <p>Notes: When saving report in .pdf format the active stand-alone data files were not reported.</p>					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-03 Readability and completeness of acquired data</td><td>Not as</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-03 Readability and completeness of acquired data	Not as
Assertion & Expected Result	Actual Result					
MDT-CA-03 Readability and completeness of acquired data	Not as					

Test Case MDT-03 Access Data MPE+ v5.5.2.60		
	via supported reports.	expected
Analysis:	Partial results achieved	

289

290 1.2.138 MDT-04 – iPad Mini (CDMA)

Test Case MDT-04 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-04 Acquire mobile device internal memory and review reported subscriber and equipment related information (e.g., IMSI, IMEI, MEID/ESN, MSISDN).					
Assertions:	MDT-CA-04 If a mobile device forensic tool completes acquisition of the target device without error then subscriber and equipment related information shall be presented in a useable format.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Thu Jul 17 16:00:12 EDT 2014					
Device:	iPad CDMA					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Jul 17 16:00:12 EDT 2014 Acquisition finished: Thu Jul 17 16:00:28 EDT 2014</p> <p>IMEI was acquired</p> <p>Notes: MEID not reported, says not applicable. Model Number reported doesn't match the model number displayed on the tablet. ICCID was not reported.</p>					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected					
Analysis:	Partial results achieved					

291

292 1.2.139 MDT-05 – iPad Mini (CDMA)

Test Case MDT-05 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-05 Acquire mobile device internal memory and review supported data elements (i.e., PIM data, call logs, SMS, MMS, stand-alone files: audio, pictures, video, application related data: documents, spreadsheets, presentations, social-media data and Internet related data: bookmarks, visited sites).
Assertions:	MDT-CA-05 If a mobile device forensic tool completes acquisition of the target device without error then all supported data elements shall be presented in a useable format.
Tester Name:	jrr
Test Host:	pN100919
Test Date:	Tue Jul 15 16:38:40 EDT 2014
Device:	iPadMini CDMA
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Jul 15 16:38:40 EDT 2014 Acquisition finished: Tue Jul 15 16:52:42 EDT 2014</p>

Test Case MDT-05 Access Data MPE+ v5.5.2.60						
	<p>All address book entries were successfully acquired Basic PIM related data was acquired Partial Maximum length PIM related data was acquired ALL text messages (SMS, EMS) were acquired Correct date/time stamps were reported for all text messages Correct status flags were reported for all text messages Sender and Recipient phone numbers associated with text messages were correctly reported ALL MMS messages (Audio, Image, Video) were acquired ALL stand-alone data files (Audio, Image, Video) were acquired All application data was acquired All Internet related data was acquired Partial Social media related data was acquired</p> <p>Notes: Active contact entry with long name was partially acquired. Only the first name and very last name was acquired, everything in between was not acquired. Active contact entry with regular name containing a middle name was partially acquired. Middle name was not acquired. When a case file (AD1) is re-opened calendar entries are not present. Screenshots were reported for Twitter, Facebook and LinkedIn conversations. Graphic files from LinkedIn were acquired.</p>					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Not as expected					
Analysis:	Partial results achieved					

293

294 1.2.140 MDT-06 – iPad Mini (CDMA)

Test Case MDT-06 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-06 Acquire mobile device internal memory by selecting a combination of supported data elements.
Assertions:	<p>MDT-CA-06 If a mobile device forensic tool provides the user with an Acquire All device data objects acquisition option then the tool shall complete the acquisition of all data objects without error.</p> <p>MDT-CA-07 If a mobile device forensic tool provides the user with an Select All individual device data objects then the tool shall complete the acquisition of all individually selected data objects without error.</p> <p>MDT-CA-08 If a mobile device forensic tool provides the user with the ability to Select Individual device data objects for acquisition then the tool shall acquire each exclusive data object without error.</p> <p>MDT-CA-09 If a mobile device forensic tool completes two consecutive logical acquisitions of the target device without error then the payload (data objects) on the mobile device shall remain consistent.</p>
Tester Name:	jrr
Test Host:	pN100919
Test Date:	Wed Jul 16 09:40:53 EDT 2014
Device:	iPadMini_CDMA
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Jul 16 09:40:53 EDT 2014 Acquisition finished: Wed Jul 16 10:00:22 EDT 2014</p> <p>Acquire All acquisition was successful</p> <p>Select All acquisition was successful</p> <p>Individual data element acquisition was successful</p>
Results:	

Test Case MDT-06 Access Data MPE+ v5.5.2.60		
	Assertion & Expected Result	Actual Result
	MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected
	MDT-CA-07 Select-all mobile device data objects acquisition.	as expected
	MDT-CA-08 Select-individual mobile device data objects acquisition.	as expected
	MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected
Analysis:	Expected results achieved	

295

296 1.2.141 MDT-12 – iPad Mini (CDMA)

Test Case MDT-12 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-12 After a successful mobile device internal memory, alter the case file via third-party means and attempt to re-open the case.					
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Wed Jul 16 10:02:11 EDT 2014					
Device:	iPadMini_CDMA					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Jul 16 10:02:11 EDT 2014 Acquisition finished: Wed Jul 16 10:25:17 EDT 2014 Notification of modified device memory data was successful Notes: Case file data can be modified without warning when re-opening the test case. However, when the case is re-opened the original data is reported.					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-08 Notification of modified device case data.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-08 Notification of modified device case data.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-08 Notification of modified device case data.	as expected					
Analysis:	Expected results achieved					

297

298 1.2.142 MDT-19 – iPad Mini (CDMA)

Test Case MDT-19 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-19 Acquire mobile device internal memory and review data containing non-ASCII characters.	
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Wed Jul 16 10:31:49 EDT 2014	
Device:	iPadMini_CDMA	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Jul 16 10:31:49 EDT 2014 Acquisition finished: Wed Jul 16 10:46:32 EDT 2014</p>	

Test Case MDT-19 Access Data MPE+ v5.5.2.60		
	Non-ASCII Address book entries were acquired but not properly displayed Non-ASCII text messages were acquired and properly displayed Notes: Non-ASCII characters displayed in different order for address book entries.	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	Not as expected
Analysis:	Partial results achieved	

299

300 1.2.143 MDT-22 – iPad Mini (CDMA)

Test Case MDT-22 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-22 Acquire mobile device internal memory and review hash values for vendor supported data objects.					
Assertions:	MDT-AO-15 If the mobile device forensic tool supports hashing for individual data objects then the tool shall present the user with a hash value for each supported data object.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Wed Jul 16 15:47:23 EDT 2014					
Device:	iPadMini CDMA					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Jul 16 15:47:23 EDT 2014 Acquisition finished: Wed Jul 16 16:09:01 EDT 2014 Hash values were properly reported for individually acquired device data elements Notes: Hashes were not reported in preview pane but they were included in the exported (.pdf file format) report.					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-15 Hash values for individual data and case presented in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-15 Hash values for individual data and case presented in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-AO-15 Hash values for individual data and case presented in a useable format.	Not as expected					
Analysis:	Partial results achieved					

301

302 1.2.144 MDT-24 – iPad Mini (CDMA)

Test Case MDT-24 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-24 Acquire mobile device internal memory and review data containing GPS longitude and latitude coordinates	
Assertions:	MDT-AO-16 If the mobile device forensic tool supports acquisition of GPS data then the tool shall present the user with the longitude and latitude coordinates for all GPS-related data in a useable format.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Wed Jul 16 16:14:36 EDT 2014	
Device:	iPadMini CDMA	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	

Test Case MDT-24 Access Data MPE+ v5.5.2.60						
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Jul 16 16:14:36 EDT 2014 Acquisition finished: Wed Jul 16 16:38:46 EDT 2014 GPS Coordinate data was successfully acquired Notes: GPS latitude and longitude were not reported, but the physical address and a map screenshot of the place were reported.					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-16 Acquisition of GPS related data presented in a useable format.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-16 Acquisition of GPS related data presented in a useable format.	as expected
	Assertion & Expected Result	Actual Result				
MDT-AO-16 Acquisition of GPS related data presented in a useable format.	as expected					
Analysis:	Expected results achieved					

303

304 1.2.145 MDT-01 – iPhone 5 (GSM)

Test Case MDT-01 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-01 Acquire mobile device internal memory over tool-supported interfaces (e.g., cable, Bluetooth, IrDA).					
Assertions:	MDT-CA-01 If a mobile device forensic tool provides support for connectivity of the target device then the tool shall successfully recognize the target device via all vendor supported interfaces (e.g., cable, Bluetooth, IrDA).					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Thu Jul 31 11:26:16 EDT 2014					
Device:	iPhone5 GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Jul 31 11:26:16 EDT 2014 Acquisition finished: Thu Jul 31 16:39:24 EDT 2014 Device connectivity was established via supported interface					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-01 Device connectivity via supported interfaces.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-01 Device connectivity via supported interfaces.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-01 Device connectivity via supported interfaces.	as expected					
Analysis:	Expected results achieved					

305

306 1.2.146 MDT-02 – iPhone 5 (GSM)

Test Case MDT-02 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-02 Begin mobile device internal memory acquisition and interrupt connectivity by interface disengagement.	
Assertions:	MDT-CA-02 If connectivity between the mobile device and mobile device forensic tool is disrupted then the tool shall notify the user that connectivity has been disrupted.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Thu Jul 31 11:26:57 EDT 2014	
Device:	iPhone5_GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	

Test Case MDT-02 Access Data MPE+ v5.5.2.60						
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Jul 31 11:26:57 EDT 2014 Acquisition finished: Thu Jul 31 16:40:09 EDT 2014 Device acquisition disruption notification was successful					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-02 Notification of device acquisition disruption.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-02 Notification of device acquisition disruption.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-02 Notification of device acquisition disruption.	as expected					
Analysis:	Expected results achieved					

307

308 1.2.147 MDT-03 – iPhone 5 (GSM)

Test Case MDT-03 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-03 Acquire mobile device internal memory and review reported data via the preview-pane or generated reports for readability.					
Assertions:	MDT-CA-03 If a mobile device forensic tool completes acquisition of the target device without error then the tool shall have the ability to present acquired data objects in a useable format via either a preview-pane or generated report.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Thu Jul 31 11:27:27 EDT 2014					
Device:	iPhone5 GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Jul 31 11:27:27 EDT 2014 Acquisition finished: Thu Jul 31 16:40:36 EDT 2014 Readability and completeness of acquired data was successful Notes: When generating report (.pdf file format), stand-alone data files were not reported.					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-03 Readability and completeness of acquired data via supported reports.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-03 Readability and completeness of acquired data via supported reports.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-CA-03 Readability and completeness of acquired data via supported reports.	Not as expected					
Analysis:	Partial results achieved					

309

310 1.2.148 MDT-04 – iPhone 5 (GSM)

Test Case MDT-04 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-04 Acquire mobile device internal memory and review reported subscriber and equipment related information (e.g., IMSI, IMEI, MEID/ESN, MSISDN).	
Assertions:	MDT-CA-04 If a mobile device forensic tool completes acquisition of the target device without error then subscriber and equipment related information shall be presented in a useable format.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Thu Jul 31 11:27:59 EDT 2014	
Device:	iPhone5 GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	

Test Case MDT-04 Access Data MPE+ v5.5.2.60					
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Jul 31 11:27:59 EDT 2014 Acquisition finished: Thu Jul 31 16:43:52 EDT 2014</p> <p>IMEI was acquired</p> <p>Notes: The MSISDN was not reported. Model Number reported doesn't match the model number displayed on the tablet.</p>				
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.</td><td>Not as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected
Assertion & Expected Result	Actual Result				
MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected				
Analysis:	Partial results achieved				

311

312 1.2.149 MDT-05 – iPhone 5 (GSM)

Test Case MDT-05 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-05 Acquire mobile device internal memory and review supported data elements (i.e., PIM data, call logs, SMS, MMS, stand-alone files: audio, pictures, video, application related data: documents, spreadsheets, presentations, social-media data and Internet related data: bookmarks, visited sites).
Assertions:	MDT-CA-05 If a mobile device forensic tool completes acquisition of the target device without error then all supported data elements shall be presented in a useable format.
Tester Name:	jrr
Test Host:	pN100919
Test Date:	Thu Jul 31 11:28:34 EDT 2014
Device:	iPhone5 GSM
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Jul 31 11:28:34 EDT 2014 Acquisition finished: Thu Jul 31 16:45:52 EDT 2014</p> <p>All address book entries were successfully acquired Basic PIM related data was acquired Partial Maximum length PIM related data was acquired All Call Logs (incoming, outgoing, missed) were acquired All Call Log date/time stamps data were correctly reported ALL text messages (SMS, EMS) were acquired Correct date/time stamps were reported for all text messages Correct status flags were reported for all text messages Sender and Recipient phone numbers associated with text messages were correctly reported ALL MMS messages (Audio, Image, Video) were acquired ALL stand-alone data files (Audio, Image, Video) were acquired Application data was not acquired All Internet related data was acquired Partial Social media related data was acquired</p> <p>Notes: Active contact entry with long name was partially acquired. Only the first name and very last name was acquired, everything in between was not acquired. Active contact entry with regular name containing a middle name was partially acquired. Middle name was not acquired. When a case file (AD1) is re-opened calendar entries are not present. Screenshots were reported for Twitter conversations only.</p>

Test Case MDT-05 Access Data MPE+ v5.5.2.60		
Results:	Assertion & Expected Result	
	Actual Result	
	MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Not as expected
Analysis:	Partial results achieved	

313

314 1.2.150 MDT-06- iPhone 5 (GSM)

Test Case MDT-06 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-06 Acquire mobile device internal memory by selecting a combination of supported data elements.	
Assertions:	<p>MDT-CA-06 If a mobile device forensic tool provides the user with an Acquire All device data objects acquisition option then the tool shall complete the acquisition of all data objects without error.</p> <p>MDT-CA-07 If a mobile device forensic tool provides the user with an Select All individual device data objects then the tool shall complete the acquisition of all individually selected data objects without error.</p> <p>MDT-CA-08 If a mobile device forensic tool provides the user with the ability to Select Individual device data objects for acquisition then the tool shall acquire each exclusive data object without error.</p> <p>MDT-CA-09 If a mobile device forensic tool completes two consecutive logical acquisitions of the target device without error then the payload (data objects) on the mobile device shall remain consistent.</p>	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Thu Jul 31 11:29:06 EDT 2014	
Device:	iPhone5 GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60</p> <p>Acquisition started: Thu Jul 31 11:29:06 EDT 2014</p> <p>Acquisition finished: Thu Jul 31 16:54:06 EDT 2014</p> <p>Acquire All acquisition was successful</p> <p>Select All acquisition was successful</p> <p>Individual data element acquisition was successful</p>	
Results:	Assertion & Expected Result	
	Actual Result	
	MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected
	MDT-CA-07 Select-all mobile device data objects acquisition.	as expected
	MDT-CA-08 Select-individual mobile device data objects acquisition.	as expected
	MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected
Analysis:	Expected results achieved	

315

316 1.2.151 MDT-07 – iPhone 5 (GSM)

Test Case MDT-07 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-07 Acquire UICC memory over supported interfaces (e.g., PC/SC reader).
Assertions:	MDT-AO-01 If a mobile device forensic tool provides support for connectivity of the target UICC then the tool shall successfully recognize

Test Case MDT-07 Access Data MPE+ v5.5.2.60						
	the target SIM via all tool-supported interfaces (e.g., PC/SC reader, proprietary reader, smart phone itself).					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Fri Aug 1 09:04:37 EDT 2014					
Device:	iPhone5_GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Aug 1 09:04:37 EDT 2014 Acquisition finished: Fri Aug 1 11:03:34 EDT 2014 UICC connectivity was established via supported interface					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-01 UICC connectivity via supported interfaces.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-01 UICC connectivity via supported interfaces.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-01 UICC connectivity via supported interfaces.	as expected					
Analysis:	Expected results achieved					

317

318 1.2.152 MDT-08 – iPhone 5 (GSM)

Test Case MDT-08 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-08 Begin UICC acquisition and interrupt connectivity by interface disengagement.					
Assertions:	MDT-AO-02 If a mobile device forensic tool loses connectivity with the UICC reader then the tool shall notify the user that connectivity has been disrupted.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Fri Aug 1 09:05:25 EDT 2014					
Device:	iPhone5_GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Aug 1 09:05:25 EDT 2014 Acquisition finished: Fri Aug 1 11:05:01 EDT 2014 Media acquisition disruption notification was not successful Notes: No error message when disrupting connectivity, it stopped and reported the data recovered until connectivity was disrupted.					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-02 Notification of SIM acquisition disruption.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-02 Notification of SIM acquisition disruption.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-AO-02 Notification of SIM acquisition disruption.	Not as expected					
Analysis:	Expected results not achieved					

319

320

321 1.2.153 MDT-09 – iPhone 5 (GSM)

Test Case MDT-09 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-09Acquire UICC memory and review reported subscriber and equipment related information (i.e., SPN, ICCID, IMSI, MSISDN).	
Assertions:	MDT-AO-03 If a mobile device forensic tool completes acquisition of the target UICC without error then the subscriber and equipment related data shall be presented in a useable format.	

Test Case MDT-09 Access Data MPE+ v5.5.2.60						
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Fri Aug 1 09:06:07 EDT 2014					
Device:	iPhone5 GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Aug 1 09:06:07 EDT 2014 Acquisition finished: Fri Aug 1 11:06:18 EDT 2014 SPN was not acquired ICCID was acquired IMSI was acquired MSISDN was acquired					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-03 Acquisition of UICC subscriber and equipment related data in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-03 Acquisition of UICC subscriber and equipment related data in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-AO-03 Acquisition of UICC subscriber and equipment related data in a useable format.	Not as expected					
Analysis:	Partial results not achieved					

322

323 1.2.154 MDT-10 – iPhone 5 (GSM)

Test Case MDT-10 Access Data MPE+ v5.5.2.60								
Case Summary:	MDT-10 Acquire UICC memory and review supported data elements (i.e., Abbreviated Dialing Numbers, Last Numbers Dialed, SMS/EMS text messages, and location related data: LOCI, GPRSLOCI).							
Assertions:	MDT-AO-04 If a mobile device forensic tool completes acquisition of the target UICC without error then all acquired data shall be presented in a useable format.							
Tester Name:	jrr							
Test Host:	pN100919							
Test Date:	Fri Aug 1 09:06:55 EDT 2014							
Device:	iPhone5 GSM							
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB							
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Aug 1 09:06:55 EDT 2014 Acquisition finished: Fri Aug 1 11:06:44 EDT 2014</p> <p>All ADNs were acquired LNDs were acquired Date/Time Stamps correctly reported for LNDs ALL text messages (SMS, EMS) were acquired All date/time stamps were reported for text messages Correct status flags were reported for text messages Sender and Recipient phone numbers associated with text messages were correctly reported Deleted text message data was recovered LOCI data was acquired GPRSLOCI data was acquired</p> <p>Notes: French contact entry was incorrectly reported as Aur[0x05]lien instead of Aurélien.</p>							
Results:	<table border="1"> <thead> <tr> <th>Assertion</th><th>Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT AO-04 Acquisition of all UICC supported data elements in a useable format.</td><td></td><td>Not as expected</td></tr> </tbody> </table>		Assertion	Expected Result	Actual Result	MDT AO-04 Acquisition of all UICC supported data elements in a useable format.		Not as expected
Assertion	Expected Result	Actual Result						
MDT AO-04 Acquisition of all UICC supported data elements in a useable format.		Not as expected						

Test Case MDT-10 Access Data MPE+ v5.5.2.60	
Analysis:	Partial results achieved

324

325 1.2.155 MDT-11 – iPhone 5 (GSM)

Test Case MDT-11 Access Data MPE+ v5.5.2.60									
Case Summary:	MDT-11 Acquire UICC memory by selecting a combination of supported data elements.								
Assertions:	MDT-AO-05 If a mobile device forensic tool provides the user with an Acquire All UICC data objects acquisition option then the tool shall complete the acquisition of all data objects without error. MDT-AO-06 If a mobile device forensic tool provides the user with an Select All individual UICC data objects then the tool shall complete the acquisition of all individually selected data objects without error. MDT-AO-07 If a mobile device forensic tool provides the user with the ability to Select Individual UICC data objects for acquisition then the tool shall acquire each exclusive data object without error.								
Tester Name:	jrr								
Test Host:	pN100919								
Test Date:	Fri Aug 1 09:07:38 EDT 2014								
Device:	iPhone5 GSM								
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB								
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Aug 1 09:07:38 EDT 2014 Acquisition finished: Fri Aug 1 11:08:13 EDT 2014 Acquire All acquisition was successful Select All acquisition was successful Individual data element acquisition was successful								
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-AO-05 Acquire-all UICC data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-AO-06 Select-all UICC data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-AO-07 Select-individual UICC data objects acquisition.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-AO-05 Acquire-all UICC data objects acquisition.	as expected	MDT-AO-06 Select-all UICC data objects acquisition.	as expected	MDT-AO-07 Select-individual UICC data objects acquisition.	as expected
Assertion & Expected Result	Actual Result								
MDT-AO-05 Acquire-all UICC data objects acquisition.	as expected								
MDT-AO-06 Select-all UICC data objects acquisition.	as expected								
MDT-AO-07 Select-individual UICC data objects acquisition.	as expected								
Analysis:	Expected results achieved								

326

327 1.2.156 MDT-12 – iPhone 5 (GSM)

Test Case MDT-12 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-12 After a successful mobile device internal memory, alter the case file via third-party means and attempt to re-open the case.
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.
Tester Name:	jrr
Test Host:	pN100919
Test Date:	Thu Jul 31 11:29:36 EDT 2014
Device:	iPhone5 GSM
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Jul 31 11:29:36 EDT 2014 Acquisition finished: Thu Jul 31 16:54:46 EDT 2014 Notification of modified device memory data was successful

Test Case MDT-12 Access Data MPE+ v5.5.2.60		
	Notes: Case file data can be modified without warning when re-opening the test case. However, when the case is re-opened the original data is reported.	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-AO-08 Notification of modified device case data.	as expected
Analysis:	Expected results achieved	

328

329 1.2.157 MDT-13 – iPhone 5 (GSM)

Test Case MDT-13 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-13 After a successful UICC acquisition, alter the case file via third-party means and attempt to re-open the case.					
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Fri Aug 1 09:08:54 EDT 2014					
Device:	iPhone5_GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Aug 1 09:08:54 EDT 2014 Acquisition finished: Fri Aug 1 11:08:50 EDT 2014 Notification of modified SIM data was successful Notes: Case file data can be modified without warning when re-opening the test case. However, when the case is re-opened the original data is reported.					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-08 Notification of modified device case data.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-08 Notification of modified device case data.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-08 Notification of modified device case data.	as expected					
Analysis:	Expected results achieved					

330

331 1.2.158 MDT-14 – iPhone 5 (GSM)

Test Case MDT-14 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-14 Attempt acquisition of a password-protected UICC.	
Assertions:	MDT-AO-09 If the UICC is password-protected then the mobile device forensic tool shall provide the examiner with the opportunity to input the PIN before acquisition.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Fri Aug 1 09:09:43 EDT 2014	
Device:	iPhone5_GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB	
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Aug 1 09:09:43 EDT 2014 Acquisition finished: Fri Aug 1 11:10:15 EDT 2014 Ability to enter PIN on protected media before acquisition was successful	

Test Case MDT-14 Access Data MPE+ v5.5.2.60		
Results:		
	Assertion & Expected Result	Actual Result
	MDT-AO-09 Acquisition of password protected UICC.	as expected
Analysis:	Expected results achieved	

332

333 1.2.159 MDT-15 – iPhone 5 (GSM)

Test Case MDT-15 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-15 Begin acquisition on a PIN protected UICC to determine if the tool provides an accurate count of the remaining number of PIN attempts and if the PIN attempts are decremented when entering an incorrect value.	
Assertions:	MDT-AO-10 If a mobile device forensic tool provides the examiner with the remaining number of authentication attempts then the application should provide an accurate count of the remaining PIN attempts.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Fri Aug 1 09:10:19 EDT 2014	
Device:	iPhone5_GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB	
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Aug 1 09:10:19 EDT 2014 Acquisition finished: Fri Aug 1 11:10:38 EDT 2014 The remaining number of PIN attempts were properly displayed	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-AO-10 Remaining number of PIN attempts properly displayed.	as expected
Analysis:	Expected results achieved	

334

335 1.2.160 MDT-16 – iPhone 5 (GSM)

Test Case MDT-16 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-16 Begin acquisition on a UICC whose PIN attempts have been exhausted to determine if the tool provides an accurate count of the remaining number of PUK attempts and if the PUK attempts are decremented when entering an incorrect value.	
Assertions:	MDT-AO-11 If a mobile device forensic tool provides the examiner with the remaining number of PUK attempts then the application should provide an accurate count of the remaining PUK attempts.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Fri Sep 5 14:34:14 EDT 2014	
Device:	iPhone5_GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB	
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Sep 5 14:34:14 EDT 2014 Acquisition finished: Fri Sep 5 15:36:06 EDT 2014 Remaining number of PUK attempts were properly displayed	
Results:		

Test Case MDT-16 Access Data MPE+ v5.5.2.60		
	Assertion & Expected Result	Actual Result
	MDT-AO-11 Remaining number of PUK attempts properly displayed.	as expected
Analysis:	Expected results achieved	

336

337 1.2.161 MDT-19 – iPhone 5 (GSM)

Test Case MDT-19 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-19 Acquire mobile device internal memory and review data containing non-ASCII characters.	
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Thu Jul 31 11:30:10 EDT 2014	
Device:	iPhone5_GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Jul 31 11:30:10 EDT 2014 Acquisition finished: Thu Jul 31 16:59:03 EDT 2014 Non-ASCII Address book entries were acquired and properly displayed Non-ASCII text messages were acquired and properly displayed	
Results:	Assertion & Expected Result	Actual Result
	MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected
Analysis:	Expected results achieved	

338

339 1.2.162 MDT-20 – iPhone 5 (GSM)

Test Case MDT-20 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-20 Acquire UICC memory and review data containing non-ASCII characters.	
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Fri Aug 1 09:13:41 EDT 2014	
Device:	iPhone5_GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB	
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Aug 1 09:13:41 EDT 2014 Acquisition finished: Fri Aug 1 11:11:05 EDT 2014 Non-ASCII ADNs were acquired and properly displayed Non-ASCII text messages were acquired and properly displayed	
Results:	Assertion & Expected Result	Actual Result

Test Case MDT-20 Access Data MPE+ v5.5.2.60		
	MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected
Analysis:	Expected results achieved	

340

341 1.2.163 MDT-22 – iPhone 5 (GSM)

Test Case MDT-22 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-22 Acquire mobile device internal memory and review hash values for vendor supported data objects.					
Assertions:	MDT-AO-15 If the mobile device forensic tool supports hashing for individual data objects then the tool shall present the user with a hash value for each supported data object.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Thu Jul 31 11:30:43 EDT 2014					
Device:	iPhone5 GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Jul 31 11:30:43 EDT 2014 Acquisition finished: Thu Jul 31 17:00:00 EDT 2014</p> <p>Hash values were properly reported for individually acquired device data elements</p> <p>Notes: Hashes were not reported in preview pane but they were included in the exported (.pdf file format) report.</p>					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-15 Hash values for individual data and case presented in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-15 Hash values for individual data and case presented in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-AO-15 Hash values for individual data and case presented in a useable format.	Not as expected					
Analysis:	Partial results achieved					

342

343 1.2.164 MDT-24 – iPhone 5 (GSM)

Test Case MDT-24 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-24 Acquire mobile device internal memory and review data containing GPS longitude and latitude coordinates	
Assertions:	MDT-AO-16 If the mobile device forensic tool supports acquisition of GPS data then the tool shall present the user with the longitude and latitude coordinates for all GPS-related data in a useable format.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Thu Jul 31 11:31:31 EDT 2014	
Device:	iPhone5 GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Thu Jul 31 11:31:31 EDT 2014 Acquisition finished: Thu Jul 31 17:00:34 EDT 2014</p> <p>GPS Coordinate data was successfully acquired</p> <p>Notes:</p>	

Test Case MDT-24 Access Data MPE+ v5.5.2.60		
	GPS latitude and longitude were not reported, only the physical address of the place was reported.	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-AO-16 Acquisition of GPS related data presented in a useable format.	as expected
Analysis:	Expected results achieved	

344

345

346 1.2.165 MDT-01 – iPhone 5S (CDMA)

Test Case MDT-01 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-01 Acquire mobile device internal memory over tool-supported interfaces (e.g., cable, Bluetooth, IrDA).	
Assertions:	MDT-CA-01 If a mobile device forensic tool provides support for connectivity of the target device then the tool shall successfully recognize the target device via all vendor supported interfaces (e.g., cable, Bluetooth, IrDA).	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Tue Jul 1 15:55:13 EDT 2014	
Device:	iPhone5S CDMA	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Jul 1 15:55:13 EDT 2014 Acquisition finished: Tue Jul 1 16:01:58 EDT 2014 Device connectivity was established via supported interface	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-CA-01 Device connectivity via supported interfaces.	as expected
Analysis:	Expected results achieved	

347

348 1.2.166 MDT-02 – iPhone 5S (CDMA)

Test Case MDT-02 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-02 Begin mobile device internal memory acquisition and interrupt connectivity by interface disengagement.	
Assertions:	MDT-CA-02 If connectivity between the mobile device and mobile device forensic tool is disrupted then the tool shall notify the user that connectivity has been disrupted.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Tue Jul 1 16:03:07 EDT 2014	
Device:	iPhone5S CDMA	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Jul 1 16:03:07 EDT 2014 Acquisition finished: Tue Jul 1 16:07:08 EDT 2014 Device acquisition disruption notification was successful	

Test Case MDT-02 Access Data MPE+ v5.5.2.60		
Results:		
	Assertion & Expected Result	Actual Result
	MDT-CA-02 Notification of device acquisition disruption.	as expected
Analysis:	Expected results achieved	

349

350 1.2.167 MDT-03 – iPhone 5S (CDMA)

Test Case MDT-03 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-03 Acquire mobile device internal memory and review reported data via the preview-pane or generated reports for readability.	
Assertions:	MDT-CA-03 If a mobile device forensic tool completes acquisition of the target device without error then the tool shall have the ability to present acquired data objects in a useable format via either a preview-pane or generated report.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Wed Jul 2 10:09:56 EDT 2014	
Device:	iPhone5S_CDMA	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Jul 2 10:09:56 EDT 2014 Acquisition finished: Wed Jul 2 14:51:40 EDT 2014</p> <p>Readability and completeness of acquired data was successful</p> <p>Notes: Graphic images associated with contact entries were not displayed in the report (HTML format) when performing a logical extraction. When saving report in .pdf and .html formats the active stand-alone data files were not reported. Only the location of the graphic images sent/received via MMS messages was displayed in the HTML report. In PDF format these were displayed.</p>	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-CA-03 Readability and completeness of acquired data via supported reports.	Not as expected
Analysis:	Partial results achieved	

351

352 1.2.168 MDT-04 – iPhone 5S (CDMA)

Test Case MDT-04 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-04 Acquire mobile device internal memory and review reported subscriber and equipment related information (e.g., IMSI, IMEI, MEID/ESN, MSISDN).	
Assertions:	MDT-CA-04 If a mobile device forensic tool completes acquisition of the target device without error then subscriber and equipment related information shall be presented in a useable format.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Mon Jul 7 14:22:23 EDT 2014	
Device:	iPhone5S_CDMA	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Mon Jul 7 14:22:23 EDT 2014</p>	

Test Case MDT-04 Access Data MPE+ v5.5.2.60						
	Acquisition finished: Mon Jul 7 14:49:54 EDT 2014 IMEI was acquired Notes: Tool has iPhone 6, 1 as the device internal name. The MSISDN was not reported. MEID not reported, says not applicable. Model number reported doesn't match the model number displayed on the phone.					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected
	Assertion & Expected Result	Actual Result				
MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected					
Analysis:	Partial results achieved					

353

354 1.2.169 MDT-05 – iPhone 5S (CDMA)

Test Case MDT-05 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-05 Acquire mobile device internal memory and review supported data elements (i.e., PIM data, call logs, SMS, MMS, stand-alone files: audio, pictures, video, application related data: documents, spreadsheets, presentations, social-media data and Internet related data: bookmarks, visited sites).
Assertions:	MDT-CA-05 If a mobile device forensic tool completes acquisition of the target device without error then all supported data elements shall be presented in a useable format.
Tester Name:	jrr
Test Host:	pN100919
Test Date:	Mon Jul 7 14:56:57 EDT 2014
Device:	iPhone5S CDMA
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Mon Jul 7 14:56:57 EDT 2014 Acquisition finished: Wed Jul 9 14:41:57 EDT 2014</p> <p>All address book entries were successfully acquired Basic PIM related data was acquired Partial Maximum length PIM related data was acquired All Call Logs (incoming, outgoing, missed) were acquired All Call Log date/time stamps data were correctly reported ALL text messages (SMS, EMS) were acquired Correct date/time stamps were reported for all text messages Partial status flags were reported for text messages Sender and Recipient phone numbers associated with text messages were correctly reported ALL MMS messages (Audio, Image, Video) were acquired ALL stand-alone data files (Audio, Image, Video) were acquired Application data was not acquired All Internet related data was acquired Partial Social media related data was acquired</p> <p>Notes: Active contact entry with long name was partially acquired. Only the first name and very last name was acquired, everything in between was not acquired. Active contact entry with regular name containing a middle name was partially acquired. Middle name was not acquired. Active incoming calls status flags were incorrectly reported as missed. When a case file (AD1) is re-opened calendar entries are not present.</p>

Test Case MDT-05 Access Data MPE+ v5.5.2.60		
Results:	Assertion & Expected Result	
	Actual Result	
	MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Not as expected
Analysis:	Partial results not achieved	

355

356 1.2.170 MDT-06 – iPhone 5S (CDMA)

Test Case MDT-06 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-06 Acquire mobile device internal memory by selecting a combination of supported data elements.	
Assertions:	<p>MDT-CA-06 If a mobile device forensic tool provides the user with an Acquire All device data objects acquisition option then the tool shall complete the acquisition of all data objects without error.</p> <p>MDT-CA-07 If a mobile device forensic tool provides the user with an Select All individual device data objects then the tool shall complete the acquisition of all individually selected data objects without error.</p> <p>MDT-CA-08 If a mobile device forensic tool provides the user with the ability to Select Individual device data objects for acquisition then the tool shall acquire each exclusive data object without error.</p> <p>MDT-CA-09 If a mobile device forensic tool completes two consecutive logical acquisitions of the target device without error then the payload (data objects) on the mobile device shall remain consistent.</p>	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Thu Jul 10 09:49:47 EDT 2014	
Device:	iPhone5 CDMA	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60</p> <p>Acquisition started: Thu Jul 10 09:49:47 EDT 2014</p> <p>Acquisition finished: Thu Jul 10 14:44:39 EDT 2014</p> <p>Acquire All acquisition was successful</p> <p>Select All acquisition was successful</p> <p>Individual data element acquisition was successful</p>	
Results:	Assertion & Expected Result	
	Actual Result	
	MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected
	MDT-CA-07 Select-all mobile device data objects acquisition.	as expected
	MDT-CA-08 Select-individual mobile device data objects acquisition.	as expected
	MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected
Analysis:	Expected results achieved	

357

358 1.2.171 MDT-12 – iPhone 5S (CDMA)

Test Case MDT-12 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-12 After a successful mobile device internal memory, alter the case file via third-party means and attempt to re-open the case.	
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms	

Test Case MDT-12 Access Data MPE+ v5.5.2.60					
	disallowing or reporting data modification.				
Tester Name:	jrr				
Test Host:	pN100919				
Test Date:	Mon Jul 14 13:54:18 EDT 2014				
Device:	iPhone5S_CDMA				
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable				
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Mon Jul 14 13:54:18 EDT 2014 Acquisition finished: Mon Jul 14 14:26:32 EDT 2014 Notification of modified device memory data was successful Notes: Case file data can be modified without warning when re-opening the test case. However, when the case is re-opened the original data is reported.				
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-AO-08 Notification of modified device case data.</td><td>as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-AO-08 Notification of modified device case data.	as expected
Assertion & Expected Result	Actual Result				
MDT-AO-08 Notification of modified device case data.	as expected				
Analysis:	Expected results achieved				

359

360 1.2.172 MDT-19 – iPhone 5S (CDMA)

Test Case MDT-19 Access Data MPE+ v5.5.2.60					
Case Summary:	MDT-19 Acquire mobile device internal memory and review data containing non-ASCII characters.				
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.				
Tester Name:	jrr				
Test Host:	pN100919				
Test Date:	Mon Jul 14 13:47:04 EDT 2014				
Device:	iPhone5S_CDMA				
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable				
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Mon Jul 14 13:47:04 EDT 2014 Acquisition finished: Mon Jul 14 13:53:23 EDT 2014 Non-ASCII Address book entries were acquired but not properly displayed Non-ASCII text messages were acquired and properly displayed Notes: Non-ASCII characters displayed in different order for address book entries.				
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.</td><td>Not as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	Not as expected
Assertion & Expected Result	Actual Result				
MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	Not as expected				
Analysis:	Partial results achieved				

361

362 1.2.173 MDT-22 – iPhone 5S (CDMA)

Test Case MDT-22 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-22 Acquire mobile device internal memory and review hash values for vendor supported data objects.

Test Case MDT-22 Access Data MPE+ v5.5.2.60						
Assertions:	MDT-AO-15 If the mobile device forensic tool supports hashing for individual data objects then the tool shall present the user with a hash value for each supported data object.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Mon Jul 14 14:29:41 EDT 2014					
Device:	iPhone5S_CDMA					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Mon Jul 14 14:29:41 EDT 2014 Acquisition finished: Mon Jul 14 14:56:44 EDT 2014 Hash values were properly reported for individually acquired device data elements					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-15 Hash values for individual data and case presented in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-15 Hash values for individual data and case presented in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-AO-15 Hash values for individual data and case presented in a useable format.	Not as expected					
Analysis:	Partial results achieved					

363

364 1.2.174 MDT-24 – iPhone 5S (CDMA)

Test Case MDT-24 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-24 Acquire mobile device internal memory and review data containing GPS longitude and latitude coordinates					
Assertions:	MDT-AO-16 If the mobile device forensic tool supports acquisition of GPS data then the tool shall present the user with the longitude and latitude coordinates for all GPS-related data in a useable format.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Mon Jul 14 14:58:01 EDT 2014					
Device:	iPhone5S CDMA					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Mon Jul 14 14:58:01 EDT 2014 Acquisition finished: Mon Jul 14 15:51:44 EDT 2014</p> <p>GPS Coordinate data was successfully acquired</p> <p>Notes: GPS latitude and longitude were not reported, but the physical address and a map screenshot of the place were reported.</p>					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-16 Acquisition of GPS related data presented in a useable format.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-16 Acquisition of GPS related data presented in a useable format.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-16 Acquisition of GPS related data presented in a useable format.	as expected					
Analysis:	Expected results achieved					

365

366

367

368 **1.2.175 MDT-01 – Nexus 4 (GSM)**

Test Case MDT-01 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-01 Acquire mobile device internal memory over tool-supported interfaces (e.g., cable, Bluetooth, IrDA).					
Assertions:	MDT-CA-01 If a mobile device forensic tool provides support for connectivity of the target device then the tool shall successfully recognize the target device via all vendor supported interfaces (e.g., cable, Bluetooth, IrDA).					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Tue Sep 2 14:22:23 EDT 2014					
Device:	Nexus4 GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Sep 2 14:22:23 EDT 2014 Acquisition finished: Tue Sep 2 15:14:58 EDT 2014 Device Connectivity was not established via supported interface					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-01 Device connectivity via supported interfaces.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-01 Device connectivity via supported interfaces.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-01 Device connectivity via supported interfaces.	as expected					
Analysis:	Expected results achieved					

369

370 **1.2.176 MDT-02 – Nexus 4 (GSM)**

Test Case MDT-02 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-02 Begin mobile device internal memory acquisition and interrupt connectivity by interface disengagement.					
Assertions:	MDT-CA-02 If connectivity between the mobile device and mobile device forensic tool is disrupted then the tool shall notify the user that connectivity has been disrupted.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Tue Sep 2 14:22:48 EDT 2014					
Device:	Nexus4 GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Sep 2 14:22:48 EDT 2014 Acquisition finished: Tue Sep 2 15:15:31 EDT 2014 Device acquisition disruption notification was successful					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-02 Notification of device acquisition disruption.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-02 Notification of device acquisition disruption.	as expected
Assertion & Expected Result	Actual Result					
MDT-CA-02 Notification of device acquisition disruption.	as expected					
Analysis:	Expected results achieved					

371

372 **1.2.177 MDT-03 – Nexus 4 (GSM)**

Test Case MDT-03 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-03 Acquire mobile device internal memory and review reported data via the preview-pane or generated reports for readability.	
Assertions:	MDT-CA-03 If a mobile device forensic tool completes acquisition of the target device without error then the tool shall have the ability to present acquired data objects in a useable format via either a preview-pane or	

Test Case MDT-03 Access Data MPE+ v5.5.2.60		
	generated report.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Tue Sep 2 14:23:25 EDT 2014	
Device:	Nexus4 GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Sep 2 14:23:25 EDT 2014 Acquisition finished: Tue Sep 2 15:17:23 EDT 2014 Readability and completeness of acquired data was successful	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-CA-03 Readability and completeness of acquired data via supported reports.	as expected
Analysis:	Expected results achieved	

373

374 1.2.178 MDT-04 – Nexus 4 (GSM)

Test Case MDT-04 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-04 Acquire mobile device internal memory and review reported subscriber and equipment related information (e.g., IMSI, IMEI, MEID/ESN, MSISDN).					
Assertions:	MDT-CA-04 If a mobile device forensic tool completes acquisition of the target device without error then subscriber and equipment related information shall be presented in a useable format.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Tue Sep 2 14:23:55 EDT 2014					
Device:	Nexus4 GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Sep 2 14:23:55 EDT 2014 Acquisition finished: Tue Sep 2 15:17:47 EDT 2014 IMEI was acquired Notes: The MSISDN was not reported.					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-CA-04 Acquisition of mobile device subscriber and equipment related data in a useable format.	Not as expected					
Analysis:	Partial results achieved					

375

376 1.2.179 MDT-05 – Nexus 4 (GSM)

Test Case MDT-05 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-05 Acquire mobile device internal memory and review supported data elements (i.e., PIM data, call logs, SMS, MMS, stand-alone files: audio, pictures, video, application related data: documents, spreadsheets, presentations, social-media data and Internet related data: bookmarks,	

Test Case MDT-05 Access Data MPE+ v5.5.2.60						
	visited sites).					
Assertions:	MDT-CA-05 If a mobile device forensic tool completes acquisition of the target device without error then all supported data elements shall be presented in a useable format.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Tue Sep 2 14:24:24 EDT 2014					
Device:	Nexus4 GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Sep 2 14:24:24 EDT 2014 Acquisition finished: Tue Sep 2 15:20:17 EDT 2014</p> <p>All address book entries were successfully acquired ALL PIM related data was acquired All Call Logs (incoming, outgoing, missed) were acquired All Call Log date/time stamps data were correctly reported ALL text messages (SMS, EMS) were acquired Correct date/time stamps were reported for all text messages Correct status flags were reported for all text messages Sender and Recipient phone numbers associated with text messages were correctly reported ALL MMS messages (Audio, Image, Video) were acquired ALL stand-alone data files (Audio, Image, Video) were acquired Application data was not acquired Partial Internet related data was acquired All Social media related data was acquired</p> <p>Notes: Graphic files associated with contact entries were not acquired. Internet related data (bookmarks) partially reported.</p>					
Results:	<table><tr><td>Assertion & Expected Result</td><td>Actual Result</td></tr><tr><td>MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-CA-05 Acquisition of all mobile device supported data elements in a useable format.	Not as expected					
Analysis:	Partial results achieved					

377

378 1.2.180 MDT-06 – Nexus 4 (GSM)

Test Case MDT-06 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-06 Acquire mobile device internal memory by selecting a combination of supported data elements.	
Assertions:	MDT-CA-06 If a mobile device forensic tool provides the user with an Acquire All device data objects acquisition option then the tool shall complete the acquisition of all data objects without error. MDT-CA-07 If a mobile device forensic tool provides the user with an Select All individual device data objects then the tool shall complete the acquisition of all individually selected data objects without error. MDT-CA-08 If a mobile device forensic tool provides the user with the ability to Select Individual device data objects for acquisition then the tool shall acquire each exclusive data object without error. MDT-CA-09 If a mobile device forensic tool completes two consecutive logical acquisitions of the target device without error then the payload (data objects) on the mobile device shall remain consistent.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Tue Sep 2 14:24:51 EDT 2014	
Device:	Nexus4 GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	

Test Case MDT-06 Access Data MPE+ v5.5.2.60											
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Sep 2 14:24:51 EDT 2014 Acquisition finished: Tue Sep 2 15:26:04 EDT 2014</p> <p>Acquire All acquisition was successful</p> <p>Select All acquisition was successful</p> <p>Individual data element acquisition was successful</p>										
Results:	<table> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> <tr> <td>MDT-CA-06 Acquire-all mobile device data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-CA-07 Select-all mobile device data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-CA-08 Select-individual mobile device data objects acquisition.</td><td>as expected</td></tr> <tr> <td>MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.</td><td>as expected</td></tr> </table>	Assertion & Expected Result	Actual Result	MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected	MDT-CA-07 Select-all mobile device data objects acquisition.	as expected	MDT-CA-08 Select-individual mobile device data objects acquisition.	as expected	MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected
Assertion & Expected Result	Actual Result										
MDT-CA-06 Acquire-all mobile device data objects acquisition.	as expected										
MDT-CA-07 Select-all mobile device data objects acquisition.	as expected										
MDT-CA-08 Select-individual mobile device data objects acquisition.	as expected										
MDT-CA-09 Perform back-to-back acquisitions, check device payload for modifications.	as expected										
Analysis:	Expected results achieved										

379

380 1.2.181 MDT-07 – Nexus 4 (GSM)

Test Case MDT-07 Access Data MPE+ v5.5.2.60					
Case Summary:	MDT-07 Acquire UICC memory over supported interfaces (e.g., PC/SC reader).				
Assertions:	MDT-AO-01 If a mobile device forensic tool provides support for connectivity of the target UICC then the tool shall successfully recognize the target SIM via all tool-supported interfaces (e.g., PC/SC reader, proprietary reader, smart phone itself).				
Tester Name:	jrr				
Test Host:	pN100919				
Test Date:	Tue Sep 2 15:30:25 EDT 2014				
Device:	Nexus4 GSM				
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB				
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Sep 2 15:30:25 EDT 2014 Acquisition finished: Wed Sep 3 14:31:47 EDT 2014</p> <p>UICC connectivity was established via supported interface</p>				
Results:	<table> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> <tr> <td>MDT-AO-01 UICC connectivity via supported interfaces.</td><td>as expected</td></tr> </table>	Assertion & Expected Result	Actual Result	MDT-AO-01 UICC connectivity via supported interfaces.	as expected
Assertion & Expected Result	Actual Result				
MDT-AO-01 UICC connectivity via supported interfaces.	as expected				
Analysis:	Expected results achieved				

381 1.2.182 MDT-08 – Nexus 4 (GSM)

Test Case MDT-08 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-08 Begin UICC acquisition and interrupt connectivity by interface disengagement.
Assertions:	MDT-AO-02 If a mobile device forensic tool loses connectivity with the UICC reader then the tool shall notify the user that connectivity has been disrupted.
Tester Name:	jrr
Test Host:	pN100919

Test Case MDT-08 Access Data MPE+ v5.5.2.60						
Test Date:	Wed Sep 3 10:32:59 EDT 2014					
Device:	Nexus4_GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Sep 3 10:32:59 EDT 2014 Acquisition finished: Wed Sep 3 14:32:07 EDT 2014 Media acquisition disruption notification was not successful Notes: No error message when disrupting connectivity, it stopped and reported the data recovered until connectivity was disrupted.					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-02 Notification of SIM acquisition disruption.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-02 Notification of SIM acquisition disruption.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-AO-02 Notification of SIM acquisition disruption.	Not as expected					
Analysis:	Expected results not achieved					

382

383 1.2.183 MDT-09 – Nexus 4 (GSM)

Test Case MDT-09 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-09Acquire UICC memory and review reported subscriber and equipment related information (i.e., SPN, ICCID, IMSI, MSISDN).					
Assertions:	MDT-AO-03 If a mobile device forensic tool completes acquisition of the target UICC without error then the subscriber and equipment related data shall be presented in a useable format.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Wed Sep 3 10:35:36 EDT 2014					
Device:	Nexus4 GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Sep 3 10:35:36 EDT 2014 Acquisition finished: Wed Sep 3 14:34:15 EDT 2014 SPN was not acquired ICCID was acquired IMSI was acquired MSISDN was acquired					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-03 Acquisition of UICC subscriber and equipment related data in a useable format.</td><td>Not as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-03 Acquisition of UICC subscriber and equipment related data in a useable format.	Not as expected
Assertion & Expected Result	Actual Result					
MDT-AO-03 Acquisition of UICC subscriber and equipment related data in a useable format.	Not as expected					
Analysis:	Partial results achieved					

384

385 1.2.184 MDT-10 – Nexus 4 (GSM)

Test Case MDT-10 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-10 Acquire UICC memory and review supported data elements (i.e., Abbreviated Dialing Numbers, Last Numbers Dialed, SMS/EMS text messages, and location related data: LOCI, GPRSLOCI).
Assertions:	MDT-AO-04 If a mobile device forensic tool completes acquisition of the target UICC without error then all acquired data shall be presented in a useable format.

Test Case MDT-10 Access Data MPE+ v5.5.2.60					
Tester Name:	jrr				
Test Host:	pN100919				
Test Date:	Wed Sep 3 10:36:10 EDT 2014				
Device:	Nexus4 GSM				
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB				
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Sep 3 10:36:10 EDT 2014 Acquisition finished: Wed Sep 3 14:34:40 EDT 2014</p> <p>All ADNs were acquired LNDs were acquired Date/Time Stamps correctly reported for LNDs ALL text messages (SMS, EMS) were acquired All date/time stamps were reported for text messages Correct status flags were reported for text messages Sender and Recipient phone numbers associated with text messages were correctly reported Deleted text message data was recovered LOCI data was acquired GPRSLOCI data was acquired</p> <p>Notes: French contact entry was incorrectly reported as Aur[0x05]lien instead of Aurélien.</p>				
Results:	<table border="1"> <thead> <tr> <th>Assertion & Expected Result</th><th>Actual Result</th></tr> </thead> <tbody> <tr> <td>MDT-AO-04 Acquisition of all UICC supported data elements in a useable format.</td><td>Not as expected</td></tr> </tbody> </table>	Assertion & Expected Result	Actual Result	MDT-AO-04 Acquisition of all UICC supported data elements in a useable format.	Not as expected
Assertion & Expected Result	Actual Result				
MDT-AO-04 Acquisition of all UICC supported data elements in a useable format.	Not as expected				
Analysis:	Partial results achieved				

386

387 1.2.185 MDT-11 – Nexus 4 (GSM)

Test Case MDT-11 Access Data MPE+ v5.5.2.60	
Case Summary:	MDT-11 Acquire UICC memory by selecting a combination of supported data elements.
Assertions:	<p>MDT-AO-05 If a mobile device forensic tool provides the user with an Acquire All UICC data objects acquisition option then the tool shall complete the acquisition of all data objects without error.</p> <p>MDT-AO-06 If a mobile device forensic tool provides the user with an Select All individual UICC data objects then the tool shall complete the acquisition of all individually selected data objects without error.</p> <p>MDT-AO-07 If a mobile device forensic tool provides the user with the ability to Select Individual UICC data objects for acquisition then the tool shall acquire each exclusive data object without error.</p>
Tester Name:	jrr
Test Host:	pN100919
Test Date:	Wed Sep 3 10:36:46 EDT 2014
Device:	Nexus4 GSM
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Sep 3 10:36:46 EDT 2014 Acquisition finished: Wed Sep 3 14:36:38 EDT 2014</p> <p>Acquire All acquisition was successful Select All acquisition was successful Individual data element acquisition was successful</p>
Results:	

Test Case MDT-11 Access Data MPE+ v5.5.2.60		
	Assertion & Expected Result	Actual Result
	MDT-AO-05 Acquire-all UICC data objects acquisition.	as expected
	MDT-AO-06 Select-all UICC data objects acquisition.	as expected
	MDT-AO-07 Select-individual UICC data objects acquisition.	as expected
Analysis:	Expected results achieved	

388 1.2.186 MDT-12 – Nexus 4 (GSM)

Test Case MDT-12 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-12 After a successful mobile device internal memory, alter the case file via third-party means and attempt to re-open the case.	
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Tue Sep 2 14:25:16 EDT 2014	
Device:	Nexus4 GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable	
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Sep 2 14:25:16 EDT 2014 Acquisition finished: Tue Sep 2 15:26:27 EDT 2014</p> <p>Notification of modified device memory data was successful</p> <p>Notes: Case file data can be modified without warning when re-opening the test case. However, when the test case is re-opened the original data is reported. Tool only gives warning when the case size changes.</p>	
Results:	Assertion & Expected Result	Actual Result
	MDT-AO-08 Notification of modified device case data.	as expected
Analysis:	Expected results achieved	

389

390 1.2.187 MDT-13 – Nexus 4 (GSM)

Test Case MDT-13 Access Data MPE+ v5.5.2.60		
Case Summary:	MDT-13 After a successful UICC acquisition, alter the case file via third-party means and attempt to re-open the case.	
Assertions:	MDT-AO-08 If the case file or individual data objects are modified via third-party means then the tool shall provide protection mechanisms disallowing or reporting data modification.	
Tester Name:	jrr	
Test Host:	pN100919	
Test Date:	Wed Sep 3 10:37:15 EDT 2014	
Device:	Nexus4 GSM	
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB	
Log Highlights:	<p>Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Sep 3 10:37:15 EDT 2014 Acquisition finished: Wed Sep 3 14:37:04 EDT 2014</p> <p>Notification of modified SIM data was successful</p> <p>Notes: Case file data can be modified without warning when re-opening the test</p>	

Test Case MDT-13 Access Data MPE+ v5.5.2.60		
	case. However, when the case is re-opened the original data is reported. Tool only gives warning when file size changes.	
Results:		
	Assertion & Expected Result	Actual Result
	MDT-AO-08 Notification of modified device case data.	as expected
Analysis:	Expected results achieved	

391

392 1.2.188 MDT-14 – Nexus 4 (GSM)

Test Case MDT-14 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-14 Attempt acquisition of a password-protected UICC.					
Assertions:	MDT-AO-09 If the UICC is password-protected then the mobile device forensic tool shall provide the examiner with the opportunity to input the PIN before acquisition.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Wed Sep 3 10:37:45 EDT 2014					
Device:	Nexus4_GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Sep 3 10:37:45 EDT 2014 Acquisition finished: Wed Sep 3 14:38:14 EDT 2014 Ability to enter PIN on protected media before acquisition was successful					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-09 Acquisition of password protected UICC.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-09 Acquisition of password protected UICC.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-09 Acquisition of password protected UICC.	as expected					
Analysis:	Expected results achieved					

393

394 1.2.189 MDT-15 – Nexus 4 (GSM)

Test Case MDT-15 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-15 Begin acquisition on a PIN protected UICC to determine if the tool provides an accurate count of the remaining number of PIN attempts and if the PIN attempts are decremented when entering an incorrect value.					
Assertions:	MDT-AO-10 If a mobile device forensic tool provides the examiner with the remaining number of authentication attempts then the application should provide an accurate count of the remaining PIN attempts.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Wed Sep 3 10:38:26 EDT 2014					
Device:	Nexus4 GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Sep 3 10:38:26 EDT 2014 Acquisition finished: Wed Sep 3 14:38:48 EDT 2014 The remaining number of PIN attempts were properly displayed					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-10 Remaining number of PIN attempts properly</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-10 Remaining number of PIN attempts properly	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-10 Remaining number of PIN attempts properly	as expected					

Test Case MDT-15 Access Data MPE+ v5.5.2.60		
	displayed.	
Analysis:	Expected results achieved	

395

396 1.2.190 MDT-16 – Nexus 4 (GSM)

Test Case MDT-16 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-16 Begin acquisition on a UICC whose PIN attempts have been exhausted to determine if the tool provides an accurate count of the remaining number of PUK attempts and if the PUK attempts are decremented when entering an incorrect value.					
Assertions:	MDT-AO-11 If a mobile device forensic tool provides the examiner with the remaining number of PUK attempts then the application should provide an accurate count of the remaining PUK attempts.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Fri Sep 5 14:52:05 EDT 2014					
Device:	Nexus4 GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Fri Sep 5 14:52:05 EDT 2014 Acquisition finished: Fri Sep 5 15:47:35 EDT 2014 Remaining number of PUK attempts were properly displayed					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-11 Remaining number of PUK attempts properly displayed.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-11 Remaining number of PUK attempts properly displayed.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-11 Remaining number of PUK attempts properly displayed.	as expected					
Analysis:	Expected results achieved					

397

398 1.2.191 MDT-19 – Nexus 4 (GSM)

Test Case MDT-19 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-19 Acquire mobile device internal memory and review data containing non-ASCII characters.					
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Tue Sep 2 14:25:42 EDT 2014					
Device:	Nexus4 GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Sep 2 14:25:42 EDT 2014 Acquisition finished: Tue Sep 2 15:27:41 EDT 2014 Non-ASCII Address book entries were acquired and properly displayed Non-ASCII text messages were acquired and properly displayed					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-13 Acquisition of data containing non-ASCII</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-13 Acquisition of data containing non-ASCII	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-13 Acquisition of data containing non-ASCII	as expected					

Test Case MDT-19 Access Data MPE+ v5.5.2.60		
	characters presented in their native format.	
Analysis:	Expected results achieved	

399

400 1.2.192 MDT-20 – Nexus 4 (GSM)

Test Case MDT-20 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-20 Acquire UICC memory and review data containing non-ASCII characters.					
Assertions:	MDT-AO-13 If the mobile device forensic tool supports display of non-ASCII characters then acquired data containing non-ASCII characters should be presented in their native format.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Wed Sep 3 10:39:13 EDT 2014					
Device:	Nexus4 GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: USB					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Wed Sep 3 10:39:13 EDT 2014 Acquisition finished: Wed Sep 3 14:39:10 EDT 2014 Non-ASCII ADNs were acquired and properly displayed Non-ASCII text messages were acquired and properly displayed					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-13 Acquisition of data containing non-ASCII characters presented in their native format.	as expected					
Analysis:	Expected results achieved					

401

402 1.2.193 MDT-22 – Nexus 4 (GSM)

Test Case MDT-22 Access Data MPE+ v5.5.2.60						
Case Summary:	MDT-22 Acquire mobile device internal memory and review hash values for vendor supported data objects.					
Assertions:	MDT-AO-15 If the mobile device forensic tool supports hashing for individual data objects then the tool shall present the user with a hash value for each supported data object.					
Tester Name:	jrr					
Test Host:	pN100919					
Test Date:	Tue Sep 2 14:26:07 EDT 2014					
Device:	Nexus4 GSM					
Source Setup:	OS: WIN 7 v6.1.7601 Interface: cable					
Log Highlights:	Created by Access Data MPE+ v5.5.2.60 Acquisition started: Tue Sep 2 14:26:07 EDT 2014 Acquisition finished: Tue Sep 2 15:28:15 EDT 2014 Hash values were properly reported for individually acquired device data elements					
Results:	<table><tr><th>Assertion & Expected Result</th><th>Actual Result</th></tr><tr><td>MDT-AO-15 Hash values for individual data and case presented in a useable format.</td><td>as expected</td></tr></table>		Assertion & Expected Result	Actual Result	MDT-AO-15 Hash values for individual data and case presented in a useable format.	as expected
Assertion & Expected Result	Actual Result					
MDT-AO-15 Hash values for individual data and case presented in a useable format.	as expected					

Test Case MDT-22 Access Data MPE+ v5.5.2.60	
Analysis:	Expected results achieved

403